



BSP Hex Plug

Part Number	BSP M
A-B1-02	-02
A-B1-04	-04
A-B1-06	-06
A-B1-08	-08
A-B1-10	-10
A-B1-12	-12
A-B1-16	-16
A-B1-20	-20
A-B1-24	-24
A-B1-32	-32
A-B1-40	-40
A-B1-48	-48



BSPP Elastomer Allen Plug

Part Number	BSP M
A-6B2-02	-02
A-6B2-04	-04
A-6B2-06	-06
A-6B2-08	-08
A-6B2-12	-12
A-6B2-16	-16
A-6B2-20	-20
A-6B2-24	-24
A-6B2-32	-32



BSP Cap

Part Number	BSP F
A-B3-02	-02
A-B3-04	-04
A-B3-06	-06
A-B3-08	-08
A-B3-10	-10
A-B3-12	-12
A-B3-16	-16
A-B3-20	-20
A-B3-24	-24
A-B3-32	-32



BSP Bonded Seal

Part Number	BSP Thread Size
B102-02	-02
B102-04	-04
B102-06	-06
B102-08	-08
B102-10	-10
B102-12	-12
B102-16	-16
B102-20	-20
B102-24	-24
B102-32	-32



BSP Male x BSP Male

Part Number	BSP M(T1)	BSP M(T2)
A-B10-0202	-02	-02
A-B10-0402	-04	-02
A-B10-0404	-04	-04
A-B10-0602	-06	-02
A-B10-0604	-06	-04
A-B10-0606	-06	-06
A-B10-0802	-08	-02
A-B10-0804	-08	-04
A-B10-0806	-08	-06
A-B10-0808	-08	-08
A-B10-1004	-10	-04
A-B10-1006	-10	-06
A-B10-1008	-10	-08
A-B10-1010	-10	-10
A-B10-1204	-12	-04
A-B10-1206	-12	-06
A-B10-1208	-12	-08
A-B10-1210	-12	-10
A-B10-1212	-12	-12
A-B10-1604	-16	-04
A-B10-1606	-16	-06
A-B10-1608	-16	-08
A-B10-1610	-16	-10
CONTINUED		

BSP Male x BSP Male

Part Number	BSP M(T1)	BSP M(T2)
A-B10-1612	-16	-12
A-B10-1616	-16	-16
A-B10-2006	-20	-06
A-B10-2008	-20	-08
A-B10-2010	-20	-10
A-B10-2012	-20	-12
A-B10-2016	-20	-16
A-B10-2020	-20	-20
A-B10-2408	-24	-08
A-B10-2410	-24	-10
A-B10-2412	-24	-12
A-B10-2416	-24	-16
A-B10-2420	-24	-20
A-B10-2424	-24	-24
A-B10-3216	-32	-16
A-B10-3220	-32	-20
A-B10-3224	-32	-24
A-B10-3232	-32	-32
A-B10-4024	-40	-24
A-B10-4032	-40	-32
A-B10-4040	-40	-40
A-B10-4832	-48	-32
A-B10-4840	-48	-40
A-B10-4848	-48	-48

BSP

ADAPTERS



BSPP O-Ring Male x BSP Male		
Part Number	BSPP M(T1)	BSP M(T2)
A-5BB10-0202	-02	-02
A-5BB10-0404	-04	-04
A-5BB10-0606	-06	-06
A-5BB10-0808	-08	-08
A-5BB10-1212	-12	-12
A-5BB10-1616	-16	-16
A-5BB10-2020	-20	-20
A-5BB10-2424	-24	-24



BSP Male x ORFS Male		
Part Number	BSP M(T1)	ORFS M(T2)
A-BF10-0408	-04	-08
A-BF10-0604	-06	-04
A-BF10-0606	-06	-06
A-BF10-0608	-06	-08
A-BF10-0806	-08	-06
A-BF10-0808	-08	-08
A-BF10-0810	-08	-10
A-BF10-1210	-12	-10
A-BF10-1212	-12	-12
A-BF10-1216	-12	-16
A-BF10-1612	-16	-12
A-BF10-1616	-16	-16
A-BF10-1620	-16	-20
A-BF10-2020	-20	-20



BSPP O-Ring Male x ORFS Male		
Part Number	BSPP M(T1)	ORFS M(T2)
A-5BF10-0204	-02	-04
A-5BF10-0404	-04	-04
A-5BF10-0406	-04	-06
A-5BF10-0408	-04	-08
A-5BF10-0604	-06	-04
A-5BF10-0606	-06	-06
A-5BF10-0608	-06	-08
A-5BF10-0610	-06	-10
A-5BF10-0806	-08	-06
A-5BF10-0808	-08	-08
A-5BF10-0810	-08	-10
CONTINUED		



BSPP O-Ring Male x ORFS Male		
Part Number	BSPP M(T1)	ORFS M(T2)
A-5BF10-0812	-08	-12
A-5BF10-1208	-12	-08
A-5BF10-1210	-12	-10
A-5BF10-1212	-12	-12
A-5BF10-1216	-12	-16
A-5BF10-1608	-16	-08
A-5BF10-1612	-16	-12
A-5BF10-1616	-16	-16
A-5BF10-1620	-16	-20
A-5BF10-2020	-20	-20
A-5BF10-2424	-24	-24

ADAPTERS

BSP



BSP Male x JIC Male

Part Number	BSP M(T1)	JIC M(T2)
A-BJ10-0204	-02	-04
A-BJ10-0205	-02	-05
A-BJ10-0206	-02	-06
A-BJ10-0404	-04	-04
A-BJ10-0405	-04	-05
A-BJ10-0406	-04	-06
A-BJ10-0408	-04	-08
A-BJ10-0410	-04	-10
A-BJ10-0412	-04	-12
A-BJ10-0604	-06	-04
A-BJ10-0605	-06	-05
A-BJ10-0606	-06	-06
A-BJ10-0608	-06	-08
A-BJ10-0610	-06	-10
A-BJ10-0612	-06	-12
A-BJ10-0804	-08	-04
A-BJ10-0805	-08	-05
A-BJ10-0806	-08	-06
A-BJ10-0808	-08	-08
A-BJ10-0810	-08	-10
A-BJ10-0812	-08	-12
A-BJ10-0816	-08	-16
A-BJ10-1006	-10	-06
A-BJ10-1008	-10	-08
A-BJ10-1010	-10	-10
A-BJ10-1012	-10	-12
A-BJ10-1016	-10	-16

CONTINUED

BSP Male x JIC Male

Part Number	BSP M(T1)	JIC M(T2)
A-BJ10-1204	-12	-04
A-BJ10-1206	-12	-06
A-BJ10-1208	-12	-08
A-BJ10-1210	-12	-10
A-BJ10-1212	-12	-12
A-BJ10-1214	-12	-14
A-BJ10-1216	-12	-16
A-BJ10-1220	-12	-20
A-BJ10-1608	-16	-08
A-BJ10-1610	-16	-10
A-BJ10-1612	-16	-12
A-BJ10-1614	-16	-14
A-BJ10-1616	-16	-16
A-BJ10-1620	-16	-20
A-BJ10-1624	-16	-24
A-BJ10-1632	-16	-32
A-BJ10-2012	-20	-12
A-BJ10-2016	-20	-16
A-BJ10-2020	-20	-20
A-BJ10-2024	-20	-24
A-BJ10-2032	-20	-32
A-BJ10-2416	-24	-16
A-BJ10-2420	-24	-20
A-BJ10-2424	-24	-24
A-BJ10-2432	-24	-32
A-BJ10-3224	-32	-24
A-BJ10-3232	-32	-32

ADAPTERS

BSP



BSP/BSPP O-Ring Male x JIC Male

Part Number	BSP M(T1)	JIC M(T2)
A-9BJ10-0204	-02	-04
A-9BJ10-0206	-02	-06
A-9BJ10-0404	-04	-04
A-9BJ10-0405	-04	-05
A-9BJ10-0406	-04	-06
A-9BJ10-0408	-04	-08
A-9BJ10-0604	-06	-04
A-9BJ10-0606	-06	-06
A-9BJ10-0608	-06	-08
A-9BJ10-0804	-08	-04
A-9BJ10-0806	-08	-06
A-9BJ10-0808	-08	-08
A-9BJ10-0810	-08	-10
A-9BJ10-0812	-08	-12
A-9BJ10-1008	-10	-08
A-9BJ10-1010	-10	-10
A-9BJ10-1012	-10	-12
A-9BJ10-1206	-12	-06
A-9BJ10-1208	-12	-08
A-9BJ10-1210	-12	-10
A-9BJ10-1212	-12	-12
A-9BJ10-1216	-12	-16
A-9BJ10-1608	-16	-08
A-9BJ10-1612	-16	-12
A-9BJ10-1616	-16	-16
A-9BJ10-1620	-16	-20
A-9BJ10-2012	-20	-12
A-9BJ10-2016	-20	-16
A-9BJ10-2020	-20	-20
A-9BJ10-2416	-24	-16
A-9BJ10-2420	-24	-20
A-9BJ10-2424	-24	-24
A-9BJ10-3232	-32	-32

BSPP O-Ring Male x JIC Male

Part Number	BSPP M(T1)	JIC M(T2)
A-5BJ10-0204	-02	-04
A-5BJ10-0205	-02	-05
A-5BJ10-0404	-04	-04
A-5BJ10-0405	-04	-05
A-5BJ10-0406	-04	-06
A-5BJ10-0408	-04	-08
A-5BJ10-0604	-06	-04
A-5BJ10-0605	-06	-05
A-5BJ10-0606	-06	-06
A-5BJ10-0608	-06	-08
A-5BJ10-0610	-06	-10
A-5BJ10-0612	-06	-12
A-5BJ10-0804	-08	-04
A-5BJ10-0806	-08	-06
A-5BJ10-0808	-08	-08
A-5BJ10-0810	-08	-10
A-5BJ10-0812	-08	-12
A-5BJ10-1008	-10	-08
A-5BJ10-1208	-12	-08
A-5BJ10-1210	-12	-10
A-5BJ10-1212	-12	-12
A-5BJ10-1214	-12	-14
A-5BJ10-1216	-12	-16
A-5BJ10-1608	-16	-08
A-5BJ10-1612	-16	-12
A-5BJ10-1616	-16	-16
A-5BJ10-1620	-16	-20
A-5BJ10-2012	-20	-12
A-5BJ10-2016	-20	-16
A-5BJ10-2020	-20	-20
A-5BJ10-2024	-20	-24
A-5BJ10-2420	-24	-20
A-5BJ10-2424	-24	-24



BSP Elastomer Male x DIN Male

Part Number	BSP M(T1)	DIN M(T2)
A-6BM10-0204LL	-02	04LL
A-6BM10-0206LL	-02	06LL
A-6BM10-0208LL	-02	08LL
A-6BM10-0206L	-02	06L
A-6BM10-0208L	-02	08L
A-6BM10-0210L	-02	10L
A-6BM10-0406L	-04	06L
A-6BM10-0406S	-04	06S
A-6BM10-0408L	-04	08L
A-6BM10-0408S	-04	08S
A-6BM10-0410L	-04	10L
A-6BM10-0410S	-04	10S
A-6BM10-0412L	-04	12L
A-6BM10-0412S	-04	12S
A-6BM10-0606L	-06	06L
A-6BM10-0608L	-06	08L
A-6BM10-0608S	-06	08S
A-6BM10-0610L	-06	10L
A-6BM10-0610S	-06	10S
A-6BM10-0612L	-06	12L
A-6BM10-0612S	-06	12S
A-6BM10-0614S	-06	14S
A-6BM10-0615L	-06	15L
A-6BM10-0616S	-06	16S
A-6BM10-0808L	-08	08L
A-6BM10-0810L	-08	10L
A-6BM10-0810S	-08	10S
A-6BM10-0812L	-08	12L
A-6BM10-0812S	-08	12S

CONTINUED

BSP Elastomer Male x DIN Male

Part Number	BSP M(T1)	DIN M(T2)
A-6BM10-0814S	-08	14S
A-6BM10-0815L	-08	15L
A-6BM10-0816S	-08	16S
A-6BM10-0818L	-08	18L
A-6BM10-0820S	-08	20S
A-6BM10-0822L	-08	22L
A-6BM10-1215L	-12	15L
A-6BM10-1216S	-12	16S
A-6BM10-1218L	-12	18L
A-6BM10-1220S	-12	20S
A-6BM10-1222L	-12	22L
A-6BM10-1225S	-12	25S
A-6BM10-1228L	-12	28L
A-6BM10-1620S	-16	20S
A-6BM10-1622L	-16	22L
A-6BM10-1625S	-16	25S
A-6BM10-1628L	-16	28L
A-6BM10-1630S	-16	30S
A-6BM10-1635L	-16	35L
A-6BM10-2014S	-20	14S
A-6BM10-2025S	-20	25S
A-6BM10-2028L	-20	28L
A-6BM10-2030S	-20	30S
A-6BM10-2035L	-20	35L
A-6BM10-2038S	-20	38S
A-6BM10-2042L	-20	42L
A-6BM10-2430S	-24	30S
A-6BM10-2438S	-24	38S
A-6BM10-2442L	-24	42L

ADAPTERS

BSP



BSP Male x NPT Male

Part Number	BSP M(T1)	NPT M(T2)
A-BP10-0202	-02	-02
A-BP10-0204	-02	-04
A-BP10-0206	-02	-06
A-BP10-0402	-04	-02
A-BP10-0404	-04	-04
A-BP10-0406	-04	-06
A-BP10-0408	-04	-08
A-BP10-0602	-06	-02
A-BP10-0604	-06	-04
A-BP10-0606	-06	-06
A-BP10-0608	-06	-08
A-BP10-0612	-06	-12
A-BP10-0616	-06	-16
A-BP10-0804	-08	-04
A-BP10-0806	-08	-06
A-BP10-0808	-08	-08
A-BP10-0812	-08	-12
A-BP10-0816	-08	-16
A-BP10-1008	-10	-08
A-BP10-1012	-10	-12
A-BP10-1204	-12	-04
A-BP10-1206	-12	-06
A-BP10-1208	-12	-08
A-BP10-1212	-12	-12
A-BP10-1216	-12	-16
A-BP10-1220	-12	-20

CONTINUED

BSP Male x NPT Male

Part Number	BSP M(T1)	NPT M(T2)
A-BP10-1606	-16	-06
A-BP10-1608	-16	-08
A-BP10-1612	-16	-12
A-BP10-1616	-16	-16
A-BP10-1620	-16	-20
A-BP10-1624	-16	-24
A-BP10-1632	-16	-32
A-BP10-2012	-20	-12
A-BP10-2016	-20	-16
A-BP10-2020	-20	-20
A-BP10-2024	-20	-24
A-BP10-2412	-24	-12
A-BP10-2416	-24	-16
A-BP10-2420	-24	-20
A-BP10-2424	-24	-24
A-BP10-2432	-24	-32
A-BP10-3220	-32	-20
A-BP10-3224	-32	-24
A-BP10-3232	-32	-32
A-BP10-3240	-32	-40
A-BP10-3248	-32	-48
A-BP10-4032	-40	-32
A-BP10-4040	-40	-40
A-BP10-4048	-40	-48
A-BP10-4848	-48	-48
A-BP10-6464	-64	-64

BSP

ADAPTERS

ADAPTERS

BSP



BSP Male x ORB Male

Part Number	BSP M(T1)	ORB M(T2)
A-BR10-0404	-04	-04
A-BR10-0405	-04	-05
A-BR10-0406	-04	-06
A-BR10-0408	-04	-08
A-BR10-0604	-06	-04
A-BR10-0605	-06	-05
A-BR10-0606	-06	-06
A-BR10-0608	-06	-08
A-BR10-0610	-06	-10
A-BR10-0804	-08	-04
A-BR10-0806	-08	-06
A-BR10-0808	-08	-08
A-BR10-0810	-08	-10
A-BR10-0812	-08	-12
A-BR10-1008	-10	-08
A-BR10-1010	-10	-10
A-BR10-1208	-12	-08
A-BR10-1210	-12	-10
A-BR10-1212	-12	-12
A-BR10-1216	-12	-16
A-BR10-1612	-16	-12
A-BR10-1616	-16	-16
A-BR10-1620	-16	-20
A-BR10-2016	-20	-16
A-BR10-2020	-20	-20
A-BR10-2024	-20	-24
A-BR10-2420	-24	-20
A-BR10-2424	-24	-24

BSP Male x BSP Female

Part Number	BSP M(T1)	BSP F(T2)
A-B22-0202	-02	-02
A-B22-0204	-02	-04
A-B22-0402	-04	-02
A-B22-0404	-04	-04
A-B22-0406	-04	-06
A-B22-0408	-04	-08
A-B22-0602	-06	-02
A-B22-0604	-06	-04
A-B22-0606	-06	-06
A-B22-0608	-06	-08
A-B22-0610	-06	-10
A-B22-0612	-06	-12
A-B22-0802	-08	-02
A-B22-0804	-08	-04
A-B22-0806	-08	-06
A-B22-0808	-08	-08
A-B22-0810	-08	-10
A-B22-0812	-08	-12
A-B22-0816	-08	-16
A-B22-1008	-10	-08
A-B22-1010	-10	-10
A-B22-1012	-10	-12
A-B22-1204	-12	-04
A-B22-1206	-12	-06
A-B22-1208	-12	-08
A-B22-1210	-12	-10
A-B22-1212	-12	-12
A-B22-1216	-12	-16
A-B22-1220	-12	-20
A-B22-1608	-16	-08
A-B22-1610	-16	-10
A-B22-1612	-16	-12
A-B22-1616	-16	-16
A-B22-1620	-16	-20
A-B22-2012	-20	-12
A-B22-2016	-20	-16
A-B22-2020	-20	-20
A-B22-2024	-20	-24
A-B22-2416	-24	-16
A-B22-2420	-24	-20
A-B22-2424	-24	-24
A-B22-2432	-24	-32
A-B22-3224	-32	-24
A-B22-3232	-32	-32



BSPP Elastomer Male x BSPP Female

Part Number	BSPP M(T1)	BSPP F(T2)
A-6B22-0204	-02	-04
A-6B22-0206	-02	-06
A-6B22-0402	-04	-02
A-6B22-0406	-04	-06
A-6B22-0408	-04	-08
A-6B22-0412	-04	-12
A-6B22-0602	-06	-02
A-6B22-0604	-06	-04
A-6B22-0608	-06	-08
A-6B22-0612	-06	-12
A-6B22-0802	-08	-02
A-6B22-0804	-08	-04
A-6B22-0806	-08	-06
A-6B22-0812	-08	-12
A-6B22-0816	-08	-16
A-6B22-0820	-08	-20
A-6B22-1204	-12	-04
A-6B22-1206	-12	-06
A-6B22-1208	-12	-08
A-6B22-1216	-12	-16
A-6B22-1220	-12	-20
A-6B22-1224	-12	-24

CONTINUED

BSPP Elastomer Male x BSPP Female

Part Number	BSPP M(T1)	BSPP F(T2)
A-6B22-1604	-16	-04
A-6B22-1606	-16	-06
A-6B22-1608	-16	-08
A-6B22-1612	-16	-12
A-6B22-1616	-16	-16
A-6B22-1620	-16	-20
A-6B22-1624	-16	-24
A-6B22-2008	-20	-08
A-6B22-2012	-20	-12
A-6B22-2016	-20	-16
A-6B22-2020	-20	-20
A-6B22-2024	-20	-24
A-6B22-2408	-24	-08
A-6B22-2412	-24	-12
A-6B22-2416	-24	-16
A-6B22-2420	-24	-20
A-6B22-2424	-24	-24
A-6B22-3216	-32	-16
A-6B22-3220	-32	-20
A-6B22-3224	-32	-24
A-6B22-3232	-32	-32
A-6B22-4032	-40	-32

ADAPTERS

BSPP



BSP Male x JIC Female

Part Number	BSP M(T1)	JIC F(T2)
A-BJ22-0204	-02	-04
A-BJ22-0404	-04	-04
A-BJ22-0405	-04	-05
A-BJ22-0406	-04	-06
A-BJ22-0408	-04	-08
A-BJ22-0604	-06	-04
A-BJ22-0605	-06	-05
A-BJ22-0606	-06	-06
A-BJ22-0608	-06	-08
A-BJ22-0610	-06	-10
A-BJ22-0804	-08	-04
A-BJ22-0806	-08	-06
A-BJ22-0808	-08	-08
A-BJ22-0810	-08	-10
A-BJ22-0812	-08	-12
A-BJ22-1008	-10	-08
A-BJ22-1010	-10	-10
A-BJ22-1012	-10	-12
A-BJ22-1208	-12	-08
A-BJ22-1210	-12	-10
A-BJ22-1212	-12	-12
A-BJ22-1214	-12	-14
A-BJ22-1216	-12	-16
A-BJ22-1612	-16	-12
A-BJ22-1614	-16	-14
A-BJ22-1616	-16	-16
A-BJ22-1620	-16	-20
A-BJ22-2016	-20	-16
A-BJ22-2020	-20	-20
A-BJ22-2024	-20	-24
A-BJ22-2424	-24	-24
A-BJ22-3224	-32	-24
A-BJ22-3232	-32	-32

BSPP Elastomer Male x DIN Female

Part Number	BSPP M(T1)	DIN F(T2)
A-6BM22-0206L	-02	06L
A-6BM22-0406S	-04	06S
A-6BM22-0408L	-04	08L
A-6BM22-0408S	-04	08S
A-6BM22-0410L	-04	10L
A-6BM22-0410S	-04	10S
A-6BM22-0412L	-04	12L
A-6BM22-0610L	-06	10L
A-6BM22-0610S	-06	10S
A-6BM22-0612L	-06	12L
A-6BM22-0612S	-06	12S
A-6BM22-0812L	-08	12L
A-6BM22-0812S	-08	12S
A-6BM22-0814S	-08	14S
A-6BM22-0815L	-08	15L
A-6BM22-0816S	-08	16S
A-6BM22-0818L	-08	18L
A-6BM22-1218L	-12	18L
A-6BM22-1220S	-12	20S
A-6BM22-1222L	-12	22L
A-6BM22-1625S	-16	25S
A-6BM22-1628L	-16	28L
A-6BM22-2030S	-20	30S
A-6BM22-2035L	-20	35L
A-6BM22-2438S	-24	38S
A-6BM22-2442L	-24	42L



BSP Male x NPT Female

Part Number	BSP M(T1)	NPT F(T2)
A-BP22-0202	-02	-02
A-BP22-0204	-02	-04
A-BP22-0402	-04	-02
A-BP22-0404	-04	-04
A-BP22-0406	-04	-06
A-BP22-0408	-04	-08
A-BP22-0602	-06	-02
A-BP22-0604	-06	-04
A-BP22-0606	-06	-06
A-BP22-0608	-06	-08
A-BP22-0802	-08	-02
A-BP22-0804	-08	-04
A-BP22-0806	-08	-06
A-BP22-0808	-08	-08
A-BP22-1006	-10	-06
A-BP22-1204	-12	-04
A-BP22-1206	-12	-06
A-BP22-1208	-12	-08
A-BP22-1212	-12	-12
A-BP22-1604	-16	-04
A-BP22-1606	-16	-06
A-BP22-1608	-16	-08
A-BP22-1612	-16	-12
A-BP22-1616	-16	-16
A-BP22-2012	-20	-12
A-BP22-2016	-20	-16
A-BP22-2020	-20	-20
A-BP22-2024	-20	-24
A-BP22-2412	-24	-12
A-BP22-2416	-24	-16
A-BP22-2420	-24	-20
A-BP22-2424	-24	-24
A-BP22-2432	-24	-32
A-BP22-3212	-32	-12
A-BP22-3224	-32	-24
A-BP22-3232	-32	-32
A-BP22-4024	-40	-24
A-BP22-4032	-40	-32
A-BP22-4040	-40	-40
A-BP22-4048	-40	-48
A-BP22-4832	-48	-32
A-BP22-4848	-48	-48

BSP Male x ORB Female

Part Number	BSP M(T1)	ORB F(T2)
A-BR22-0202	-02	-02
A-BR22-0204	-02	-04
A-BR22-0404	-04	-04
A-BR22-0405	-04	-05
A-BR22-0406	-04	-06
A-BR22-0605	-06	-05
A-BR22-0606	-06	-06
A-BR22-0608	-06	-08
A-BR22-0808	-08	-08
A-BR22-0810	-08	-10
A-BR22-0816	-08	-16
A-BR22-1010	-10	-10
A-BR22-1212	-12	-12
A-BR22-1216	-12	-16
A-BR22-1608	-16	-08
A-BR22-1616	-16	-16
A-BR22-2020	-20	-20
A-BR22-2024	-20	-24
A-BR22-2424	-24	-24
A-BR22-3224	-32	-24



BSP Female x BSP Male

Part Number	BSP F(T1)	BSP M(T2)
A-2BB55-0202	-02	-02
A-2BB55-0204	-02	-04
A-2BB55-0206	-02	-06
A-2BB55-0208	-02	-08
A-2BB55-0402	-04	-02
A-2BB55-0404	-04	-04
A-2BB55-0406	-04	-06
A-2BB55-0408	-04	-08
A-2BB55-0412	-04	-12
A-2BB55-0416	-04	-16
A-2BB55-0602	-06	-02
A-2BB55-0604	-06	-04
A-2BB55-0606	-06	-06
A-2BB55-0608	-06	-08
A-2BB55-0612	-06	-12
A-2BB55-0616	-06	-16
A-2BB55-0804	-08	-04
A-2BB55-0806	-08	-06
A-2BB55-0808	-08	-08
A-2BB55-0810	-08	-10
A-2BB55-0812	-08	-12
A-2BB55-0816	-08	-16
A-2BB55-0820	-08	-20
CONTINUED		

BSP Female x BSP Male

Part Number	BSP F(T1)	BSP M(T2)
A-2BB55-0824	-08	-24
A-2BB55-1012	-10	-12
A-2BB55-1206	-12	-06
A-2BB55-1208	-12	-08
A-2BB55-1212	-12	-12
A-2BB55-1216	-12	-16
A-2BB55-1220	-12	-20
A-2BB55-1224	-12	-24
A-2BB55-1608	-16	-08
A-2BB55-1612	-16	-12
A-2BB55-1616	-16	-16
A-2BB55-1620	-16	-20
A-2BB55-1624	-16	-24
A-2BB55-1632	-16	-32
A-2BB55-2012	-20	-12
A-2BB55-2016	-20	-16
A-2BB55-2020	-20	-20
A-2BB55-2024	-20	-24
A-2BB55-2032	-20	-32
A-2BB55-2416	-24	-16
A-2BB55-2424	-24	-24
A-2BB55-2432	-24	-32
A-2BB55-3232	-32	-32
A-2BB55-3240	-32	-40



BSPF Female x BSP Male Long

Part Number	BSPF F(T1)	BSP M(T2)
A-2BB56-0202	-02	-02
A-2BB56-0204	-02	-04
A-2BB56-0402	-04	-02
A-2BB56-0404	-04	-04
A-2BB56-0406	-04	-06
A-2BB56-0604	-06	-04
A-2BB56-0606	-06	-06
A-2BB56-0608	-06	-08
A-2BB56-0806	-08	-06
A-2BB56-0808	-08	-08
A-2BB56-0810	-08	-10
A-2BB56-0812	-08	-12
A-2BB56-1208	-12	-08
A-2BB56-1212	-12	-12
A-2BB56-1216	-12	-16
A-2BB56-1612	-16	-12
A-2BB56-1616	-16	-16
A-2BB56-2020	-20	-20
A-2BB56-2024	-20	-24
A-2BB56-2424	-24	-24
A-2BB56-3232	-32	-32

BSPF Female x JIC Male

Part Number	BSP F(T1)	JIC M(T2)
A-BJ55-0204	-02	-04
A-BJ55-0404	-04	-04
A-BJ55-0405	-04	-05
A-BJ55-0406	-04	-06
A-BJ55-0604	-06	-04
A-BJ55-0605	-06	-05
A-BJ55-0606	-06	-06
A-BJ55-0608	-06	-08
A-BJ55-0610	-06	-10
A-BJ55-0804	-08	-04
A-BJ55-0806	-08	-06
A-BJ55-0808	-08	-08
A-BJ55-0810	-08	-10
A-BJ55-0812	-08	-12
A-BJ55-1008	-10	-08
A-BJ55-1010	-10	-10
A-BJ55-1208	-12	-08
A-BJ55-1210	-12	-10
A-BJ55-1212	-12	-12
A-BJ55-1216	-12	-16
A-BJ55-1612	-16	-12
A-BJ55-1616	-16	-16
A-BJ55-1620	-16	-20
A-BJ55-2016	-20	-16
A-BJ55-2020	-20	-20
A-BJ55-2424	-24	-24
A-BJ55-3224	-32	-24
A-BJ55-3232	-32	-32



BSPP Female x JIC Male

Part Number	BSPP F(T1)	JIC M(T2)
A-2BJ55-0204	-02	-04
A-2BJ55-0206	-02	-06
A-2BJ55-0208	-02	-08
A-2BJ55-0404	-04	-04
A-2BJ55-0406	-04	-06
A-2BJ55-0606	-06	-06
A-2BJ55-0608	-06	-08
A-2BJ55-0808	-08	-08
A-2BJ55-1212	-12	-12
A-2BJ55-1616	-16	-16
A-2BJ55-2020	-20	-20
A-2BJ55-2424	-24	-24

BSPP Female x DIN Male

Part Number	BSPP F(T1)	DIN M(T2)
A-2BM55-0206L	-02	06L
A-2BM55-0406S	-04	06S
A-2BM55-0408L	-04	08L
A-2BM55-0408S	-04	08S
A-2BM55-0410L	-04	10L
A-2BM55-0412L	-04	12L
A-2BM55-0610S	-06	10S
A-2BM55-0612L	-06	12L
A-2BM55-0612S	-06	12S
A-2BM55-0812L	-08	12L
A-2BM55-0814S	-08	14S
A-2BM55-0815L	-08	15L
A-2BM55-0816S	-08	16S
A-2BM55-0818L	-08	18L
A-2BM55-1220S	-12	20S
A-2BM55-1222L	-12	22L
A-2BM55-1625S	-16	25S
A-2BM55-1628L	-16	28L
A-2BM55-2030S	-20	30S
A-2BM55-2035L	-20	35L
A-2BM55-2438S	-24	38S
A-2BM55-2442L	-24	42L



BSP Female x NPT Male

Part Number	BSP F(T1)	NPT M(T2)
A-BP55-0202	-02	-02
A-BP55-0404	-04	-04
A-BP55-0406	-04	-06
A-BP55-0606	-06	-06
A-BP55-0608	-06	-08
A-BP55-0616	-06	-16
A-BP55-0806	-08	-06
A-BP55-0808	-08	-08
A-BP55-0812	-08	-12
A-BP55-0816	-08	-16
A-BP55-0820	-08	-20
A-BP55-1212	-12	-12
A-BP55-1216	-12	-16
A-BP55-1616	-16	-16
A-BP55-1632	-16	-32
A-BP55-2024	-20	-24
A-BP55-2032	-20	-32
A-BP55-3248	-32	-48

BSPP Female x NPT Male

Part Number	BSPP F(T1)	NPT M(T2)
A-2BP55-0202	-02	-02
A-2BP55-0204	-02	-04
A-2BP55-0402	-04	-02
A-2BP55-0404	-04	-04
A-2BP55-0406	-04	-06
A-2BP55-0408	-04	-08
A-2BP55-0412	-04	-12
A-2BP55-0604	-06	-04
A-2BP55-0606	-06	-06
A-2BP55-0608	-06	-08
A-2BP55-0612	-06	-12
A-2BP55-0616	-06	-16
A-2BP55-0804	-08	-04
A-2BP55-0808	-08	-08
A-2BP55-0812	-08	-12
A-2BP55-0816	-08	-16
A-2BP55-0820	-08	-20
A-2BP55-1204	-12	-04
A-2BP55-1206	-12	-06
A-2BP55-1208	-12	-08
A-2BP55-1212	-12	-12
A-2BP55-1216	-12	-16
A-2BP55-1606	-16	-06
A-2BP55-1608	-16	-08
A-2BP55-1612	-16	-12
A-2BP55-1616	-16	-16
A-2BP55-1620	-16	-20
A-2BP55-1624	-16	-24
A-2BP55-1632	-16	-32
A-2BP55-2008	-20	-08
A-2BP55-2020	-20	-20
A-2BP55-2024	-20	-24
A-2BP55-2032	-20	-32
A-2BP55-2420	-24	-20
A-2BP55-2424	-24	-24
A-2BP55-3216	-32	-16
A-2BP55-3220	-32	-20
A-2BP55-3232	-32	-32
A-2BP55-3248	-32	-48
A-2BP55-4040	-40	-40
A-2BP55-4832	-48	-32
A-2BP55-4848	-48	-48



BSPP Female x NPT Male

Part Number	BSPP F(T1)	NPT M(T2)
A-2BP55-0202	-02	-02
A-2BP55-0204	-02	-04
A-2BP55-0402	-04	-02
A-2BP55-0404	-04	-04
A-2BP55-0406	-04	-06
A-2BP55-0408	-04	-08
A-2BP55-0412	-04	-12
A-2BP55-0604	-06	-04
A-2BP55-0606	-06	-06
A-2BP55-0608	-06	-08
A-2BP55-0612	-06	-12
A-2BP55-0616	-06	-16
A-2BP55-0804	-08	-04
A-2BP55-0808	-08	-08
A-2BP55-0812	-08	-12
A-2BP55-0816	-08	-16
A-2BP55-0820	-08	-20
A-2BP55-1204	-12	-04
A-2BP55-1206	-12	-06
A-2BP55-1208	-12	-08
A-2BP55-1212	-12	-12
CONTINUED		

BSPP Female x NPT Male

Part Number	BSPP F(T1)	NPT M(T2)
A-2BP55-1216	-12	-16
A-2BP55-1606	-16	-06
A-2BP55-1608	-16	-08
A-2BP55-1612	-16	-12
A-2BP55-1616	-16	-16
A-2BP55-1620	-16	-20
A-2BP55-1624	-16	-24
A-2BP55-1632	-16	-32
A-2BP55-2008	-20	-08
A-2BP55-2020	-20	-20
A-2BP55-2024	-20	-24
A-2BP55-2032	-20	-32
A-2BP55-2420	-24	-20
A-2BP55-2424	-24	-24
A-2BP55-3216	-32	-16
A-2BP55-3220	-32	-20
A-2BP55-3232	-32	-32
A-2BP55-3248	-32	-48
A-2BP55-4040	-40	-40
A-2BP55-4832	-48	-32
A-2BP55-4848	-48	-48



BSP Female x BSP Female

Part Number	BSP F(T1)	BSP F(T2)
A-B67-0202	-02	-02
A-B67-0402	-04	-02
A-B67-0404	-04	-04
A-B67-0406	-04	-06
A-B67-0408	-04	-08
A-B67-0604	-06	-04
A-B67-0606	-06	-06
A-B67-0608	-06	-08
A-B67-0804	-08	-04
A-B67-0806	-08	-06
A-B67-0808	-08	-08
A-B67-0810	-08	-10
A-B67-0812	-08	-12
A-B67-1008	-10	-08
A-B67-1010	-10	-10
A-B67-1012	-10	-12
A-B67-1208	-12	-08
A-B67-1210	-12	-10
A-B67-1212	-12	-12
A-B67-1216	-12	-16
A-B67-1608	-16	-08
A-B67-1610	-16	-10
A-B67-1612	-16	-12
A-B67-1616	-16	-16
A-B67-2012	-20	-12
A-B67-2020	-20	-20
A-B67-2424	-24	-24
A-B67-3224	-32	-24
A-B67-3232	-32	-32

BSPP Female x BSPP Female

Part Number	BSPP F(T1)	BSPP F(T2)
A-2B67-0202	-02	-02
A-2B67-0402	-04	-02
A-2B67-0404	-04	-04
A-2B67-0602	-06	-02
A-2B67-0604	-06	-04
A-2B67-0606	-06	-06
A-2B67-0804	-08	-04
A-2B67-0806	-08	-06
A-2B67-0808	-08	-08
A-2B67-1008	-10	-08
A-2B67-1010	-10	-10
A-2B67-1208	-12	-08
A-2B67-1212	-12	-12
A-2B67-1612	-16	-12
A-2B67-1616	-16	-16
A-2B67-2020	-20	-20
A-2B67-2424	-24	-24
A-2B67-3232	-32	-32
A-2B67-4040	-40	-40
A-2B67-4848	-48	-48



BSP Female x JIC Female		
Part Number	BSP F(T1)	JIC F(T2)
A-BJ67-0404	-04	-04
A-BJ67-0405	-04	-05
A-BJ67-0406	-04	-06
A-BJ67-0604	-06	-04
A-BJ67-0605	-06	-05
A-BJ67-0606	-06	-06
A-BJ67-0608	-06	-08
A-BJ67-0806	-08	-06
A-BJ67-0808	-08	-08
A-BJ67-0810	-08	-10
A-BJ67-0812	-08	-12
A-BJ67-1010	-10	-10
A-BJ67-1208	-12	-08
A-BJ67-1212	-12	-12
A-BJ67-1216	-12	-16
A-BJ67-1612	-16	-12
A-BJ67-1616	-16	-16
A-BJ67-2020	-20	-20



BSPP Female x JIC Female		
Part Number	BSPP F(T1)	JIC F(T2)
A-2BJ67-0806	-08	-06
A-2BJ67-0808	-08	-08
A-2BJ67-1010	-10	-10
A-2BJ67-1208	-12	-08
A-2BJ67-1212	-12	-12
A-2BJ67-1216	-12	-16



BSPP Female x NPT Female		
Part Number	BSPP F(T1)	NPT F(T2)
A-2BP67-0202	-02	-02
A-2BP67-0404	-04	-04
A-2BP67-0406	-04	-06
A-2BP67-0604	-06	-04
A-2BP67-0606	-06	-06
A-2BP67-0608	-06	-08
A-2BP67-0804	-08	-04
A-2BP67-0808	-08	-08
A-2BP67-1212	-12	-12
A-2BP67-1616	-16	-16
A-2BP67-2016	-20	-16
A-2BP67-2020	-20	-20
A-2BP67-2424	-24	-24
A-2BP67-3232	-32	-32
A-2BP67-4040	-40	-40
A-2BP67-4840	-48	-40
A-2BP67-4848	-48	-48



BSPP O-Ring Male x BSP Male 45°		
Part Number	BSPP M(T1)	BSP M(T2)
A-5BB29-0404	-04	-04
A-5BB29-0406	-04	-06
A-5BB29-0606	-06	-06
A-5BB29-0608	-06	-08
A-5BB29-0808	-08	-08
A-5BB29-1212	-12	-12
A-5BB29-1616	-16	-16



BSPP O-Ring Male x ORFS Male 45°

Part Number	BSPP M(T1)	ORFS M(T2)
A-5BF29-0204	-02	-04
A-5BF29-0404	-04	-04
A-5BF29-0406	-04	-06
A-5BF29-0606	-06	-06
A-5BF29-0608	-06	-08
A-5BF29-0808	-08	-08
A-5BF29-0810	-08	-10
A-5BF29-1210	-12	-10
A-5BF29-1212	-12	-12
A-5BF29-1616	-16	-16

BSPP O-Ring Male x JIC Male 45°

Part Number	BSPP M(T1)	JIC M(T2)
A-5BJ29-0204	-02	-04
A-5BJ29-0404	-04	-04
A-5BJ29-0405	-04	-05
A-5BJ29-0406	-04	-06
A-5BJ29-0408	-04	-08
A-5BJ29-0604	-06	-04
A-5BJ29-0605	-06	-05
A-5BJ29-0606	-06	-06
A-5BJ29-0608	-06	-08
A-5BJ29-0610	-06	-10
A-5BJ29-0806	-08	-06
A-5BJ29-0808	-08	-08
A-5BJ29-0810	-08	-10
A-5BJ29-0812	-08	-12
A-5BJ29-1012	-10	-12
A-5BJ29-1208	-12	-08
A-5BJ29-1210	-12	-10
A-5BJ29-1212	-12	-12
A-5BJ29-1216	-12	-16
A-5BJ29-1612	-16	-12
A-5BJ29-1616	-16	-16
A-5BJ29-1620	-16	-20
A-5BJ29-2016	-20	-16
A-5BJ29-2020	-20	-20
A-5BJ29-2424	-24	-24

BSP

ADAPTERS

ADAPTERS

BSP



BSP Male x BSP Female 45°

Part Number	BSP M(T1)	BSP F(T2)
A-B23-0202	-02	-02
A-B23-0404	-04	-04
A-B23-0606	-06	-06
A-B23-0808	-08	-08
A-B23-1010	-10	-10
A-B23-1212	-12	-12
A-B23-1616	-16	-16
A-B23-2020	-20	-20
A-B23-2424	-24	-24
A-B23-3232	-32	-32



BSP Female x JIC Male 45°

Part Number	BSP F(T1)	JIC M(T2)
A-BJ59-0404	-04	-04
A-BJ59-0606	-06	-06
A-BJ59-0808	-08	-08
A-BJ59-1010	-10	-10
A-BJ59-1212	-12	-12
A-BJ59-1616	-16	-16



BSP Female x BSP Female 45° Tube

Part Number	BSP F(T1)	BSP F(T2)
A-B68-0404-T	-04	-04
A-B68-0606-T	-06	-06
A-B68-0808-T	-08	-08
A-B68-1010-T	-10	-10
A-B68-1212-T	-12	-12
A-B68-1616-T	-16	-16
A-B68-2020-T	-20	-20



BSPP Female x BSPP Female 45°

Part Number	BSPP F(T1)	BSPP F(T2)
A-2B68-0404	-04	-04
A-2B68-0808	-08	-08
A-2B68-1010	-10	-10
A-2B68-1212	-12	-12
A-2B68-1616	-16	-16



BSP Male x BSP Male 90°

Part Number	BSP M(T1)	BSP M(T2)
A-B18-0202	-02	-02
A-B18-0404	-04	-04
A-B18-0604	-06	-04
A-B18-0606	-06	-06
A-B18-0608	-06	-08
A-B18-0806	-08	-06
A-B18-0808	-08	-08
A-B18-1010	-10	-10
A-B18-1208	-12	-08
A-B18-1210	-12	-10
A-B18-1212	-12	-12
A-B18-1216	-12	-16
A-B18-1612	-16	-12
A-B18-1616	-16	-16
A-B18-2020	-20	-20
A-B18-2424	-24	-24
A-B18-3232	-32	-32

BSPP O-Ring Male x BSP Male 90°

Part Number	BSPP M(T1)	BSP M(T2)
A-5BB33-0404	-04	-04
A-5BB33-0406	-04	-06
A-5BB33-0604	-06	-04
A-5BB33-0606	-06	-06
A-5BB33-0608	-06	-08
A-5BB33-0806	-08	-06
A-5BB33-0808	-08	-08
A-5BB33-0812	-08	-12
A-5BB33-1208	-12	-08
A-5BB33-1212	-12	-12
A-5BB33-1616	-16	-16
A-5BB33-2020	-20	-20



BSP O-Ring Male x ORFS Male 90°

Part Number	BSP M(T1)	ORFS M(T2)
A-5BF33-0204	-02	-04
A-5BF33-0404	-04	-04
A-5BF33-0406	-04	-06
A-5BF33-0408	-04	-08
A-5BF33-0604	-06	-04
A-5BF33-0606	-06	-06
A-5BF33-0608	-06	-08
A-5BF33-0610	-06	-10
A-5BF33-0806	-08	-06
A-5BF33-0808	-08	-08
A-5BF33-0810	-08	-10
A-5BF33-0812	-08	-12
A-5BF33-1010	-10	-10
A-5BF33-1210	-12	-10
A-5BF33-1212	-12	-12
A-5BF33-1216	-12	-16
A-5BF33-1612	-16	-12
A-5BF33-1616	-16	-16
A-5BF33-2016	-20	-16
A-5BF33-2020	-20	-20
A-5BF33-2424	-24	-24

BSP O-Ring Male x JIC Male 90°

Part Number	BSP M(T1)	JIC M(T2)
A-5BJ33-0204	-02	-04
A-5BJ33-0205	-02	-05
A-5BJ33-0404	-04	-04
A-5BJ33-0405	-04	-05
A-5BJ33-0406	-04	-06
A-5BJ33-0408	-04	-08
A-5BJ33-0604	-06	-04
A-5BJ33-0605	-06	-05
A-5BJ33-0606	-06	-06
A-5BJ33-0608	-06	-08
A-5BJ33-0610	-06	-10
A-5BJ33-0806	-08	-06
A-5BJ33-0808	-08	-08
A-5BJ33-0810	-08	-10
A-5BJ33-0812	-08	-12
A-5BJ33-1010	-10	-10
A-5BJ33-1208	-12	-08
A-5BJ33-1210	-12	-10
A-5BJ33-1212	-12	-12
A-5BJ33-1216	-12	-16
A-5BJ33-1612	-16	-12
A-5BJ33-1616	-16	-16
A-5BJ33-1620	-16	-20
A-5BJ33-2016	-20	-16
A-5BJ33-2020	-20	-20
A-5BJ33-2024	-20	-24
A-5BJ33-2424	-24	-24



BSP O-Ring Male x DIN Male 90°

Part Number	BSP M(T1)	DIN M(T2)
A-5BM33-0206L	-02	06L
A-5BM33-0406S	-04	06S
A-5BM33-0408L	-04	08L
A-5BM33-0408S	-04	08S
A-5BM33-0410L	-04	10L
A-5BM33-0610S	-06	10S
A-5BM33-0612L	-06	12L
A-5BM33-0612S	-06	12S
A-5BM33-0614S	-06	14S
A-5BM33-0615L	-06	15L
A-5BM33-0810L	-08	10L
A-5BM33-0814S	-08	14S
A-5BM33-0815L	-08	15L
A-5BM33-0816S	-08	16S
A-5BM33-0818L	-08	18L
A-5BM33-1220S	-12	20S
A-5BM33-1222L	-12	22L
A-5BM33-1625S	-16	25S
A-5BM33-1628L	-16	28L
A-5BM33-2030S	-20	30S
A-5BM33-2035L	-20	35L
A-5BM33-2438S	-24	38S
A-5BM33-2442L	-24	42L

BSP Elastomer Male x DIN Male Banjo

Part Number	BSP M(T1)	DIN M(T2)
A-6BM91-0206L	-02	06L
A-6BM91-0406L	-04	06L
A-6BM91-0406S	-04	06S
A-6BM91-0408L	-04	08L
A-6BM91-0408S	-04	08S
A-6BM91-0410L	-04	10L
A-6BM91-0610S	-06	10S
A-6BM91-0612L	-06	12L
A-6BM91-0612S	-06	12S
A-6BM91-0814S	-08	14S
A-6BM91-0815L	-08	15L
A-6BM91-0816S	-08	16S
A-6BM91-0818L	-08	18L
A-6BM91-1220S	-12	20S
A-6BM91-1222L	-12	22L
A-6BM91-1625S	-16	25S
A-6BM91-1628L	-16	28L
A-6BM91-2030S	-20	30S
A-6BM91-2035L	-20	35L
A-6BM91-2438S	-24	38S
A-6BM91-2442L	-24	42L



BSP Male x NPT Male 90°		
Part Number	BSP M(T1)	NPT M(T2)
A-BP18-0202	-02	-02
A-BP18-0404	-04	-04
A-BP18-0606	-06	-06
A-BP18-0808	-08	-08
A-BP18-1212	-12	-12
A-BP18-1616	-16	-16



BSP Male x ORB Male 90°		
Part Number	BSP M(T1)	ORB M(T2)
A-BR19-0204	-02	-04
A-BR19-0406	-04	-06
A-BR19-0606	-06	-06
A-BR19-0608	-06	-08
A-BR19-0808	-08	-08
A-BR19-0810	-08	-10
A-BR19-1212	-12	-12
A-BR19-1616	-16	-16



BSP Male x BSP Female 90°		
Part Number	BSP M(T1)	BSP F(T2)
A-B24-0202	-02	-02
A-B24-0404	-04	-04
A-B24-0406	-04	-06
A-B24-0604	-06	-04
A-B24-0606	-06	-06
A-B24-0608	-06	-08
A-B24-0806	-08	-06
A-B24-0808	-08	-08
A-B24-1010	-10	-10
A-B24-1212	-12	-12
A-B24-1612	-16	-12
A-B24-1616	-16	-16
A-B24-2020	-20	-20
A-B24-2424	-24	-24
A-B24-3232	-32	-32



BSP Male x BSP Female 90° Tube		
Part Number	BSP M(T1)	BSP F(T2)
A-B24-0404-T	-04	-04
A-B24-0606-T	-06	-06
A-B24-0808-T	-08	-08
A-B24-1010-T	-10	-10
A-B24-1212-T	-12	-12
A-B24-1616-T	-16	-16
A-B24-2020-T	-20	-20
A-B24-2424-T	-24	-24
A-B24-3232-T	-32	-32

BSP

ADAPTERS



BSPP Male O-Ring x BSP Female 90°

Part Number	BSPP M(T1)	(T2)
A-5BB39-0404	-04	-04
A-5BB39-0606	-06	-06
A-5BB39-0808	-08	-08
A-5BB39-1212	-12	-12
A-5BB39-1616	-16	-16



BSP Male x JIC Female 90°

Part Number	BSP M(T1)	JIC F(T2)
A-BJ24-0202	-02	-02
A-BJ24-0404	-04	-04
A-BJ24-0406	-04	-06
A-BJ24-0606	-06	-06
A-BJ24-0608	-06	-08
A-BJ24-0806	-08	-06
A-BJ24-0808	-08	-08
A-BJ24-0810	-08	-10
A-BJ24-1010	-10	-10
A-BJ24-1212	-12	-12
A-BJ24-1616	-16	-16
A-BJ24-2020	-20	-20



BSP Female x JIC Male 90°

Part Number	BSP F(T1)	JIC M(T2)
A-BJ63-0404	-04	-04
A-BJ63-0606	-06	-06
A-BJ63-0808	-08	-08
A-BJ63-1010	-10	-10
A-BJ63-1212	-12	-12
A-BJ63-1616	-16	-16



BSPP O-Ring Male x NPT Female 90°

Part Number	BSPP M(T1)	NPT F(T2)
A-5BP39-0202	-02	-02
A-5BP39-0402	-04	-02
A-5BP39-0404	-04	-04
A-5BP39-0604	-06	-04
A-5BP39-0606	-06	-06
A-5BP39-0806	-08	-06
A-5BP39-0808	-08	-08
A-5BP39-1212	-12	-12
A-5BP39-1616	-16	-16
A-5BP39-2020	-20	-20
A-5BP39-2424	-24	-24

ADAPTERS

BSP

BSP

ADAPTERS



BSP Female x NPT Male 90°		
Part Number	BSP F(T1)	NPT M(T2)
A-BP63-0202	-02	-02
A-BP63-0404	-04	-04
A-BP63-0606	-06	-06
A-BP63-0808	-08	-08
A-BP63-1212	-12	-12
A-BP63-1616	-16	-16
A-BP63-2020	-20	-20
A-BP63-2424	-24	-24



BSP Female x BSP Female 90°		
Part Number	BSP F(T1)	BSP F(T2)
A-B69-0202	-02	-02
A-B69-0404	-04	-04
A-B69-0606	-06	-06
A-B69-0808	-08	-08
A-B69-1010	-10	-10
A-B69-1212	-12	-12
A-B69-1616	-16	-16
A-B69-2020	-20	-20
A-B69-2424	-24	-24
A-B69-3232	-32	-32



BSPP Female x BSPP Female 90°		
Part Number	BSPP F(T1)	BSPP F(T2)
A-2B69-0202	-02	-02
A-2B69-0404	-04	-04
A-2B69-0606	-06	-06
A-2B69-0808	-08	-08
A-2B69-1010	-10	-10
A-2B69-1212	-12	-12
A-2B69-1616	-16	-16
A-2B69-2020	-20	-20
A-2B69-2424	-24	-24



BSP Bulkhead x BSP Male		
Part Number	BSP M(T1)	BSP M(T2)
A-B40LN-0202	-02	-02
A-B40LN-0404	-04	-04
A-B40LN-0406	-04	-06
A-B40LN-0604	-06	-04
A-B40LN-0606	-06	-06
A-B40LN-0608	-06	-08
A-B40LN-0806	-08	-06
A-B40LN-0808	-08	-08
A-B40LN-0812	-08	-12
A-B40LN-1010	-10	-10
A-B40LN-1208	-12	-08
A-B40LN-1212	-12	-12
A-B40LN-1216	-12	-16
A-B40LN-1612	-16	-12
A-B40LN-1616	-16	-16
A-B40LN-2020	-20	-20
A-B40LN-2424	-24	-24
A-B40LN-3232	-32	-32

ADAPTERS

BSP

BSP

ADAPTERS

ADAPTERS

BSP



BSP Bulkhead Nut

Part Number	BSP
A-B4-02	-02
A-B4-04	-04
A-B4-06	-06
A-B4-08	-08
A-B4-10	-10
A-B4-12	-12
A-B4-16	-16
A-B4-20	-20
A-B4-24	-24
A-B4-32	-32



BSP Male Branch Tee

Part Number	BSP M(T1)	BSP M(T2)
A-B5-18-0202	-02	-02
A-B5-18-0404	-04	-04
A-B5-18-0606	-06	-06
A-B5-18-0808	-08	-08
A-B5-18-1010	-10	-10
A-B5-18-1212	-12	-12
A-B5-18-1616	-16	-16
A-B5-18-2020	-20	-20
A-B5-18-2424	-24	-24
A-B5-18-3232	-32	-32



BSPP O-Ring Male x BSP Male Branch Tee

Part Number	BSPP M(T1)	BSP M(T2)
A-5BB5-33-0404	-04	-04
A-5BB5-33-0406	-04	-06
A-5BB5-33-0606	-06	-06
A-5BB5-33-0608	-06	-08
A-5BB5-33-0808	-08	-08
A-5BB5-33-1212	-12	-12



BSP Female x BSP Male Branch Tee

Part Number	BSP F(T1)	BSP M(T2)
A-B5-63-0202	-02	-02
A-B5-63-0404	-04	-04
A-B5-63-0606	-06	-06
A-B5-63-0808	-08	-08
A-B5-63-1010	-10	-10
A-B5-63-1212	-12	-12
A-B5-63-1616	-16	-16
A-B5-63-2020	-20	-20
A-B5-63-2424	-24	-24
A-B5-63-3232	-32	-32



BSP Female Branch Tee		
Part Number	BSP F(T1)	BSP F(T2)
A-B5-69-0202	-02	-02
A-B5-69-0404	-04	-04
A-B5-69-0606	-06	-06
A-B5-69-0808	-08	-08
A-B5-69-1010	-10	-10
A-B5-69-1212	-12	-12
A-B5-69-1616	-16	-16
A-B5-69-2020	-20	-20
A-B5-69-2424	-24	-24
A-B5-69-3232	-32	-32



BSPP Female Branch Tee		
Part Number	BSPP F(T1)	BSPP F(T2)
A-2B5-69-0202	-02	-02
A-2B5-69-0404	-04	-04
A-2B5-69-0606	-06	-06
A-2B5-69-0808	-08	-08
A-2B5-69-1212	-12	-12
A-2B5-69-1616	-16	-16
A-2B5-69-2020	-20	-20



BSPP O-Ring Male x ORFS Male Branch Tee		
Part Number	BSPP M(T1)	ORFS M(T2)
A-5BF5-33-0204	-02	-04
A-5BF5-33-0404	-04	-04
A-5BF5-33-0406	-04	-06
A-5BF5-33-0606	-06	-06
A-5BF5-33-0608	-06	-08
A-5BF5-33-0808	-08	-08
A-5BF5-33-0810	-08	-10



BSPP O-Ring Male x JIC Male Branch Tee		
Part Number	BSPP M(T1)	JIC M(T2)
A-5BJ5-33-0204	-02	-04
A-5BJ5-33-0404	-04	-04
A-5BJ5-33-0405	-04	-05
A-5BJ5-33-0406	-04	-06
A-5BJ5-33-0606	-06	-06
A-5BJ5-33-0608	-06	-08
A-5BJ5-33-0808	-08	-08
A-5BJ5-33-0810	-08	-10
A-5BJ5-33-1212	-12	-12
A-5BJ5-33-1616	-16	-16
A-5BJ5-33-2020	-20	-20
A-5BJ5-33-2424	-24	-24



BSP O-Ring Male x BSP Male Run Tee

Part Number	BSP M(T1)	BSP M(T2)
A-5BB6-33-0404	-04	-04
A-5BB6-33-0406	-04	-06
A-5BB6-33-0606	-06	-06
A-5BB6-33-0608	-06	-08
A-5BB6-33-0808	-08	-08
A-5BB6-33-1212	-12	-12



BSP Male x BSP Female Run Tee

Part Number	BSP M(T1)	BSP F
A-B6-24-0202	-02	-02
A-B6-24-0404	-04	-04
A-B6-24-0606	-06	-06
A-B6-24-0808	-08	-08
A-B6-24-1010	-10	-10
A-B6-24-1212	-12	-12
A-B6-24-1616	-16	-16
A-B6-24-2020	-20	-20



BSP Female x BSP Male Run Tee

Part Number	BSP F(T1)	BSP M
A-B6-63-0202	-02	-02
A-B6-63-0404	-04	-04
A-B6-63-0606	-06	-06
A-B6-63-0808	-08	-08
A-B6-63-1010	-10	-10
A-B6-63-1212	-12	-12
A-B6-63-1616	-16	-16
A-B6-63-2020	-20	-20
A-B6-63-2424	-24	-24
A-B6-63-3232	-32	-32



BSP O-Ring Male x ORFS Male Run Tee

Part Number	BSP M(T1)	ORFS M
A-5BF6-33-0404	-04	-04
A-5BF6-33-0406	-04	-06
A-5BF6-33-0606	-06	-06
A-5BF6-33-0608	-06	-08
A-5BF6-33-0808	-08	-08
A-5BF6-33-0810	-08	-10
A-5BF6-33-1212	-12	-12
A-5BF6-33-1612	-16	-12
A-5BF6-33-1616	-16	-16



BSPP O-Ring Male x JIC Male Run Tee

Part Number	BSPP M(T1)	JIC M
A-5BJ6-33-0204	-02	-04
A-5BJ6-33-0404	-04	-04
A-5BJ6-33-0405	-04	-05
A-5BJ6-33-0406	-04	-06
A-5BJ6-33-0606	-06	-06
A-5BJ6-33-0608	-06	-08
A-5BJ6-33-0808	-08	-08
A-5BJ6-33-0810	-08	-10
A-5BJ6-33-1212	-12	-12
A-5BJ6-33-1616	-16	-16
A-5BJ6-33-2020	-20	-20
A-5BJ6-33-2424	-24	-24



BSPP Female Cross

Part Number	BSPP F(T1)	BSPP F
A-2B7-69-0202	-02	-02
A-2B7-69-0404	-04	-04
A-2B7-69-0606	-06	-06
A-2B7-69-0808	-08	-08
A-2B7-69-1616	-16	-16
A-2B7-69-2020	-20	-20



BSPP Female x DIN Male Gauge Adapter

Part Number	BSPP F(T1)	DIN M
A-2BM96-0406L	-04	06L
A-2BM96-0408L	-04	08L
A-2BM96-0410L	-04	10L
A-2BM96-0412L	-04	12L
A-2BM96-0806S	-08	06S
A-2BM96-0808S	-08	08S
A-2BM96-0810S	-08	10S
A-2BM96-0812S	-08	12S



BSP Banjo x JIC Male

Part Number	BSP(T1)	JIC M
A-BJ91-0204	-02	-04
A-BJ91-0404	-04	-04
A-BJ91-0405	-04	-05
A-BJ91-0406	-04	-06
A-BJ91-0606	-06	-06
A-BJ91-0808	-08	-08
A-BJ91-0810	-08	-10
A-BJ91-1210	-12	-10
A-BJ91-1212	-12	-12
A-BJ91-1612	-16	-12



BSPT Hex Plug

Part Number	BSPT M
A-4B1-02	-02
A-4B1-04	-04
A-4B1-06	-06
A-4B1-08	-08
A-4B1-10	-10
A-4B1-12	-12
A-4B1-16	-16
A-4B1-20	-20
A-4B1-24	-24
A-4B1-32	-32



BSPT Allen Plug

Part Number	BSPT M
A-4B2-02	-02
A-4B2-04	-04
A-4B2-06	-06
A-4B2-08	-08
A-4B2-12	-12
A-4B2-16	-16
A-4B2-20	-20
A-4B2-24	-24



BSPT Male x BSPT Male

Part Number	BSPT M(T1)	BSPT M(T2)
A-4B10-0202	-02	-02
A-4B10-0402	-04	-02
A-4B10-0404	-04	-04
A-4B10-0602	-06	-02
A-4B10-0604	-06	-04
A-4B10-0606	-06	-06
A-4B10-0804	-08	-04
A-4B10-0806	-08	-06
A-4B10-0808	-08	-08
A-4B10-1010	-10	-10
A-4B10-1206	-12	-06
A-4B10-1208	-12	-08
A-4B10-1212	-12	-12
A-4B10-1612	-16	-12
A-4B10-1616	-16	-16
A-4B10-2016	-20	-16
A-4B10-2020	-20	-20
A-4B10-2424	-24	-24
A-4B10-3232	-32	-32
A-4B10-4040	-40	-40
A-4B10-4848	-48	-48



BSPT Male x BSP Male

Part Number	BSPT M(T1)	BSP M(T2)
A-4BB10-0202	-02	-02
A-4BB10-0204	-02	-04
A-4BB10-0206	-02	-06
A-4BB10-0402	-04	-02
A-4BB10-0404	-04	-04
A-4BB10-0406	-04	-06
A-4BB10-0408	-04	-08
A-4BB10-0412	-04	-12
A-4BB10-0602	-06	-02
A-4BB10-0604	-06	-04
A-4BB10-0606	-06	-06
A-4BB10-0608	-06	-08
A-4BB10-0610	-06	-10
A-4BB10-0612	-06	-12
A-4BB10-0804	-08	-04
A-4BB10-0806	-08	-06
A-4BB10-0808	-08	-08
A-4BB10-0810	-08	-10
A-4BB10-0812	-08	-12
A-4BB10-0816	-08	-16
A-4BB10-1008	-10	-08
A-4BB10-1010	-10	-10
A-4BB10-1206	-12	-06
A-4BB10-1208	-12	-08
A-4BB10-1210	-12	-10
A-4BB10-1212	-12	-12
A-4BB10-1216	-12	-16
A-4BB10-1220	-12	-20
A-4BB10-1606	-16	-06
A-4BB10-1612	-16	-12
A-4BB10-1616	-16	-16
A-4BB10-1620	-16	-20
A-4BB10-1624	-16	-24
A-4BB10-2012	-20	-12
A-4BB10-2016	-20	-16
A-4BB10-2020	-20	-20
A-4BB10-2024	-20	-24
A-4BB10-2416	-24	-16
A-4BB10-2420	-24	-20
A-4BB10-2424	-24	-24
A-4BB10-2432	-24	-32
A-4BB10-3216	-32	-16
A-4BB10-3220	-32	-20
A-4BB10-3224	-32	-24
A-4BB10-3232	-32	-32
A-4BB10-4040	-40	-40
A-4BB10-4848	-48	-48

BSPT Male x JIC Male

Part Number	BSPT M(T1)	JIC M(T2)
A-4BJ10-0204	-02	-04
A-4BJ10-0205	-02	-05
A-4BJ10-0206	-02	-06
A-4BJ10-0404	-04	-04
A-4BJ10-0405	-04	-05
A-4BJ10-0406	-04	-06
A-4BJ10-0408	-04	-08
A-4BJ10-0604	-06	-04
A-4BJ10-0605	-06	-05
A-4BJ10-0606	-06	-06
A-4BJ10-0608	-06	-08
A-4BJ10-0610	-06	-10
A-4BJ10-0806	-08	-06
A-4BJ10-0808	-08	-08
A-4BJ10-0810	-08	-10
A-4BJ10-0812	-08	-12
A-4BJ10-1208	-12	-08
A-4BJ10-1210	-12	-10
A-4BJ10-1212	-12	-12
A-4BJ10-1214	-12	-14
A-4BJ10-1216	-12	-16
A-4BJ10-1608	-16	-08
A-4BJ10-1612	-16	-12
A-4BJ10-1616	-16	-16
A-4BJ10-1620	-16	-20
A-4BJ10-2016	-20	-16
A-4BJ10-2020	-20	-20
A-4BJ10-2420	-24	-20
A-4BJ10-2424	-24	-24
A-4BJ10-3224	-32	-24
A-4BJ10-3232	-32	-32



BSPT Male x Komatsu Male

Part Number	BSPT M(T1)	Komatsu M(T2)
A-4BM10-0204LL	-02	04LL
A-4BM10-0206L	-02	06L
A-4BM10-0206LL	-02	06LL
A-4BM10-0208L	-02	08L
A-4BM10-0208LL	-02	08LL
A-4BM10-0406L	-04	06L
A-4BM10-0408L	-04	08L
A-4BM10-0408LL	-04	08LL
A-4BM10-0410L	-04	10L
A-4BM10-0410LL	-04	10LL
A-4BM10-0412L	-04	12L
A-4BM10-0608L	-06	08L
A-4BM10-0610L	-06	10L
A-4BM10-0612L	-06	12L
A-4BM10-0612LL	-06	12LL
A-4BM10-0812L	-08	12L
A-4BM10-0815L	-08	15L



BSPT Male x NPT Male

Part Number	BSPT M(T1)	NPT M(T2)
A-4BP10-0202	-02	-02
A-4BP10-0204	-02	-04
A-4BP10-0402	-04	-02
A-4BP10-0404	-04	-04
A-4BP10-0406	-04	-06
A-4BP10-0604	-06	-04
A-4BP10-0606	-06	-06
A-4BP10-0808	-08	-08
A-4BP10-1212	-12	-12
A-4BP10-1216	-12	-16
A-4BP10-1616	-16	-16
A-4BP10-2020	-20	-20
A-4BP10-2424	-24	-24
A-4BP10-3232	-32	-32
A-4BP10-4040	-40	-40
A-4BP10-4848	-48	-48



BSPT Male x BSPT Female

Part Number	BSPT M(T1)	BSPT F(T2)
A-4B22-0402	-04	-02
A-4B22-0602	-06	-02
A-4B22-0604	-06	-04
A-4B22-0804	-08	-04
A-4B22-0806	-08	-06
A-4B22-1206	-12	-06
A-4B22-1208	-12	-08
A-4B22-1608	-16	-08
A-4B22-1612	-16	-12
A-4B22-3224	-32	-24



BSPT Male x BSPP Female

Part Number	BSPT M(T1)	BSPP F(T2)
A-4B2B22-0204	-02	-04
A-4B2B22-0402	-04	-02
A-4B2B22-0404	-04	-04
A-4B2B22-0406	-04	-06
A-4B2B22-0602	-06	-02
A-4B2B22-0604	-06	-04
A-4B2B22-0606	-06	-06
A-4B2B22-0808	-08	-08
A-4B2B22-1204	-12	-04
A-4B2B22-1206	-12	-06
A-4B2B22-1208	-12	-08
A-4B2B22-1212	-12	-12
A-4B2B22-1608	-16	-08
A-4B2B22-1612	-16	-12
A-4B2B22-1616	-16	-16
A-4B2B22-2016	-20	-16
A-4B2B22-2020	-20	-20
A-4B2B22-2420	-24	-20

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

BSPT

ADAPTERS



BSPT Male x NPT Female

Part Number	BSPT M(T1)	NPT F(T2)
A-4BP22-0202	-02	-02
A-4BP22-0204	-02	-04
A-4BP22-0402	-04	-02
A-4BP22-0404	-04	-04
A-4BP22-0602	-06	-02
A-4BP22-0604	-06	-04
A-4BP22-0606	-06	-06
A-4BP22-0804	-08	-04
A-4BP22-0808	-08	-08
A-4BP22-1206	-12	-06
A-4BP22-1208	-12	-08
A-4BP22-1212	-12	-12
A-4BP22-1604	-16	-04
A-4BP22-1608	-16	-08
A-4BP22-1612	-16	-12
A-4BP22-1616	-16	-16
A-4BP22-2012	-20	-12
A-4BP22-2016	-20	-16
A-4BP22-2020	-20	-20
A-4BP22-2420	-24	-20
A-4BP22-2424	-24	-24
A-4BP22-3232	-32	-32
A-4BP22-4848	-48	-48

BSPT Male x JIC Male 45°

Part Number	BSPT M(T1)	JIC M(T2)
A-4BJ14-0204	-02	-04
A-4BJ14-0206	-02	-06
A-4BJ14-0404	-04	-04
A-4BJ14-0406	-04	-06
A-4BJ14-0606	-06	-06
A-4BJ14-0608	-06	-08
A-4BJ14-0806	-08	-06
A-4BJ14-0808	-08	-08
A-4BJ14-0810	-08	-10
A-4BJ14-1212	-12	-12
A-4BJ14-1216	-12	-16
A-4BJ14-1616	-16	-16
A-4BJ14-2020	-20	-20

ADAPTERS

BSPT



BSPT Male x BSP Male 90°

Part Number	BSPT M(T1)	BSP M(T2)
A-4BB18-0202	-02	-02
A-4BB18-0204	-02	-04
A-4BB18-0402	-04	-02
A-4BB18-0404	-04	-04
A-4BB18-0406	-04	-06
A-4BB18-0604	-06	-04
A-4BB18-0606	-06	-06
A-4BB18-0608	-06	-08
A-4BB18-0808	-08	-08
A-4BB18-1212	-12	-12
A-4BB18-1616	-16	-16

BSPT Male x JIC Male 90°

Part Number	BSPT M(T1)	JIC M(T2)
A-4BJ18-0204	-02	-04
A-4BJ18-0205	-02	-05
A-4BJ18-0206	-02	-06
A-4BJ18-0404	-04	-04
A-4BJ18-0405	-04	-05
A-4BJ18-0406	-04	-06
A-4BJ18-0606	-06	-06
A-4BJ18-0608	-06	-08
A-4BJ18-0610	-06	-10
A-4BJ18-0806	-08	-06
A-4BJ18-0808	-08	-08
A-4BJ18-0810	-08	-10
A-4BJ18-0812	-08	-12
A-4BJ18-1210	-12	-10
A-4BJ18-1212	-12	-12
A-4BJ18-1216	-12	-16
A-4BJ18-1612	-16	-12
A-4BJ18-1616	-16	-16
A-4BJ18-1620	-16	-20
A-4BJ18-2016	-20	-16
A-4BJ18-2020	-20	-20
A-4BJ18-2424	-24	-24
A-4BJ18-3232	-32	-32



BSPT Male x DIN Male 90°		
Part Number	BSPT M(T1)	DIN M(T2)
A-4BM18-0204LL	-02	04LL
A-4BM18-0206L	-02	06L
A-4BM18-0206LL	-02	06LL
A-4BM18-0208L	-02	08L
A-4BM18-0208LL	-02	08LL
A-4BM18-0406L	-04	06L
A-4BM18-0406S	-04	06S
A-4BM18-0408L	-04	08L
A-4BM18-0408S	-04	08S
A-4BM18-0410L	-04	10L
A-4BM18-0410LL	-04	10LL
A-4BM18-0412L	-04	12L
A-4BM18-0412LL	-04	12LL
A-4BM18-0610L	-06	10L
A-4BM18-0610S	-06	10S

CONTINUED

BSPT Male x DIN Male 90°		
Part Number	BSPT M(T1)	DIN M(T2)
A-4BM18-0612L	-06	12L
A-4BM18-0612LL	-06	12LL
A-4BM18-0612S	-06	12S
A-4BM18-0814S	-08	14S
A-4BM18-0815L	-08	15L
A-4BM18-0816S	-08	16S
A-4BM18-0818L	-08	18L
A-4BM18-1220S	-12	20S
A-4BM18-1222L	-12	22L
A-4BM18-1625S	-16	25S
A-4BM18-1628L	-16	28L
A-4BM18-2030S	-20	30S
A-4BM18-2035L	-20	35L
A-4BM18-2438S	-24	38S
A-4BM18-2442L	-24	42L



BSPT Male x JIC Male Branch Tee		
Part Number	BSPT M(T1)	JIC M(T2)
A-4BJ5-18-0404	-04	-04
A-4BJ5-18-0406	-04	-06
A-4BJ5-18-0608	-06	-08
A-4BJ5-18-0810	-08	-10
A-4BJ5-18-1212	-12	-12

BSPT Male x JIC Male Run Tee		
Part Number	BSPT M(T1)	JIC M(T2)
A-4BJ6-18-0404	-04	-04
A-4BJ6-18-0406	-04	-06
A-4BJ6-18-0608	-06	-08
A-4BJ6-18-0810	-08	-10
A-4BJ6-18-1212	-12	-12

Ph. 780-413-0904
Fax 780-413-0905
Toll Free 1-800-239-0416



18141 - 111 Avenue
Edmonton, Alberta T5S 2P2
boschhydraulic.com

DIN/METRIC

ADAPTERS



DIN Plug

Part Number	DIN M
A-M1-06L	06L
A-M1-06S	06S
A-M1-08L	08L
A-M1-08S	08S
A-M1-10L	10L
A-M1-10S	10S
A-M1-12L	12L
A-M1-12S	12S
A-M1-14S	14S
A-M1-15L	15L
A-M1-16S	16S
A-M1-18L	18L
A-M1-20S	20S
A-M1-22L	22L
A-M1-25S	25S
A-M1-28L	28L
A-M1-30S	30S
A-M1-35L	35L
A-M1-38S	38S
A-M1-42L	42L

Metric Elastomer Allen Plug

Part Number	METRIC M
A-6M2-08	M08X1.0
A-6M2-10	M10X1.0
A-6M2-12	M12X1.5
A-6M2-14	M14X1.5
A-6M2-16	M16X1.5
A-6M2-18	M18X1.5
A-6M2-20	M20X1.5
A-6M2-22	M22X1.5
A-6M2-24	M24X1.5
A-6M2-26	M26X1.5
A-6M2-27	M27X2.0
A-6M2-30	M30X2.0
A-6M2-30X1.5	M30X1.5
A-6M2-33	M33X2.0
A-6M2-42	M42X2.0
A-6M2-48	M48X2.0

ADAPTERS

DIN/METRIC



Metric Plug, No O-Ring

Part Number	METRIC M
A-2M1-08X1.0	M08X1.0
A-2M1-10X1.0	M10X1.0
A-2M1-10X1.5	M10X1.5
A-2M1-12X1.0	M12X1.0
A-2M1-12X1.5	M12X1.5
A-2M1-14X1.5	M14X1.5
A-2M1-16X1.5	M16X1.5
A-2M1-18X1.5	M18X1.5
A-2M1-20X1.5	M20X1.5
A-2M1-22X1.5	M22X1.5
A-2M1-24X1.5	M24X1.5
A-2M1-26X1.5	M26X1.5
A-2M1-30X1.5	M30X1.5
A-2M1-30X2.0	M30X2.0
A-2M1-36X1.5	M36X1.5
A-2M1-36X2.0	M36X2.0
A-2M1-38X1.5	M38X1.5
A-2M1-42X1.5	M42X1.5
A-2M1-42X2.0	M42X2.0
A-2M1-45X1.5	M45X1.5
A-2M1-48X1.5	M48X1.5

DIN Cap

Part Number	DIN F
A-M3-06L	06L
A-M3-06S	06S
A-M3-08L	08L
A-M3-08S	08S
A-M3-10L	10L
A-M3-10S	10S
A-M3-12L	12L
A-M3-12S	12S
A-M3-14S	14S
A-M3-15L	15L
A-M3-16S	16S
A-M3-18L	18L
A-M3-20S	20S
A-M3-22L	22L
A-M3-25S	25S
A-M3-28L	28L
A-M3-30S	30S
A-M3-35L	35L
A-M3-38S	38S
A-M3-42L	42L



DIN Nut	
Part Number	Thread Size
A-M8-04LL	04LL
A-M8-05LL	05LL
A-M8-06LL	06LL
A-M8-08LL	08LL
A-M8-10LL	10LL
A-M8-12LL	12LL
A-M8-06L	06L
A-M8-06S	06S
A-M8-08L	08L
A-M8-08S	08S
A-M8-10L	10L
A-M8-10S	10S
A-M8-12L	12L
A-M8-12S	12S
A-M8-14S	14S
A-M8-15L	15L
A-M8-16S	16S
A-M8-18L	18L
A-M8-20S	20S
A-M8-22L	22L
A-M8-25S	25S
A-M8-28L	28L
A-M8-30S	30S
A-M8-35L	35L
A-M8-38S	38S
A-M8-42L	42L

DIN Cut Ring	
Part Number	Thread Size
A-M9-04LL	04LL
A-M9-05LL	05LL
A-M9-06LL	06LL
A-M9-08LL	08LL
A-M9-10LL	10LL
A-M9-12LL	12LL
A-M9-06LS	06L and 06S
A-M9-08LS	08L and 08S
A-M9-10LS	10L and 10S
A-M9-12LS	12L and 12S
A-M9-14S	14S
A-M9-15L	15L
A-M9-16S	16S
A-M9-18L	18L
A-M9-20S	20S
A-M9-22L	22L
A-M9-25S	25S
A-M9-28L	28L
A-M9-30S	30S
A-M9-35L	35L
A-M9-38S	38S
A-M9-42L	42L



Metric Bonded Seal	
Part Number	Thread Size
M102-04	04MM
M102-06	06MM
M102-08	08MM
M102-10	10MM
M102-12	12MM
M102-14	14MM
M102-16	16MM
M102-18	18MM
M102-20	20MM
M102-22	22MM
M102-24	24MM
M102-26	26MM
M102-27	27MM
M102-30	30MM
M102-33	33MM
M102-36	36MM
M102-42	42MM
M102-45	45MM
M102-48	48MM
M102-50	50MM
M102-52	52MM



Metric Copper Washer		
Part Number	ID	OD
AC-CW-0610	06MM	10MM
AC-CW-0812	08MM	12MM
AC-CW-1016	10MM	16MM
AC-CW-1218	12MM	18MM
AC-CW-1420	14MM	20MM
AC-CW-1622	16MM	22MM
AC-CW-1824	18MM	24MM
AC-CW-2026	20MM	26MM
AC-CW-2226	22MM	26MM
AC-CW-2228	22MM	28MM
AC-CW-2430	24MM	30MM
AC-CW-2632	26MM	32MM
AC-CW-3036	30MM	36MM
AC-CW-3844	38MM	44MM



DIN Male x DIN Male		
Part Number	DIN M(T1)	DIN M(T2)
A-M10-04LL04LL	04LL	04LL
A-M10-05LL05LL	05LL	05LL
A-M10-06LL04LL	06LL	04LL
A-M10-06LL06LL	06LL	06LL
A-M10-08LL04LL	08LL	04LL
A-M10-08LL06LL	08LL	06LL
A-M10-08LL08LL	08LL	08LL
A-M10-10LL10LL	10LL	10LL
A-M10-12LL12LL	12LL	12LL
A-M10-06L06L	06L	06L
A-M10-06S06S	06S	06S
A-M10-08L06L	08L	06L
A-M10-08L08L	08L	08L
A-M10-08S06S	08S	06S
A-M10-08S08S	08S	08S
A-M10-10L06L	10L	06L
A-M10-10L08L	10L	08L
A-M10-10L10L	10L	10L
A-M10-10S06S	10S	06S
A-M10-10S08S	10S	08S
A-M10-10S10S	10S	10S
A-M10-12L06L	12L	06L
A-M10-12L08L	12L	08L
A-M10-12L10L	12L	10L
A-M10-12L12L	12L	12L
A-M10-12S06S	12S	06S
A-M10-12S08S	12S	08S
A-M10-12S10S	12S	10S
A-M10-12S12S	12S	12S
A-M10-14S10S	14S	10S
A-M10-14S12S	14S	12S
A-M10-14S14S	14S	14S
CONTINUED		

DIN Male x DIN Male		
Part Number	DIN M(T1)	DIN M(T2)
A-M10-15L10L	15L	10L
A-M10-15L12L	15L	12L
A-M10-15L15L	15L	15L
A-M10-16S12S	16S	12S
A-M10-16S14S	16S	14S
A-M10-16S16S	16S	16S
A-M10-18L10L	18L	10L
A-M10-18L12L	18L	12L
A-M10-18L15L	18L	15L
A-M10-18L18L	18L	18L
A-M10-20S10S	20S	10S
A-M10-20S12S	20S	12S
A-M10-20S16S	20S	16S
A-M10-20S20S	20S	20S
A-M10-22L12L	22L	12L
A-M10-22L15L	22L	15L
A-M10-22L18L	22L	18L
A-M10-22L22L	22L	22L
A-M10-25S16S	25S	15S
A-M10-25S20S	25S	20S
A-M10-25S25S	25S	25S
A-M10-28L18L	28L	18L
A-M10-28L22L	28L	22L
A-M10-28L28L	28L	28L
A-M10-30S20S	30S	20S
A-M10-30S25S	30S	25S
A-M10-30S30S	30S	30S
A-M10-35L22L	35L	22L
A-M10-35L28L	35L	28L
A-M10-35L35L	35L	35L
A-M10-38S30S	38S	30S
A-M10-38S38S	38S	38S
A-M10-42L42L	42L	42L



Metric Elastomer Male x DIN Male

Part Number	METRIC M(T1)	DIN M(T2)
A-6MM10-0804LL	M08X1.0	04LL
A-6MM10-1006L	M10X1.0	06L
A-6MM10-1006LL	M10X1.0	06LL
A-6MM10-1006S	M10X1.0	06S
A-6MM10-1008L	M10X1.0	08L
A-6MM10-1008LL	M10X1.0	08LL
A-6MM10-1206L	M12X1.5	06L
A-6MM10-1206S	M12X1.5	06S
A-6MM10-1208L	M12X1.5	08L
A-6MM10-1210L	M12X1.5	10L
A-6MM10-1408L	M14X1.5	08L
A-6MM10-1408S	M14X1.5	08S
A-6MM10-1410L	M14X1.5	10L
A-6MM10-1410S	M14X1.5	10S
A-6MM10-1412L	M14X1.5	12L
A-6MM10-1610L	M16X1.5	10L
A-6MM10-1610S	M16X1.5	10S
A-6MM10-1612L	M16X1.5	12L
A-6MM10-1612S	M16X1.5	12S
A-6MM10-1615L	M16X1.5	15L
A-6MM10-1808L	M18X1.5	08L
A-6MM10-1810L	M18X1.5	10L
A-6MM10-1810S	M18X1.5	10S
A-6MM10-1812L	M18X1.5	12L
A-6MM10-1812S	M18X1.5	12S

CONTINUED

Metric Elastomer Male x DIN Male

Part Number	METRIC M(T1)	DIN M(T2)
A-6MM10-1815L	M18X1.5	15L
A-6MM10-1816S	M18X1.5	16S
A-6MM10-1818L	M18X1.5	18L
A-6MM10-2014S	M20X1.5	14S
A-6MM10-2210L	M22X1.5	10L
A-6MM10-2212L	M22X1.5	12L
A-6MM10-2212S	M22X1.5	12S
A-6MM10-2215L	M22X1.5	15L
A-6MM10-2216S	M22X1.5	16S
A-6MM10-2218L	M22X1.5	18L
A-6MM10-2220S	M22X1.5	20S
A-6MM10-2222L	M22X1.5	22L
A-6MM10-2618L	M26X1.5	18L
A-6MM10-2622L	M26X1.5	22L
A-6MM10-2720S	M27X2.0	20S
A-6MM10-2722L	M27X2.0	22L
A-6MM10-2725S	M27X2.0	25S
A-6MM10-3325S	M33X2.0	25S
A-6MM10-3328L	M33X2.0	28L
A-6MM10-3330S	M33X2.0	30S
A-6MM10-4230S	M42X2.0	30S
A-6MM10-4235L	M42X2.0	35L
A-6MM10-4238S	M42X2.0	38S
A-6MM10-4838S	M48X2.0	38S
A-6MM10-4842L	M48X2.0	42L

DIN/METRIC

ADAPTERS

ADAPTERS

DIN/METRIC



DIN Male x ORB Male		
Part Number	DIN M(T1)	ORB M(T2)
A-MR10-06L04	06L	-04
A-MR10-06L06	06L	-06
A-MR10-06S05	06S	-05
A-MR10-08L04	08L	-04
A-MR10-08L05	08L	-05
A-MR10-08L06	08L	-06
A-MR10-08S04	08S	-04
A-MR10-08S05	08S	-05
A-MR10-10L04	10L	-04
A-MR10-10L05	10L	-05
A-MR10-10L06	10L	-06
A-MR10-10L08	10L	-08
A-MR10-10S06	10S	-06
A-MR10-12L06	12L	-06
A-MR10-12L08	12L	-08
A-MR10-12L10	12L	-10
A-MR10-12L12	12L	-12
A-MR10-12S06	12S	-06
A-MR10-12S08	12S	-08
A-MR10-12S10	12S	-10
A-MR10-14S08	14S	-08
A-MR10-15L08	15L	-08
A-MR10-15L10	15L	-10
CONTINUED		

DIN Male x ORB Male		
Part Number	DIN M(T1)	ORB M(T2)
A-MR10-16S08	16S	-08
A-MR10-16S10	16S	-10
A-MR10-16S12	16S	-12
A-MR10-18L08	18L	-08
A-MR10-18L10	18L	-10
A-MR10-20S08	20S	-08
A-MR10-20S10	20S	-10
A-MR10-20S12	20S	-12
A-MR10-22L10	22L	-10
A-MR10-22L12	22L	-12
A-MR10-22L16	22L	-16
A-MR10-25S12	25S	-12
A-MR10-25S16	25S	-16
A-MR10-28L10	28L	-10
A-MR10-28L12	28L	-12
A-MR10-28L16	28L	-16
A-MR10-30S16	30S	-16
A-MR10-30S20	30S	-20
A-MR10-35L16	35L	-16
A-MR10-35L20	35L	-20
A-MR10-38S20	38S	-20
A-MR10-38S24	38S	-24
A-MR10-42L20	42L	-20
A-MR10-42L24	42L	-24



Metric O-Ring Male x NPT Male		
Part Number	METRIC M(T1)	NPT M(T2)
A-5MP10-1002	M10X1.0	02
A-5MP10-1204	M12X1.5	04
A-5MP10-1404	M14X1.5	04
A-5MP10-1606	M16X1.5	06
A-5MP10-1806	M18X1.5	06
A-5MP10-1808	M18X1.5	08
A-5MP10-2008	M20X1.5	08
A-5MP10-2208	M22X1.5	08
A-5MP10-2712	M27X2.0	12



DIN Male x NPT Male

Part Number	DIN M(T1)	NPT M(T2)
A-MP10-04LL02	04LL	-02
A-MP10-05LL02	05LL	-02
A-MP10-06LL02	06LL	-02
A-MP10-08LL02	08LL	-02
A-MP10-10LL04	10LL	-04
A-MP10-12LL06	12LL	-06
A-MP10-12LL08	12LL	-08
A-MP10-06L02	06L	-02
A-MP10-06L04	06L	-04
A-MP10-06S04	06S	-04
A-MP10-08L02	08L	-02
A-MP10-08L04	08L	-04
A-MP10-08L06	08L	-06
A-MP10-08L08	08L	-08
A-MP10-08S04	08S	-04
A-MP10-10L02	10L	-02
A-MP10-10L04	10L	-04
A-MP10-10L06	10L	-06
A-MP10-10L08	10L	-08
A-MP10-10S04	10S	-04
A-MP10-10S06	10S	-06
A-MP10-12L02	12L	-02
A-MP10-12L04	12L	-04
A-MP10-12L06	12L	-06
A-MP10-12L08	12L	-08
A-MP10-12S04	12S	-04

CONTINUED

DIN Male x NPT Male

Part Number	DIN M(T1)	NPT M(T2)
A-MP10-12S06	12S	-06
A-MP10-12S08	12S	-08
A-MP10-14S06	14S	-06
A-MP10-14S08	14S	-08
A-MP10-15L06	15L	-06
A-MP10-15L08	15L	-08
A-MP10-15L12	15L	-12
A-MP10-16S06	16S	-06
A-MP10-16S08	16S	-08
A-MP10-18L08	18L	-08
A-MP10-18L12	18L	-12
A-MP10-20S08	20S	-08
A-MP10-20S12	20S	-12
A-MP10-20S16	20S	-16
A-MP10-22L08	22L	-08
A-MP10-22L12	22L	-12
A-MP10-25S12	25S	-12
A-MP10-25S16	25S	-16
A-MP10-28L16	28L	-16
A-MP10-30S12	30S	-12
A-MP10-30S16	30S	-16
A-MP10-30S20	30S	-20
A-MP10-30S24	30S	-24
A-MP10-35L16	35L	-16
A-MP10-35L20	35L	-20
A-MP10-38S24	38S	-24
A-MP10-42L24	42L	-24

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

DIN/METRIC

ADAPTERS



Metric O-Ring Male x ORFS Male

Part Number	METRIC M(T1)	ORFS M(T2)
A-5MF10-1004	M10X1.0	-04
A-5MF10-1204	M12X1.5	-04
A-5MF10-1206	M12X1.5	-06
A-5MF10-1404	M14X1.5	-04
A-5MF10-1406	M14X1.5	-06
A-5MF10-1408	M14X1.5	-08
A-5MF10-1604	M16X1.5	-04
A-5MF10-1606	M16X1.5	-06
A-5MF10-1608	M16X1.5	-08
A-5MF10-1610	M16X1.5	-10
A-5MF10-1806	M18X1.5	-06
A-5MF10-1808	M18X1.5	-08
A-5MF10-1810	M18X1.5	-10
A-5MF10-2206	M22X1.5	-06
A-5MF10-2208	M22X1.5	-08
A-5MF10-2210	M22X1.5	-10
A-5MF10-2212	M22X1.5	-12
A-5MF10-2216	M22X1.5	-16
A-5MF10-2612	M26X1.5	-12
A-5MF10-2708	M27X2.0	-08
A-5MF10-2710	M27X2.0	-10
A-5MF10-2712	M27X2.0	-12
A-5MF10-2716	M27X2.0	-16
A-5MF10-3020	M30X2.0	-20
A-5MF10-3308	M33X2.0	-08
A-5MF10-3310	M33X2.0	-10
A-5MF10-3312	M33X2.0	-12
A-5MF10-3316	M33X2.0	-16
A-5MF10-3320	M33X2.0	-20
A-5MF10-3820	M38X2.0	-20
A-5MF10-4216	M42X2.0	-16
A-5MF10-4220	M42X2.0	-20
A-5MF10-4224	M42X2.0	-24
A-5MF10-4824	M48X2.0	-24

DIN Male x ORFS Male

Part Number	DIN M(T1)	ORFS M(T2)
A-MF10-06L04	06L	-04
A-MF10-06S04	06S	-04
A-MF10-08L04	08L	-04
A-MF10-08L06	08L	-06
A-MF10-08S04	08S	-04
A-MF10-08S06	08S	-06
A-MF10-10L06	10L	-06
A-MF10-10L08	10L	-08
A-MF10-10S06	10S	-06
A-MF10-12L06	12L	-06
A-MF10-12L08	12L	-08
A-MF10-12L12	12L	-12
A-MF10-12S08	12S	-08
A-MF10-12S10	12S	-10
A-MF10-14S08	14S	-08
A-MF10-15L08	15L	-08
A-MF10-15L12	15L	-12
A-MF10-18L12	18L	-12
A-MF10-20S12	20S	-12
A-MF10-22L12	22L	-12
A-MF10-22L16	22L	-16
A-MF10-25S12	25S	-12
A-MF10-25S16	25S	-16
A-MF10-30S16	30S	-16

ADAPTERS

DIN/METRIC



Metric O-Ring Male x JIC Male

Part Number	METRIC M(T1)	JIC M(T2)
A-5MJ10-1004	M10X1.0	-04
A-5MJ10-1005	M10X1.0	-05
A-5MJ10-1204	M12X1.5	-04
A-5MJ10-1205	M12X1.5	-05
A-5MJ10-1206	M12X1.5	-06
A-5MJ10-1208	M12X1.5	-08
A-5MJ10-1404	M14X1.5	-04
A-5MJ10-1405	M14X1.5	-05
A-5MJ10-1406	M14X1.5	-06
A-5MJ10-1408	M14X1.5	-08
A-5MJ10-1604	M16X1.5	-04
A-5MJ10-1605	M16X1.5	-05
A-5MJ10-1606	M16X1.5	-06
A-5MJ10-1608	M16X1.5	-08
A-5MJ10-1610	M16X1.5	-10
A-5MJ10-1804	M18X1.5	-04
A-5MJ10-1806	M18X1.5	-06
A-5MJ10-1808	M18X1.5	-08
A-5MJ10-1810	M18X1.5	-10
A-5MJ10-2008	M20X1.5	-08
A-5MJ10-2010	M20X1.5	-10
A-5MJ10-2208	M22X1.5	-08
A-5MJ10-2210	M22X1.5	-10
A-5MJ10-2212	M22X1.5	-12
A-5MJ10-2612	M26X1.5	-12
A-5MJ10-2614	M26X1.5	-14
A-5MJ10-2616	M26X1.5	-16
A-5MJ10-2712	M27X2.0	-12
A-5MJ10-2716	M27X2.0	-16
A-5MJ10-3316	M33X2.0	-16
A-5MJ10-3320	M33X2.0	-20
A-5MJ10-3824	M38X2.0	-24
A-5MJ10-4220	M42X2.0	-20
A-5MJ10-4824	M48X2.0	-24

Metric Male x JIC Male, No O-Ring

Part Number	METRIC M(T1)	JIC M(T2)
A-2MJ10-06X1.0-04	M06X1.0	-04
A-2MJ10-08X1.0-04	M08X1.0	-04
A-2MJ10-08X1.25-04	M08X1.0	-04
A-2MJ10-10X1.0-02	M10X1.0	-02
A-2MJ10-10X1.25-04	M10X1.2	-04
A-2MJ10-10X1.5-04	M10X1.5	-04
A-2MJ10-10X1.5-06	M10X1.5	-06
A-2MJ10-12X1.0-04	M12X1.0	-04
A-2MJ10-12X1.0-05	M12X1.0	-05
A-2MJ10-12X1.25-04	M12X1.2	-06
A-2MJ10-12X1.25-05	M12X1.2	-05
A-2MJ10-12X1.25-06	M12X1.2	-06
A-2MJ10-12X1.25-08	M12X1.2	-08
A-2MJ10-12X1.5-04	M12X1.5	-04
A-2MJ10-12X1.5-06	M12X1.5	-06
A-2MJ10-12X1.5-08	M12X1.5	-08
A-2MJ10-14X1.5-04	M14X1.5	-04
A-2MJ10-14X1.5-06	M14X1.5	-06
A-2MJ10-14X1.5-08	M14X1.5	-08
A-2MJ10-14X1.5-10	M14X1.5	-10
A-2MJ10-16X1.5-06	M16X1.5	-06
A-2MJ10-16X1.5-08	M16X1.5	-08
A-2MJ10-16X1.5-10	M16X1.5	-10
A-2MJ10-16X1.5-12	M16X1.5	-12
A-2MJ10-18X1.5-06	M18X1.5	-06
A-2MJ10-18X1.5-08	M18X1.5	-08
A-2MJ10-18X1.5-10	M18X1.5	-10
A-2MJ10-20X1.5-06	M20X1.5	-06
A-2MJ10-20X1.5-08	M20X1.5	-08
A-2MJ10-20X1.5-10	M20X1.5	-10
A-2MJ10-22X1.5-06	M22X1.5	-06
A-2MJ10-22X1.5-08	M22X1.5	-08
A-2MJ10-22X1.5-10	M22X1.5	-10
A-2MJ10-24X1.5-12	M24X1.5	-12
A-2MJ10-25X1.5-10	M25X1.5	-10
A-2MJ10-25X1.5-12	M25X1.5	-12
A-2MJ10-26X1.5-10	M26X1.5	-10
A-2MJ10-26X1.5-12	M26X1.5	-12
A-2MJ10-27X1.5-12	M27X1.5	-12
A-2MJ10-30X1.5-12	M30X1.5	-12
A-2MJ10-33X1.5-20	M33X1.5	-20
A-2MJ10-33X2.0-20	M33X2.0	-20
A-2MJ10-38X1.5-20	M38X1.5	-20
A-2MJ10-38X1.5-24	M38X1.5	-24
A-2MJ10-45X1.5-20	M45X1.5	-20
A-2MJ10-45X1.5-24	M45X1.5	-24



DIN Male x JIC Male

Part Number	DIN M(T1)	JIC M(T2)
A-9MJ10-1006LL04	06LL	-04
A-9MJ10-1208LL04	08LL	-04
A-9MJ10-1208LL06	08LL	-06
A-9MJ10-1206L04	06L	-04
A-9MJ10-1406S04	06S	-04
A-9MJ10-1408L04	08L	-04
A-9MJ10-1408L06	08L	-06
A-9MJ10-1608S04	08S	-04
A-9MJ10-1608S06	08S	-06
A-9MJ10-1610L06	10L	-06
A-9MJ10-1610L08	10L	-08
A-9MJ10-1810S06	10S	-06
A-9MJ10-1810S08	10S	-08
A-9MJ10-1812L06	12L	-06
A-9MJ10-1812L08	12L	-08
A-9MJ10-2012S06	12S	-06
A-9MJ10-2012S08	12S	-08
A-9MJ10-2012S10	12S	-10
A-9MJ10-2214S06	14S	-06
A-9MJ10-2214S08	14S	-08
A-9MJ10-2215L08	15L	-08
A-9MJ10-2215L10	15L	-10
A-9MJ10-2215L12	15L	-12
A-9MJ10-2416S08	16S	-08
A-9MJ10-2416S10	16S	-10
A-9MJ10-2416S12	16S	-12
A-9MJ10-2618L10	18L	-10
A-9MJ10-2618L12	18L	-12
A-9MJ10-3020S12	20S	-12
A-9MJ10-3020S16	20S	-16
A-9MJ10-3022L12	22L	-12
A-9MJ10-3625S12	25S	-12
A-9MJ10-3625S16	25S	-16
A-9MJ10-3628L16	28L	-16
A-9MJ10-4230S16	30S	-16
A-9MJ10-4230S20	30S	-20
A-9MJ10-4535L20	35L	-20
A-9MJ10-5238S20	38S	-20
A-9MJ10-5238S24	38S	-24
A-9MJ10-5242L24	42L	-24

Metric Elastomer Male x JIC Male

Part Number	METRIC M(T1)	JIC M(T2)
A-9MJ10-1006LL04	M10X1.0	-04
A-9MJ10-1208LL04	M12X1.0	-04
A-9MJ10-1208LL06	M12X1.0	-06
A-9MJ10-1206L04	M12X1.5	-04
A-9MJ10-1406S04	M14X1.5	-04
A-9MJ10-1408L04	M14X1.5	-04
A-9MJ10-1408L06	M14X1.5	-06
A-9MJ10-1608S04	M16X1.5	-04
A-9MJ10-1608S06	M16X1.5	-06
A-9MJ10-1610L06	M16X1.5	-06
A-9MJ10-1610L08	M16X1.5	-08
A-9MJ10-1810S06	M18X1.5	-06
A-9MJ10-1810S08	M18X1.5	-08
A-9MJ10-1812L06	M18X1.5	-06
A-9MJ10-1812L08	M18X1.5	-08
A-9MJ10-2012S06	M20X1.5	-06
A-9MJ10-2012S08	M20X1.5	-08
A-9MJ10-2012S10	M20X1.5	-10
A-9MJ10-2214S06	M22X1.5	-06
A-9MJ10-2214S08	M22X1.5	-08
A-9MJ10-2215L08	M22X1.5	-08
A-9MJ10-2215L10	M22X1.5	-10
A-9MJ10-2215L12	M22X1.5	-12
A-9MJ10-2416S08	M24X1.5	-08
A-9MJ10-2416S10	M24X1.5	-10
A-9MJ10-2416S12	M24X1.5	-12
A-9MJ10-2618L10	M26X1.5	-10
A-9MJ10-2618L12	M26X1.5	-12
A-9MJ10-3020S12	M30X2.0	-12
A-9MJ10-3020S16	M30X2.0	-16
A-9MJ10-3022L12	M30X2.0	-12
A-9MJ10-3625S12	M36X2.0	-12
A-9MJ10-3625S16	M36X2.0	-16
A-9MJ10-3628L16	M36X2.0	-16
A-9MJ10-4230S16	M42X2.0	-16
A-9MJ10-4230S20	M42X2.0	-20
A-9MJ10-4535L20	M45X2.0	-20
A-9MJ10-5238S20	M52X2.0	-20
A-9MJ10-5238S24	M52X2.0	-24
A-9MJ10-5242L24	M52X2.0	-24



DIN Male x DIN Female

Part Number	DIN M(T1)	DIN F(T2)
A-M22-06L06L	06L	06L
A-M22-06L08L	06L	08L
A-M22-06L08S	06L	08S
A-M22-06L10L	06L	10L
A-M22-06L12L	06L	12L
A-M22-06L15L	06L	15L
A-M22-06L18L	06L	18L
A-M22-06L22L	06L	22L
A-M22-06L28L	06L	28L
A-M22-06L35L	06L	35L
A-M22-06L42L	06L	42L
A-M22-06S08S	06S	08S
A-M22-06S10S	06S	10S
A-M22-06S12S	06S	12S
A-M22-06S14S	06S	14S
A-M22-06S16S	06S	16S
A-M22-06S20S	06S	20S
A-M22-06S25S	06S	25S
A-M22-06S30S	06S	30S
A-M22-06S38S	06S	38S
A-M22-08L06L	08L	06L
A-M22-08L08L	08L	08L
A-M22-08L08S	08L	08S
A-M22-08L10L	08L	10L
A-M22-08L10S	08L	10S
A-M22-08L12L	08L	12L
A-M22-08L12S	08L	12S
A-M22-08L15L	08L	15L
A-M22-08L18L	08L	18L
A-M22-08L22L	08L	22L
A-M22-08L28L	08L	28L
A-M22-08L35L	08L	35L
A-M22-08L42L	08L	42L
A-M22-08S06L	08S	06L
A-M22-08S08S	08S	08S
A-M22-08S10S	08S	10S
A-M22-08S12S	08S	12S
A-M22-08S14S	08S	14S
A-M22-08S16S	08S	16S
A-M22-08S20S	08S	20S
A-M22-08S25S	08S	25S
A-M22-08S30S	08S	30S
A-M22-08S38S	08S	38S
A-M22-10L08L	10L	08L
A-M22-10L10L	10L	10L

CONTINUED

DIN Male x DIN Female

Part Number	DIN M(T1)	DIN F(T2)
A-M22-10L10S	10L	10S
A-M22-10L12L	10L	12L
A-M22-10L12S	10L	12S
A-M22-10L15L	10L	15L
A-M22-10L18L	10L	18L
A-M22-10L22L	10L	22L
A-M22-10L28L	10L	28L
A-M22-10L35L	10L	35L
A-M22-10L42L	10L	42L
A-M22-10S06L	10S	06L
A-M22-10S08L	10S	08L
A-M22-10S08S	10S	08S
A-M22-10S10S	10S	10S
A-M22-10S12S	10S	12S
A-M22-10S14S	10S	14S
A-M22-10S16S	10S	16S
A-M22-10S20S	10S	20S
A-M22-10S25S	10S	25S
A-M22-10S30S	10S	30S
A-M22-10S38S	10S	38S
A-M22-12L08L	12L	08L
A-M22-12L10L	12L	10L
A-M22-12L10S	12L	10S
A-M22-12L12L	12L	12L
A-M22-12L12S	12L	12S
A-M22-12L14S	12L	14S
A-M22-12L15L	12L	15L
A-M22-12L18L	12L	18L
A-M22-12L22L	12L	22L
A-M22-12L28L	12L	28L
A-M22-12L35L	12L	35L
A-M22-12L42L	12L	42L
A-M22-12S08L	12S	08L
A-M22-12S10L	12S	10L
A-M22-12S10S	12S	10S
A-M22-12S12S	12S	12S
A-M22-12S14S	12S	14S
A-M22-12S16S	12S	16S
A-M22-12S20S	12S	20S
A-M22-12S25S	12S	25S
A-M22-12S30S	12S	30S
A-M22-12S38S	12S	38S
A-M22-14S10L	14S	10L
A-M22-14S10S	14S	10S
A-M22-14S12L	14S	12L

CONTINUED

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

DIN/METRIC

ADAPTERS



DIN Male x DIN Female

Part Number	DIN M(T1)	DIN F(T2)
A-M22-14S12S	14S	12S
A-M22-14S14S	14S	14S
A-M22-14S16S	14S	16S
A-M22-14S20S	14S	20S
A-M22-14S25S	14S	25S
A-M22-14S30S	14S	30S
A-M22-14S38S	14S	38S
A-M22-15L10L	15L	10L
A-M22-15L10S	15L	10S
A-M22-15L12L	15L	12L
A-M22-15L12S	15L	12S
A-M22-15L14S	15L	14S
A-M22-15L15L	15L	15L
A-M22-15L18L	15L	18L
A-M22-15L22L	15L	22L
A-M22-15L28L	15L	28L
A-M22-15L35L	15L	35L
A-M22-15L42L	15L	42L
A-M22-16S08S	16S	08S
A-M22-16S10L	16S	10L
A-M22-16S10S	16S	10S
A-M22-16S12L	16S	12L
A-M22-16S12S	16S	12S
A-M22-16S14S	16S	14S
A-M22-16S15L	16S	15L
A-M22-16S16S	16S	16S
A-M22-16S20S	16S	20S
A-M22-16S25S	16S	25S
A-M22-16S30S	16S	30S
A-M22-16S38S	16S	38S
A-M22-18L15L	18L	15L
A-M22-18L16S	18L	16S
A-M22-18L18L	18L	18L
A-M22-18L20S	18L	20S
A-M22-18L22L	18L	22L
A-M22-18L28L	18L	28L
A-M22-18L35L	18L	35L
A-M22-18L42L	18L	42L
A-M22-20S15L	20S	15L
A-M22-20S16S	20S	16S
A-M22-20S18L	20S	18L
A-M22-20S20S	20S	20S
A-M22-20S25S	20S	25S
A-M22-20S30S	20S	30S
A-M22-20S38S	20S	38S

CONTINUED

DIN Male x DIN Female

Part Number	DIN M(T1)	DIN F(T2)
A-M22-22L16S	22L	16S
A-M22-22L18L	22L	18L
A-M22-22L20S	22L	20S
A-M22-22L22L	22L	22L
A-M22-22L25S	22L	25S
A-M22-22L28L	22L	28L
A-M22-22L35L	22L	35L
A-M22-22L42L	22L	42L
A-M22-25S16S	25S	16S
A-M22-25S18L	25S	18L
A-M22-25S20S	25S	20S
A-M22-25S22L	25S	22L
A-M22-25S25S	25S	25S
A-M22-25S30S	25S	30S
A-M22-25S38S	25S	38S
A-M22-2718L	-27	18L
A-M22-28L20S	28L	20S
A-M22-28L22L	28L	22L
A-M22-28L25S	28L	25S
A-M22-28L28L	28L	28L
A-M22-28L30S	28L	30S
A-M22-28L35L	28L	35L
A-M22-28L42L	28L	42L
A-M22-30S20S	30S	20S
A-M22-30S22L	30S	22L
A-M22-30S25S	30S	25S
A-M22-30S28L	30S	28L
A-M22-30S30S	30S	30S
A-M22-30S38S	30S	38S
A-M22-35L25S	35L	25S
A-M22-35L28L	35L	28L
A-M22-35L30S	35L	30S
A-M22-35L35L	35L	35L
A-M22-35L38S	35L	38S
A-M22-35L42L	35L	42L
A-M22-38S22L	38S	22L
A-M22-38S28L	38S	28L
A-M22-38S30S	38S	30S
A-M22-38S35L	38S	35L
A-M22-38S38S	38S	38S
A-M22-42L28L	42L	28L
A-M22-42L30S	42L	30S
A-M22-42L35L	42L	35L
A-M22-42L38S	42L	38S
A-M22-42L42L	42L	42L

ADAPTERS

DIN/METRIC



Metric Elastomer Female x DIN Female

Part Number	METRIC M(T1)	DIN F(T2)
A-6MM22-1006L	M10X1.0	06L
A-6MM22-1206S	M12X1.5	06S
A-6MM22-1208L	M12X1.5	08L
A-6MM22-1408S	M14X1.5	08S
A-6MM22-1410L	M14X1.5	10L
A-6MM22-1610S	M16X1.5	10S
A-6MM22-1612L	M16X1.5	12L
A-6MM22-1812S	M18X1.5	12S
A-6MM22-1815L	M18X1.5	15L
A-6MM22-2014S	M20X1.5	14S
A-6MM22-2216S	M22X1.5	16S
A-6MM22-2218L	M22X1.5	18L
A-6MM22-2622L	M26X1.5	22L
A-6MM22-2720S	M27X2.0	20S
A-6MM22-3325S	M33X2.0	25S
A-6MM22-3328L	M33X2.0	28L
A-6MM22-4230S	M42X2.0	30S
A-6MM22-4235L	M42X2.0	35L
A-6MM22-4838S	M48X2.0	38S
A-6MM22-4842L	M48X2.0	42L

Metric Female x DIN Male

Part Number	METRIC F(T1)	DIN M(T2)
A-2MM55-10X1.0-06L	M10X1.0	06L
A-2MM55-12X1.5-06S	M12X1.5	06S
A-2MM55-12X1.5-08L	M12X1.5	08L
A-2MM55-14X1.5-08S	M14X1.5	08S
A-2MM55-14X1.5-10L	M14X1.5	10L
A-2MM55-16X1.5-10S	M16X1.5	10S
A-2MM55-16X1.5-12L	M16X1.5	12L
A-2MM55-18X1.5-12S	M18X1.5	12S
A-2MM55-18X1.5-15L	M18X1.5	15L
A-2MM55-20X1.5-14S	M20X1.5	14S
A-2MM55-22X1.5-16S	M22X1.5	16S
A-2MM55-22X1.5-18L	M22X1.5	18L
A-2MM55-26X1.5-22L	M26X1.5	22L
A-2MM55-27X2.0-20S	M27X2.0	20S
A-2MM55-33X2.0-25S	M33X2.0	25S
A-2MM55-33X2.0-28L	M33X2.0	28L
A-2MM55-42X2.0-30S	M42X2.0	30S
A-2MM55-42X2.0-35L	M42X2.0	35L
A-2MM55-48X2.0-38S	M48X2.0	38S



Metric Female x NPT Male

Part Number	METRIC F(T1)	NPT M(T2)
A-2MP55-06X1.0-02	M06X1.0	-02
A-2MP55-08X1.0-02	M08X1.0	-02
A-2MP55-10X1.0-02	M10X1.0	-02
A-2MP55-10X1.0-04	M10X1.0	-04
A-2MP55-10X1.25-02	M10X1.2	-02
A-2MP55-10X1.5-02	M10X1.5	-02
A-2MP55-10X1.50-02	M10X1.5	-02
A-2MP55-12X1.0-02	M12X1.0	-02
A-2MP55-12X1.5-02	M12X1.5	-02
A-2MP55-12X1.5-04	M12X1.5	-04
A-2MP55-14X1.5-04	M14X1.5	-04
A-2MP55-14X1.5-06	M14X1.5	-06
A-2MP55-14X1.5-08	M14X1.5	-08
A-2MP55-16X1.5-04	M16X1.5	-04
A-2MP55-16X1.5-06	M16X1.5	-06
A-2MP55-18X1.5-06	M18X1.5	-06
A-2MP55-18X1.5-08	M18X1.5	-08
A-2MP55-18X1.5-12	M18X1.5	-12
A-2MP55-20X1.5-08	M20X1.5	-08
A-2MP55-20X1.5-12	M20X1.5	-12
A-2MP55-22X1.5-08	M22X1.5	-08
A-2MP55-24X1.5-08	M24X1.5	-08
A-2MP55-26X1.5-12	M26X1.5	-12
A-2MP55-26X1.5-16	M26X1.5	-16
A-2MP55-30X1.5-12	M30X1.5	-12
A-2MP55-30X1.5-20	M30X1.5	-20
A-2MP55-30X2.0-12	M30X2.0	-12

Metric O-Ring Male x NPT Female

Part Number	METRIC M(T1)	NPT F(T2)
A-5MP22-1002	M10X1.0	-02
A-5MP22-1004	M10X1.0	-04
A-5MP22-1202	M12X1.5	-02
A-5MP22-1204	M12X1.5	-04
A-5MP22-1206	M12X1.5	-06
A-5MP22-1402	M14X1.5	-02
A-5MP22-1404	M14X1.5	-04
A-5MP22-1604	M16X1.5	-04
A-5MP22-1606	M16X1.5	-06
A-5MP22-1608	M16X1.5	-08
A-5MP22-1802	M18X1.5	-02
A-5MP22-1804	M18X1.5	-04
A-5MP22-1806	M18X1.5	-06
A-5MP22-1808	M18X1.5	-08
A-5MP22-1812	M18X1.5	-12
A-5MP22-2004	M20X1.5	-04
A-5MP22-2006	M20X1.5	-06
A-5MP22-2008	M20X1.5	-08
A-5MP22-2206	M22X1.5	-06
A-5MP22-2208	M22X1.5	-08
A-5MP22-2212	M22X1.5	-12
A-5MP22-2412	M24X1.5	-12
A-5MP22-2612	M26X1.5	-12
A-5MP22-2712	M27X2.0	-12
A-5MP22-3012	M30X2.0	-12
A-5MP22-3316	M33X2.0	-16
A-5MP22-4216	M42X2.0	-16
A-5MP22-4220	M42X2.0	-20
A-5MP22-4816	M48X2.0	-16
A-5MP22-4824	M48X2.0	-24



DIN Male x NPT Female		
Part Number	DIN M(T1)	NPT F(T2)
A-9MP22-1206L04	06L	-04
A-9MP22-1206L06	06L	-06
A-9MP22-1408L04	08L	-04
A-9MP22-1610L04	10L	-04
A-9MP22-1610L06	10L	-06
A-9MP22-1812L04	12L	-04
A-9MP22-1812L06	12L	-06
A-9MP22-1812L08	12L	-08
A-9MP22-2012S04	12S	-04
A-9MP22-2215L06	15L	-06
A-9MP22-2215L08	15L	-08
A-9MP22-2215L12	15L	-12
A-9MP22-2416S12	16S	-12
A-9MP22-2618L12	18L	-12
A-9MP22-3022L12	22L	-12
A-9MP22-4230S16	30S	-16
A-9MP22-4230S20	30S	-20

Metric Elastomer Male x NPT Female		
Part Number	METRIC M(T1)	NPT F(T2)
A-9MP22-1206L04	M12X1.5	-04
A-9MP22-1206L06	M12X1.5	-06
A-9MP22-1408L04	M14X1.5	-04
A-9MP22-1610L04	M16X1.5	-04
A-9MP22-1610L06	M16X1.5	-06
A-9MP22-1812L04	M18X1.5	-04
A-9MP22-1812L06	M18X1.5	-06
A-9MP22-1812L08	M18X1.5	-08
A-9MP22-2012S04	M20X1.5	-04
A-9MP22-2215L06	M22X1.5	-06
A-9MP22-2215L08	M22X1.5	-08
A-9MP22-2215L12	M22X1.5	-12
A-9MP22-2416S12	M24X1.5	-12
A-9MP22-2618L12	M26X1.5	-12
A-9MP22-3022L12	M30X2.0	-12
A-9MP22-4230S16	M42X2.0	-16
A-9MP22-4230S20	M42X2.0	-20



DIN Female x NPT Male		
Part Number	DIN F(T1)	NPT M(T2)
A-MP55-06L02	06L	-02
A-MP55-06S04	06S	-04
A-MP55-08L02	08L	-02
A-MP55-08L04	08L	-04
A-MP55-08S04	08S	-04
A-MP55-10L04	10L	-04
A-MP55-10S04	10S	-04
A-MP55-10S06	10S	-06
A-MP55-12L04	12L	-04
A-MP55-12L06	12L	-06
A-MP55-12S06	12S	-06
A-MP55-14S08	14S	-08
A-MP55-15L06	15L	-06

DIN Female x NPT Male		
Part Number	DIN F(T1)	NPT M(T2)
A-MP55-15L08	15L	-08
A-MP55-16S08	16S	-08
A-MP55-18L08	18L	-08
A-MP55-20S08	20S	-08
A-MP55-20S12	20S	-12
A-MP55-22L12	22L	-12
A-MP55-25S12	25S	-12
A-MP55-25S16	25S	-16
A-MP55-28L16	28L	-16
A-MP55-30S12	30S	-12
A-MP55-30S20	30S	-20
A-MP55-35L20	35L	-20
A-MP55-38S24	38S	-24
A-MP55-42L24	42L	-24

CONTINUED



Metric Male x JIC Female, No O-Ring

Part Number	METRIC M(T1)	JIC F(T2)
A-2MJ22-12X1.5-05	M12X1.5	-05
A-2MJ22-14X1.5-06	M14X1.5	-06
A-2MJ22-16X1.5-06	M16X1.5	-06
A-2MJ22-16X1.5-08	M16X1.5	-08
A-2MJ22-16X1.5-10	M16X1.5	-10
A-2MJ22-18X1.5-06	M18X1.5	-06
A-2MJ22-18X1.5-08	M18X1.5	-08
A-2MJ22-18X1.5-10	M18X1.5	-10
A-2MJ22-20X1.5-06	M20X1.5	-06
A-2MJ22-20X1.5-08	M20X1.5	-08
A-2MJ22-20X1.5-10	M20X1.5	-10
A-2MJ22-22X1.5-06	M22X1.5	-06
A-2MJ22-22X1.5-08	M22X1.5	-08
A-2MJ22-22X1.5-10	M22X1.5	-10

DIN Male x JIC Female

Part Number	DIN M(T1)	JIC F(T2)
A-MJ22-06L04	06L	-04
A-MJ22-06S04	06S	-04
A-MJ22-08L06	08L	-06
A-MJ22-08S06	08S	-06
A-MJ22-10L06	10L	-06
A-MJ22-10S06	10S	-06
A-MJ22-12L08	12L	-08
A-MJ22-12S08	12S	-08
A-MJ22-14S08	14S	-08
A-MJ22-15L08	15L	-08
A-MJ22-16S08	16S	-08
A-MJ22-18L12	18L	-12
A-MJ22-20S12	20S	-12
A-MJ22-22L12	22L	-12
A-MJ22-25S16	25S	-16
A-MJ22-28L16	28L	-16
A-MJ22-30S20	30S	-20
A-MJ22-35L24	35L	-24
A-MJ22-38S24	38S	-24
A-MJ22-42L24	42L	-24



DIN Female x JIC Male

Part Number	DIN F(T1)	JIC M(T2)
A-MJ55-06LL04	06LL	-04
A-MJ55-06L04	06L	-04
A-MJ55-06L05	06L	-05
A-MJ55-06S04	06S	-04
A-MJ55-06S06	06S	-06
A-MJ55-08L04	08L	-04
A-MJ55-08L06	08L	-06
A-MJ55-08S04	08S	-04
A-MJ55-08S06	08S	-06
A-MJ55-10L04	10L	-04
A-MJ55-10L06	10L	-06
A-MJ55-10L08	10L	-08
A-MJ55-10S04	10S	-04
A-MJ55-10S06	10S	-06
A-MJ55-10S08	10S	-08
A-MJ55-12L06	12L	-06
A-MJ55-12L08	12L	-08
A-MJ55-12L10	12L	-10
A-MJ55-12S05	12S	-05
A-MJ55-12S06	12S	-06
A-MJ55-12S08	12S	-08
A-MJ55-12S10	12S	-10
A-MJ55-14S06	14S	-06
A-MJ55-14S08	14S	-08
A-MJ55-14S10	14S	-10
A-MJ55-15L06	15L	-06

CONTINUED

DIN Female x JIC Male

Part Number	DIN F(T1)	JIC M(T2)
A-MJ55-15L08	15L	-08
A-MJ55-15L10	15L	-10
A-MJ55-16S08	16S	-08
A-MJ55-16S10	16S	-10
A-MJ55-16S12	16S	-12
A-MJ55-18L10	18L	-10
A-MJ55-18L12	18L	-12
A-MJ55-20S10	20S	-10
A-MJ55-20S12	20S	-12
A-MJ55-20S16	20S	-16
A-MJ55-22L12	22L	-12
A-MJ55-22L16	22L	-16
A-MJ55-25S10	25S	-10
A-MJ55-25S12	25S	-12
A-MJ55-25S16	25S	-16
A-MJ55-28L16	28L	-16
A-MJ55-28L20	28L	-20
A-MJ55-30S16	30S	-16
A-MJ55-30S20	30S	-20
A-MJ55-30S24	30S	-24
A-MJ55-35L20	35L	-20
A-MJ55-35L24	35L	-24
A-MJ55-38S20	38S	-20
A-MJ55-38S24	38S	-24
A-MJ55-38S32	38S	-32
A-MJ55-42L24	42L	-24
A-MJ55-42L32	42L	-32



DIN Female x DIN Female		
Part Number	DIN F(T1)	DIN F(T2)
A-M67-06L06L	06L	06L
A-M67-06L06S	06L	06S
A-M67-06L08L	06L	08L
A-M67-06L08S	06L	08S
A-M67-06L10L	06L	10L
A-M67-06L10S	06L	10S
A-M67-06S06S	06S	06S
A-M67-08L08L	08L	08L
A-M67-08L10L	08L	10L
A-M67-08L10S	08L	10S
A-M67-08L12L	08L	12L
A-M67-08L12S	08L	12S
A-M67-08S08L	08S	08L
A-M67-08S08S	08S	08S
A-M67-08S10S	08S	10S
A-M67-10L10L	10L	10L
A-M67-10L12L	10L	12L
A-M67-10L12S	10L	12S
A-M67-10L14S	10L	14S
A-M67-10L15L	10L	15L
A-M67-10L16S	10L	16S
A-M67-10S10L	10S	10L
A-M67-10S10S	10S	10S
A-M67-10S12L	10S	12L
A-M67-10S12S	10S	12S
A-M67-12L12L	12L	12L
A-M67-12L14S	12L	14S
A-M67-12L15L	12L	15L
A-M67-12L16S	12L	16S
A-M67-12L18L	12L	18L
A-M67-12L20S	12L	20S
A-M67-12S12L	12S	12L
A-M67-12S12S	12S	12S
A-M67-12S14S	12S	14S
A-M67-12S15L	12S	15L
A-M67-12S16S	12S	16S
A-M67-14S14S	14S	14S
A-M67-14S16S	14S	16S
A-M67-15L15L	15L	15L
A-M67-15L16S	15L	16S
A-M67-15L18L	15L	18L
A-M67-15L20S	15L	20S
A-M67-15L22L	15L	22L

CONTINUED

DIN Female x DIN Female		
Part Number	DIN F(T1)	DIN F(T2)
A-M67-15L25S	15L	25S
A-M67-16S16S	16S	16S
A-M67-16S18L	16S	18L
A-M67-16S20S	16S	20S
A-M67-16S22L	16S	22L
A-M67-16S25S	16S	25S
A-M67-18L18L	18L	18L
A-M67-18L20S	18L	20S
A-M67-18L22L	18L	22L
A-M67-18L25S	18L	25S
A-M67-18L28L	18L	28L
A-M67-18L30S	18L	30S
A-M67-20S20S	20S	20S
A-M67-20S22L	20S	22L
A-M67-20S25S	20S	25S
A-M67-20S28L	20S	28L
A-M67-20S30S	20S	30S
A-M67-22L22L	22L	22L
A-M67-22L25S	22L	25S
A-M67-22L28L	22L	28L
A-M67-22L30S	22L	30S
A-M67-22L35L	22L	35L
A-M67-22L38S	22L	38S
A-M67-25S25S	25S	25S
A-M67-25S28L	25S	28L
A-M67-25S30S	25S	30S
A-M67-25S35L	25S	35L
A-M67-25S38S	25S	38S
A-M67-28L28L	28L	28L
A-M67-28L30S	28L	30S
A-M67-28L35L	28L	35L
A-M67-28L38S	28L	38S
A-M67-28L42L	28L	42L
A-M67-30S30S	30S	30S
A-M67-30S35L	30S	35L
A-M67-30S38S	30S	38S
A-M67-30S42L	30S	42L
A-M67-35L35L	35L	35L
A-M67-35L38S	35L	38S
A-M67-35L42L	35L	42L
A-M67-38S38S	38S	38S
A-M67-38S42L	38S	42L
A-M67-42L42L	42L	42L



Metric Female x Metric Female		
Part Number	METRIC F(T1)	METRIC F(T2)
A-2M67-10X1.0-10X1.0	M10X1.0	M10X1.0
A-2M67-12X1.5-12X1.5	M12X1.5	M12X1.5
A-2M67-14X1.5-14X1.5	M14X1.5	M14X1.5
A-2M67-16X1.5-12X1.5	M16X1.5	M12X1.5
A-2M67-16X1.5-16X1.5	M16X1.5	M16X1.5
A-2M67-18X1.5-18X1.5	M18X1.5	M18X1.5
A-2M67-20X1.5-20X1.5	M20X1.5	M20X1.5
A-2M67-22X1.5-16X1.5	M22X1.5	M16X1.5
A-2M67-22X1.5-22X1.5	M22X1.5	M22X1.5
A-2M67-27X2.0-27X2.0	M27X2.0	M27X2.0
A-2M67-33X2.0-33X2.0	M33X2.0	M33X2.0



Metric Female x NPT Female		
Part Number	METRIC F(T1)	NPT F(T2)
A-2MP67-06X1.0-02	M06X1.0	-02
A-2MP67-08X1.0-02	M08X1.0	-02
A-2MP67-10X1.0-02	M10X1.0	-02
A-2MP67-12X1.5-04	M12X1.5	-04
A-2MP67-14X1.5-04	M14X1.5	-04
A-2MP67-16X1.5-04	M16X1.5	-04



Metric O-Ring Male x ORFS Male 45°		
Part Number	METRIC M(T1)	ORFS M(T2)
A-5MF29-1404	M14X1.5	-04
A-5MF29-1406	M14X1.5	-06
A-5MF29-1408	M14X1.5	-08
A-5MF29-1606	M16X1.5	-06
A-5MF29-1806	M18X1.5	-06
A-5MF29-1808	M18X1.5	-08
A-5MF29-2210	M22X1.5	-10
A-5MF29-2712	M27X2.0	-12
A-5MF29-3316	M33X2.0	-16
A-5MF29-4220	M42X2.0	-20
A-5MF29-4824	M48X2.0	-24



Metric O-Ring Male x JIC Male 45°		
Part Number	METRIC M(T1)	JIC M(T2)
A-5MJ29-1004	M10X1.0	-04
A-5MJ29-1204	M12X1.5	-04
A-5MJ29-1205	M12X1.5	-05
A-5MJ29-1406	M14X1.5	-06
A-5MJ29-1606	M16X1.5	-06
A-5MJ29-1608	M16X1.5	-08
A-5MJ29-1808	M18X1.5	-08
A-5MJ29-1810	M18X1.5	-10
A-5MJ29-2210	M22X1.5	-10
A-5MJ29-2212	M22X1.5	-12
A-5MJ29-2610	M26X1.5	-10
A-5MJ29-2712	M27X2.0	-12
A-5MJ29-2716	M27X2.0	-16
A-5MJ29-3316	M33X2.0	-16
A-5MJ29-4824	M48X2.0	-24



DIN Male x DIN Female 45°

Part Number	DIN M(T1)	DIN F(T2)
A-M23-06L06L	06L	06L
A-M23-06S06S	06S	06S
A-M23-08L08L	08L	08L
A-M23-08S08S	08S	08S
A-M23-10L10L	10L	10L
A-M23-10S10S	10S	10S
A-M23-12L12L	12L	12L
A-M23-12S12S	12S	12S
A-M23-14S14S	14S	14S
A-M23-15L15L	15L	15L
A-M23-16S16S	16S	16S
A-M23-18L18L	18L	18L
A-M23-20S20S	20S	20S
A-M23-22L22L	22L	22L
A-M23-25S25S	25S	25S
A-M23-28L28L	28L	28L
A-M23-30S30S	30S	30S
A-M23-35L35L	35L	35L
A-M23-38S38S	38S	38S
A-M23-42L42L	42L	42L



DIN Male x DIN Male 90°

Part Number	DIN M(T1)	DIN M(T2)
A-M18-04LL04LL	04LL	04LL
A-M18-06LL06LL	06LL	06LL
A-M18-08LL08LL	08LL	08LL
A-M18-10LL10LL	10LL	10LL
A-M18-12LL12LL	12LL	12LL
A-M18-06L06L	06L	06L
A-M18-06S06S	06S	06S
A-M18-08L08L	08L	08L
A-M18-08S08S	08S	08S
A-M18-10L10L	10L	10L
A-M18-10S10S	10S	10S
A-M18-12L12L	12L	12L
A-M18-12S12S	12S	12S
A-M18-14S14S	14S	14S
A-M18-15L15L	15L	15L
A-M18-16S16S	16S	16S
A-M18-18L18L	18L	18L
A-M18-20S20S	20S	20S
A-M18-22L22L	22L	22L
A-M18-25S25S	25S	25S
A-M18-28L28L	28L	28L
A-M18-30S30S	30S	30S
A-M18-35L35L	35L	35L
A-M18-38S38S	38S	38S
A-M18-42L42L	42L	42L



Metric Taper Male x DIN Male 90°

Part Number	METRIC M(T1)	DIN M(T2)
A-4MM18-0604LL	M06X1.0	04LL
A-4MM18-0606LL	M06X1.0	06LL
A-4MM18-0804LL	M08X1.0	04LL
A-4MM18-0806LL	M08X1.0	06LL
A-4MM18-1006LL	M10X1.0	06LL
A-4MM18-1008LL	M10X1.0	08LL
A-4MM18-1006L	M10X1.0	06L
A-4MM18-1206S	M12X1.5	06S
A-4MM18-1208L	M12X1.5	08L
A-4MM18-1408S	M14X1.5	08S
A-4MM18-1410L	M14X1.5	10L
A-4MM18-1610S	M16X1.5	10S
A-4MM18-1612L	M16X1.5	12L
A-4MM18-1812S	M18X1.5	12S
A-4MM18-1815L	M18X1.5	15L
A-4MM18-2014S	M20X1.5	14S
A-4MM18-2216S	M22X1.5	16S
A-4MM18-2218L	M22X1.5	18L



Metric O-Ring Male x DIN Male 90°

Part Number	METRIC M(T1)	DIN M(T2)
A-5MM33-1006L	M10X1.0	06L
A-5MM33-1206S	M12X1.5	06S
A-5MM33-1208L	M12X1.5	08L
A-5MM33-1408L	M14X1.5	08L
A-5MM33-1408S	M14X1.5	08S
A-5MM33-1410L	M14X1.5	10L
A-5MM33-1610L	M16X1.5	10L
A-5MM33-1610S	M16X1.5	10S
A-5MM33-1612L	M16X1.5	12L
A-5MM33-1615L	M16X1.5	15L
A-5MM33-1812S	M18X1.5	12S
A-5MM33-1815L	M18X1.5	15L
A-5MM33-2014S	M20X1.5	14S
A-5MM33-2210L	M22X1.5	10L
A-5MM33-2215L	M22X1.5	15L
A-5MM33-2216S	M22X1.5	16S
A-5MM33-2218L	M22X1.5	18L
A-5MM33-2720S	M27X2.0	20S
A-5MM33-2722L	M27X2.0	22L
A-5MM33-3325S	M33X2.0	25S
A-5MM33-3328L	M33X2.0	28L
A-5MM33-4230S	M42X2.0	30S
A-5MM33-4235L	M42X2.0	35L
A-5MM33-4838S	M48X2.0	38S
A-5MM33-4842L	M48X2.0	42L



Metric Elastomer Male x DIN Male Banjo

Part Number	METRIC M(T1)	DIN M(T2)
A-6MM91-1006L	M10X1.0	06L
A-6MM91-1006LL	M10X1.0	06LL
A-6MM91-1008LL	M10X1.0	08LL
A-6MM91-1206S	M12X1.5	06S
A-6MM91-1208L	M12X1.5	08L
A-6MM91-1408S	M14X1.5	08S
A-6MM91-1410L	M14X1.5	10L
A-6MM91-1610S	M16X1.5	10S
A-6MM91-1612L	M16X1.5	12L
A-6MM91-1812S	M18X1.5	12S
A-6MM91-1815L	M18X1.5	15L
A-6MM91-2014S	M20X1.5	14S
A-6MM91-2216S	M22X1.5	16S
A-6MM91-2218L	M22X1.5	18L
A-6MM91-2622L	M26X1.5	22L
A-6MM91-2720S	M27X2.0	20S
A-6MM91-3325S	M33X2.0	25S
A-6MM91-3328L	M33X2.0	28L
A-6MM91-4230S	M42X2.0	30S
A-6MM91-4235L	M42X2.0	35L
A-6MM91-4838S	M48X2.0	38S
A-6MM91-4842L	M48X2.0	42L



DIN Male x NPT Male 90°

Part Number	DIN M(T1)	NPT M(T2)
A-MP18-04LL02	04LL	-02
A-MP18-05LL02	05LL	-02
A-MP18-06LL02	06LL	-02
A-MP18-08LL02	08LL	-02
A-MP18-10LL04	10LL	-04
A-MP18-12LL06	12LL	-06
A-MP18-06L02	06L	-02
A-MP18-06L04	06L	-04
A-MP18-06S02	06S	-02
A-MP18-06S04	06S	-04
A-MP18-08L02	08L	-02
A-MP18-08L04	08L	-04
A-MP18-08S04	08S	-04
A-MP18-10L04	10L	-04
A-MP18-10S06	10S	-06
A-MP18-12L04	12L	-04
A-MP18-12L06	12L	-06
A-MP18-12S06	12S	-06
A-MP18-14S08	14S	-08
A-MP18-15L06	15L	-06
A-MP18-15L08	15L	-08
A-MP18-16S08	16S	-08
A-MP18-18L08	18L	-08
A-MP18-20S12	20S	-12
A-MP18-22L12	22L	-12
A-MP18-25S16	25S	-16
A-MP18-28L16	28L	-16
A-MP18-30S16	30S	-16
A-MP18-30S20	30S	-20
A-MP18-35L20	35L	-20
A-MP18-38S24	38S	-24
A-MP18-42L24	42L	-24



Metric O-Ring Male x ORFS Male 90°

Part Number	METRIC M(T1)	ORFS M(T2)
A-5MF33-1004	M10X1.0	-04
A-5MF33-1006	M10X1.0	-06
A-5MF33-1204	M12X1.5	-04
A-5MF33-1206	M12X1.5	-06
A-5MF33-1404	M14X1.5	-04
A-5MF33-1406	M14X1.5	-06
A-5MF33-1408	M14X1.5	-08
A-5MF33-1606	M16X1.5	-06
A-5MF33-1608	M16X1.5	-08
A-5MF33-1806	M18X1.5	-06
A-5MF33-1808	M18X1.5	-08
A-5MF33-1810	M18X1.5	-10
A-5MF33-2008	M20X1.5	-08
A-5MF33-2208	M22X1.5	-08
A-5MF33-2210	M22X1.5	-10
A-5MF33-2212	M22X1.5	-12
A-5MF33-2416	M24X1.5	-16
A-5MF33-2710	M27X2.0	-10
A-5MF33-2712	M27X2.0	-12
A-5MF33-2716	M27X2.0	-16
A-5MF33-3008	M30X2.0	-08
A-5MF33-3312	M33X2.0	-12
A-5MF33-3316	M33X2.0	-16
A-5MF33-3320	M33X2.0	-20
A-5MF33-4220	M42X2.0	-20
A-5MF33-4820	M48X2.0	-20
A-5MF33-4824	M48X2.0	-24

Metric O-Ring Male x JIC Male 90°

Part Number	METRIC M(T1)	JIC M(T2)
A-5MJ33-1004	M10X1.0	-04
A-5MJ33-1005	M10X1.0	-05
A-5MJ33-1204	M12X1.5	-04
A-5MJ33-1205	M12X1.5	-05
A-5MJ33-1206	M12X1.5	-06
A-5MJ33-1208	M12X1.5	-08
A-5MJ33-1404	M14X1.5	-04
A-5MJ33-1405	M14X1.5	-05
A-5MJ33-1406	M14X1.5	-06
A-5MJ33-1408	M14X1.5	-08
A-5MJ33-1606	M16X1.5	-06
A-5MJ33-1608	M16X1.5	-08
A-5MJ33-1806	M18X1.5	-06
A-5MJ33-1808	M18X1.5	-08
A-5MJ33-1810	M18X1.5	-10
A-5MJ33-2008	M20X1.5	-08
A-5MJ33-2010	M20X1.5	-10
A-5MJ33-2208	M22X1.5	-08
A-5MJ33-2210	M22X1.5	-10
A-5MJ33-2212	M22X1.5	-12
A-5MJ33-2612	M26X1.5	-12
A-5MJ33-2712	M27X2.0	-12
A-5MJ33-2716	M27X2.0	-16
A-5MJ33-3316	M33X2.0	-16
A-5MJ33-4220	M42X2.0	-20
A-5MJ33-4824	M48X2.0	-24

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

DIN/METRIC

ADAPTERS



DIN Male x DIN Female 90°		
Part Number	DIN M(T1)	DIN F(T2)
A-M24-06L06L	06L	06L
A-M24-06S06S	06S	06S
A-M24-08L08L	08L	08L
A-M24-08S08S	08S	08S
A-M24-10L10L	10L	10L
A-M24-10S10S	10S	10S
A-M24-12L12L	12L	12L
A-M24-12S12S	12S	12S
A-M24-14S14S	14S	14S
A-M24-15L15L	15L	15L
A-M24-16S16S	16S	16S
A-M24-18L18L	18L	18L
A-M24-20S20S	20S	20S
A-M24-22L22L	22L	22L
A-M24-25S25S	25S	25S
A-M24-28L28L	28L	28L
A-M24-30S30S	30S	30S
A-M24-35L35L	35L	35L
A-M24-38S38S	38S	38S
A-M24-42L42L	42L	42L

DIN Female x JIC Male 90°		
Part Number	DIN F(T1)	JIC M(T2)
A-MJ63-06L04	06L	-04
A-MJ63-06S04	06S	-04
A-MJ63-08L06	08L	-06
A-MJ63-08S06	08S	-06
A-MJ63-10L06	10L	-06
A-MJ63-10S06	10S	-06
A-MJ63-12L08	12L	-08
A-MJ63-12S08	12S	-08
A-MJ63-15L10	15L	-10
A-MJ63-16S10	16S	-10
A-MJ63-18L12	18L	-12
A-MJ63-20S12	20S	-12
A-MJ63-22L16	22L	-16
A-MJ63-25S16	25S	-16
A-MJ63-28L16	28L	-16
A-MJ63-30S20	30S	-20
A-MJ63-35L20	35L	-20
A-MJ63-42L24	42L	-24

ADAPTERS

DIN/METRIC



DIN Bulkhead x DIN Male		
Part Number	DIN M(T1)	DIN M(T2)
A-M40LN-06L06L	06L	06L
A-M40LN-06S06S	06S	06S
A-M40LN-08L08L	08L	08L
A-M40LN-08S08S	08S	08S
A-M40LN-10L10L	10L	10L
A-M40LN-10S10S	10S	10S
A-M40LN-12L12L	12L	12L
A-M40LN-12S12S	12S	12S
A-M40LN-14S14S	14S	14S
A-M40LN-15L15L	15L	15L
A-M40LN-16S16S	16S	16S
A-M40LN-18L18L	18L	18L
A-M40LN-20S20S	20S	20S
A-M40LN-22L22L	22L	22L
A-M40LN-25S25S	25S	25S
A-M40LN-28L28L	28L	28L
A-M40LN-30S30S	30S	30S
A-M40LN-35L35L	35L	35L
A-M40LN-38S38S	38S	38S
A-M40LN-42L42L	42L	42L

DIN Bulkhead x DIN Male 90°		
Part Number	DIN M(T1)	DIN M(T2)
A-M48LN-06L06L	06L	06L
A-M48LN-06S06S	06S	06S
A-M48LN-08L08L	08L	08L
A-M48LN-08S08S	08S	08S
A-M48LN-10L10L	10L	10L
A-M48LN-10S10S	10S	10S
A-M48LN-12L12L	12L	12L
A-M48LN-12S12S	12S	12S
A-M48LN-14S14S	14S	14S
A-M48LN-15L15L	15L	15L
A-M48LN-16S16S	16S	16S
A-M48LN-18L18L	18L	18L
A-M48LN-20S20S	20S	20S
A-M48LN-22L22L	22L	22L
A-M48LN-25S25S	25S	25S
A-M48LN-28L28L	28L	28L
A-M48LN-30S30S	30S	30S
A-M48LN-35L35L	35L	35L
A-M48LN-38S38S	38S	38S
A-M48LN-42L42L	42L	42L



DIN Bulkhead Locknut	
Part Number	Thread Size
A-M4-12	06L
A-M4-14	08L and 06S
A-M4-16	10L and 08S
A-M4-18	12L and 10S
A-M4-20	12S
A-M4-22	14S and 15L
A-M4-24	16S
A-M4-26	18L
A-M4-30	20S and 22L
A-M4-36	25S and 28L
A-M4-42	30S
A-M4-45	35L
A-M4-52	38S and 42L



DIN Male x DIN Male Branch Tee

Part Number	DIN M(T1)	DIN M(T2)
A-M5-18-04LL04LL	04LL	04LL
A-M5-18-06LL06LL	06LL	06LL
A-M5-18-08LL08LL	08LL	08LL
A-M5-18-10LL10LL	10LL	10LL
A-M5-18-06L06L	06L	06L
A-M5-18-06S06S	06S	06S
A-M5-18-08L08L	08L	08L
A-M5-18-08S08S	08S	08S
A-M5-18-10L10L	10L	10L
A-M5-18-10S10S	10S	10S
A-M5-18-12L12L	12L	12L
A-M5-18-12S12S	12S	12S
A-M5-18-14S14S	14S	14S
A-M5-18-15L15L	15L	15L
A-M5-18-16S16S	16S	16S
A-M5-18-18L18L	18L	18L
A-M5-18-20S16S	20S	16S
A-M5-18-20S20S	20S	20S
A-M5-18-22L22L	22L	22L
A-M5-18-25S25S	25S	25S
A-M5-18-28L28L	28L	28L
A-M5-18-30S30S	30S	30S
A-M5-18-35L35L	35L	35L
A-M5-18-38S38S	38S	38S
A-M5-18-42L42L	42L	42L



DIN Female x DIN Male Branch Tee

Part Number	DIN F(T1)	DIN M(T2)
A-M5-63-06L06L	06L	06L
A-M5-63-06S06S	06S	06S
A-M5-63-08L08L	08L	08L
A-M5-63-08S08S	08S	08S
A-M5-63-10L10L	10L	10L
A-M5-63-10S10S	10S	10S
A-M5-63-12L12L	12L	12L
A-M5-63-12S12S	12S	12S
A-M5-63-14S14S	14S	14S
A-M5-63-15L15L	15L	15L
A-M5-63-16S16S	16S	16S
A-M5-63-18L18L	18L	18L
A-M5-63-20S20S	20S	20S
A-M5-63-22L22L	22L	22L
A-M5-63-25S25S	25S	25S
A-M5-63-28L28L	28L	28L
A-M5-63-30S30S	30S	30S
A-M5-63-35L35L	35L	35L
A-M5-63-38S38S	38S	38S
A-M5-63-42L42L	42L	42L

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

DIN/METRIC

ADAPTERS



Metric O-Ring Male x ORFS Male Branch Tee

Part Number	METRIC M(T1)	ORFS M(T2)
A-5MF5-33-1004	M10X1.0	-04
A-5MF5-33-1204	M12X1.5	-04
A-5MF5-33-1404	M14X1.5	-04
A-5MF5-33-1406	M14X1.5	-06
A-5MF5-33-1408	M14X1.5	-08
A-5MF5-33-1606	M16X1.5	-06
A-5MF5-33-1608	M16X1.5	-08
A-5MF5-33-1806	M18X1.5	-06
A-5MF5-33-1808	M18X1.5	-08
A-5MF5-33-1810	M18X1.5	-10
A-5MF5-33-2208	M22X1.5	-08
A-5MF5-33-2210	M22X1.5	-10
A-5MF5-33-2712	M27X2.0	-12
A-5MF5-33-3316	M33X2.0	-16
A-5MF5-33-4220	M42X2.0	-20
A-5MF5-33-4824	M48X2.0	-24



Metric O-Ring Male x JIC Male Branch Tee

Part Number	METRIC M(T1)	JIC M(T2)
A-5MJ5-33-1004	M10X1.0	-04
A-5MJ5-33-1204	M12X1.5	-04
A-5MJ5-33-1406	M14X1.5	-06
A-5MJ5-33-1608	M16X1.5	-08
A-5MJ5-33-1808	M18X1.5	-08
A-5MJ5-33-2210	M22X1.5	-10
A-5MJ5-33-2712	M27X1.5	-12
A-5MJ5-33-3316	M33X1.5	-16

ADAPTERS

DIN/METRIC

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

DIN/METRIC

ADAPTERS



DIN Female x DIN Male Run Tee		
Part Number	DIN F(T1)	DIN M(T2)
A-M6-63-06L06L	06L	06L
A-M6-63-06S06S	06S	06S
A-M6-63-08L08L	08L	08L
A-M6-63-08S08S	08S	08S
A-M6-63-10L10L	10L	10L
A-M6-63-10S10S	10S	10S
A-M6-63-12L12L	12L	12L
A-M6-63-12S12S	12S	12S
A-M6-63-14S14S	14S	14S
A-M6-63-15L15L	15L	15L
A-M6-63-16S16S	16S	16S
A-M6-63-18L18L	18L	18L
A-M6-63-20S20S	20S	20S
A-M6-63-22L22L	22L	22L
A-M6-63-25S25S	25S	25S
A-M6-63-28L28L	28L	28L
A-M6-63-30S30S	30S	30S
A-M6-63-35L35L	35L	35L
A-M6-63-38S38S	38S	38S
A-M6-63-42L42L	42L	42L

Metric O-Ring Male x ORFS Male Run Tee		
Part Number	METRIC M(T1)	ORFS M(T2)
A-5MF6-33-1004	M10X1.0	-04
A-5MF6-33-1204	M12X1.5	-04
A-5MF6-33-1404	M14X1.5	-04
A-5MF6-33-1406	M14X1.5	-06
A-5MF6-33-1408	M14X1.5	-08
A-5MF6-33-1506	M15X1.5	-06
A-5MF6-33-1606	M16X1.5	-06
A-5MF6-33-1608	M16X1.5	-08
A-5MF6-33-1808	M18X1.5	-08
A-5MF6-33-1810	M18X1.5	-10
A-5MF6-33-2208	M22X1.5	-08
A-5MF6-33-2210	M22X1.5	-10
A-5MF6-33-2712	M27X2.0	-12
A-5MF6-33-3316	M33X2.0	-16
A-5MF6-33-4220	M42X2.0	-20
A-5MF6-33-4824	M48X2.0	-24

ADAPTERS

DIN/METRIC

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

DIN/METRIC

ADAPTERS



Metric O-Ring Male x JIC Male Run Tee		
Part Number	METRIC M(T1)	JIC M(T2)
A-5MJ6-33-1004	M10X1.5	-04
A-5MJ6-33-1204	M12X1.5	-04
A-5MJ6-33-1406	M14X1.5	-06
A-5MJ6-33-1608	M16X1.5	-08
A-5MJ6-33-1808	M18X1.5	-08
A-5MJ6-33-2210	M22X1.5	-10
A-5MJ6-33-2712	M27X2.0	-12
A-5MJ6-33-3316	M33X2.0	-16



DIN Male Cross		
Part Number	DIN M(T1)	DIN M(T2)
A-M7-18-06L06L	06L	06L
A-M7-18-06S06S	06S	06S
A-M7-18-08L08L	08L	08L
A-M7-18-08S08S	08S	08S
A-M7-18-10L10L	10L	10L
A-M7-18-10S10S	10S	10S
A-M7-18-12L12L	12L	12L
A-M7-18-12S12S	12S	12S
A-M7-18-14S14S	14S	14S
A-M7-18-15L15L	15L	15L
A-M7-18-16S16S	16S	16S
A-M7-18-18L18L	18L	18L
A-M7-18-20S20S	20S	20S
A-M7-18-22L22L	22L	22L
A-M7-18-25S25S	25S	25S
A-M7-18-28L28L	28L	28L
A-M7-18-30S30S	30S	30S
A-M7-18-35L35L	35L	35L
A-M7-18-38S38S	38S	38S
A-M7-18-42L42L	42L	42L

ADAPTERS

DIN/METRIC



Metric Standpipe x JIC Male		
Part Number	STANDPIPE(T1)	JIC M(T2)
A-MJ90-0403	04MM	-03
A-MJ90-0404	04MM	-04
A-MJ90-0604	06MM	-04
A-MJ90-0804	08MM	-04
A-MJ90-0806	08MM	-06
A-MJ90-1004	10MM	-04
A-MJ90-1006	10MM	-06
A-MJ90-1008	10MM	-08
A-MJ90-1205	12MM	-05
A-MJ90-1206	12MM	-06
A-MJ90-1208	12MM	-08
A-MJ90-1406	14MM	-06
A-MJ90-1408	14MM	-08
A-MJ90-1508	15MM	-08
A-MJ90-1608	16MM	-08
A-MJ90-1610	16MM	-10
A-MJ90-1612	16MM	-12
A-MJ90-1810	18MM	-10
A-MJ90-1812	18MM	-12
A-MJ90-2010	20MM	-10
A-MJ90-2012	20MM	-12
A-MJ90-2016	20MM	-16
A-MJ90-2212	22MM	-12
A-MJ90-2512	25MM	-12
A-MJ90-2516	25MM	-16
A-MJ90-2816	28MM	-16
A-MJ90-2820	28MM	-20
A-MJ90-3016	30MM	-16
A-MJ90-3520	35MM	-20
A-MJ90-3524	35MM	-24
A-MJ90-3820	38MM	-20
A-MJ90-3824	38MM	-24
A-MJ90-4224	42MM	-24



Metric Standpipe x NPT Male		
Part Number	STANDPIPE(T1)	NPT M(T2)
A-MP90-0602	06MM	-02
A-MP90-0804	08MM	-04
A-MP90-1004	10MM	-04
A-MP90-1206	12MM	-06



Metric Banjo x JIC Male		
Part Number	BANJO(T1)	JIC M(T2)
A-MJ91-0804	8MM	-04
A-MJ91-1004	10MM	-04
A-MJ91-1204	12MM	-04
A-MJ91-1206	12MM	-06
A-MJ91-1406	14MM	-06
A-MJ91-1606	16MM	-06
A-MJ91-1808	18MM	-08
A-MJ91-2008	20MM	-08
A-MJ91-2210	22MM	-10
A-MJ91-2410	24MM	-10
A-MJ91-2612	26MM	-12



Komatsu Hex Plug

Part Number	Komatsu M
A-K1-14	14MM
A-K1-16	16MM
A-K1-18	18MM
A-K1-22	22MM
A-K1-24	24MM
A-K1-30	30MM
A-K1-33	33MM
A-K1-36	36MM
A-K1-42	42MM
A-K1-45	45MM



Komatsu Cap

Part Number	Komatsu F
A-K3-14	14MM
A-K3-16	16MM
A-K3-18	18MM
A-K3-22	22MM
A-K3-24	24MM
A-K3-30	30MM
A-K3-33	33MM
A-K3-36	36MM
A-K3-42	42MM
A-K3-45	45MM



Komatsu Male x Komatsu Male

Part Number	Komatsu M(T1)	Komatsu M(T2)
A-K10-1010	10MM	10MM
A-K10-1212	12MM	12MM
A-K10-1414	14MM	14MM
A-K10-1616	16MM	16MM
A-K10-1818	18MM	18MM
A-K10-2222	22MM	22MM
A-K10-2424	24MM	24MM
A-K10-3030	30MM	30MM
A-K10-3333	33MM	33MM



Komatsu Male x JIC Male

Part Number	Komatsu M(T1)	JIC M(T2)
A-KJ10-1404	14MM	-04
A-KJ10-1606	16MM	-06
A-KJ10-1806	18MM	-06
A-KJ10-2208	22MM	-08
A-KJ10-2410	24MM	-10
A-KJ10-3010	30MM	-10
A-KJ10-3012	30MM	-12
A-KJ10-3316	33MM	-16



Komatsu Female x JIC Male		
Part Number	Komatsu F(T1)	JIC M(T2)
A-KJ55-1204	12MM	-04
A-KJ55-1404	14MM	-04
A-KJ55-1606	16MM	-06
A-KJ55-1806	18MM	-06
A-KJ55-2208	22MM	-08
A-KJ55-2410	24MM	-10
A-KJ55-3012	30MM	-12
A-KJ55-3316	33MM	-16



Komatsu Female x Komatsu Female		
Part Number	Komatsu F(T1)	Komatsu F(T2)
A-K67-1414	14MM	14MM
A-K67-1818	18MM	18MM
A-K67-2222	22MM	22MM
A-K67-2424	24MM	24MM
A-K67-3030	30MM	30MM
A-K67-3333	33MM	33MM



Komatsu Female x JIC Male		
Part Number	Komatsu F(T1)	JIC M(T2)
A-KJ67-1404	14MM	-04
A-KJ67-1806	18MM	-06
A-KJ67-2208	22MM	-08
A-KJ67-2410	24MM	-10
A-KJ67-3012	30MM	-12



Komatsu Male x Komatsu Female 90°		
Part Number	Komatsu M(T1)	Komatsu F(T2)
A-K24-1414	14MM	14MM
A-K24-1616	16MM	16MM
A-K24-1818	18MM	18MM
A-K24-2222	22MM	22MM
A-K24-2424	24MM	24MM
A-K24-3030	30MM	30MM
A-K24-3333	33MM	33MM



Komatsu Female x Male Run Tee		
Part Number	Komatsu F(T1)	Komatsu M(T2)
A-K6-63-1414	14MM	14MM
A-K6-63-1616	16MM	16MM
A-K6-63-1818	18MM	18MM
A-K6-63-2222	22MM	22MM
A-K6-63-2424	24MM	24MM
A-K6-63-3030	30MM	30MM
A-K6-63-3333	33MM	33MM

JIS

ADAPTERS

ADAPTERS

JIS



JIS Hex Plug

Part Number	JIS M
A-8B1-02	-02
A-8B1-04	-04
A-8B1-06	-06
A-8B1-08	-08
A-8B1-10	-10
A-8B1-12	-12
A-8B1-16	-16
A-8B1-20	-20
A-8B1-24	-24
A-8B1-32	-32



JIS Cap

Part Number	JIS F
A-8B3-02	-02
A-8B3-04	-04
A-8B3-06	-06
A-8B3-08	-08
A-8B3-10	-10
A-8B3-12	-12
A-8B3-16	-16
A-8B3-20	-20
A-8B3-24	-24
A-8B3-32	-32



JIS Male x JIS Male

Part Number	JIS M(T1)	JIS M(T2)
A-8B10-0202	-02	-02
A-8B10-0404	-04	-04
A-8B10-0606	-06	-06
A-8B10-0808	-08	-08
A-8B10-1212	-12	-12
A-8B10-1616	-16	-16
A-8B10-2020	-20	-20
A-8B10-2424	-24	-24
A-8B10-3232	-32	-32



JIS Male x JIC Male

Part Number	JIS M(T1)	JIC M(T2)
A-8BJ10-0204	-02	-04
A-8BJ10-0404	-04	-04
A-8BJ10-0606	-06	-06
A-8BJ10-0808	-08	-08
A-8BJ10-1212	-12	-12
A-8BJ10-1616	-16	-16
A-8BJ10-2020	-20	-20
A-8BJ10-2424	-24	-24

JIS

ADAPTERS



JIS Female x JIC Male		
Part Number	JIS F(T1)	JIC M(T2)
A-8BJ55-0204	-02	-04
A-8BJ55-0404	-04	-04
A-8BJ55-0406	-04	-06
A-8BJ55-0604	-06	-04
A-8BJ55-0606	-06	-06
A-8BJ55-0608	-06	-08
A-8BJ55-0808	-08	-08
A-8BJ55-1010	-10	-10
A-8BJ55-1212	-12	-12
A-8BJ55-1616	-16	-16
A-8BJ55-2020	-20	-20
A-8BJ55-2424	-24	-24
A-8BJ55-3232	-32	-32



JIS Female x JIS Female		
Part Number	JIS F(T1)	JIS F(T2)
A-8B67-0606	-06	-06
A-8B67-0808	-08	-08
A-8B67-1212	-12	-12



JIS Female x JIC Female		
Part Number	JIS F(T1)	JIC F(T2)
A-8BJ67-0404	-04	-04
A-8BJ67-0606	-06	-06
A-8BJ67-0808	-08	-08



JIS Male x JIS Female 90°		
Part Number	JIS M(T1)	JIS F(T2)
A-8B24-0404	-04	-04
A-8B24-0606	-06	-06
A-8B24-0808	-08	-08
A-8B24-1212	-12	-12

ADAPTERS

JIS



JIS Female x JIS Male Run Tee

Part Number	JIS F(T1)	JIS M(T2)
A-8B6-63-0202	-02	-02
A-8B6-63-0404	-04	-04
A-8B6-63-0606	-06	-06
A-8B6-63-0808	-08	-08
A-8B6-63-1212	-12	-12
A-8B6-63-1616	-16	-16
A-8B6-63-2020	-20	-20
A-8B6-63-2424	-24	-24



BSP To JIS Seat Converter

Part Number	BSP M	JIS M
A-8B9-02	-02	-02
A-8B9-04	-04	-04
A-8B9-06	-06	-06
A-8B9-08	-08	-08
A-8B9-10	-10	-10
A-8B9-12	-12	-12
A-8B9-16	-16	-16
A-8B9-20	-20	-20
A-8B9-24	-24	-24

FLANGES

ADAPTERS

ADAPTERS

FLANGES



Code 61 Plug

Part Number	CODE 61 M
A-S1-08	-08
A-S1-12	-12
A-S1-16	-16
A-S1-20	-20
A-S1-24	-24
A-S1-32	-32
A-S1-40	-40
A-S1-48	-48
A-S1-56	-56
A-S1-64	-64



Code 62 Plug

Part Number	CODE 62 M
A-2S1-08	-08
A-2S1-12	-12
A-2S1-16	-16
A-2S1-20	-20
A-2S1-24	-24
A-2S1-32	-32



CAT Flange Plug

Part Number	CAT M
A-CS1-12	-12
A-CS1-16	-16
A-CS1-20	-20
A-CS1-24	-24
A-CS1-32	-32

FLANGES

ADAPTERS

ADAPTERS

FLANGES



Code 61 Cap

Part Number	CODE 61 F
A-S3-08	-08
A-S3-12	-12
A-S3-16	-16
A-S3-20	-20
A-S3-24	-24
A-S3-32	-32
A-S3-48	-48



Code 62 Cap

Part Number	CODE 62 F
A-2S3-08	-08
A-2S3-12	-12
A-2S3-16	-16
A-2S3-20	-20
A-2S3-24	-24
A-2S3-32	-32



Code 61 Shipping Plate

Part Number	CODE 61 M
A-SP-08	-08
A-SP-12	-12
A-SP-16	-16
A-SP-20	-20
A-SP-24	-24
A-SP-32	-32
A-SP-40	-40



Code 62 Shipping Plate

Part Number	CODE 61 M
A-2SP-12	-12
A-2SP-16	-16
A-2SP-20	-20
A-2SP-24	-24
A-2SP-32	-32

FLANGES

ADAPTERS

ADAPTERS

FLANGES



Code 61 Clamp Kit

Part Number	CODE 61
A-SFK-08	-08
A-SFK-12	-12
A-SFK-16	-16
A-SFK-20	-20
A-SFK-24	-24
A-SFK-32	-32
A-SFK-40	-40
A-SFK-48	-48
A-SFK-56	-56
A-SFK-64	-64



Code 62 Clamp Kit

Part Number	CODE 62
A-2SFK-08	-08
A-2SFK-12	-12
A-2SFK-16	-16
A-2SFK-20	-20
A-2SFK-24	-24
A-2SFK-32	-32



CAT Flange Clamp Kit

Part Number	CAT
A-CSFK-12	-12
A-CSFK-16	-16
A-CSFK-20	-20
A-CSFK-24	-24
A-CSFK-32	-32

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

FLANGES

ADAPTERS



Code 61 Male x ORFS Male		
Part Number	CODE 61 M(T1)	ORFS M(T2)
A-SF10-1212	-12	-12
A-SF10-1216	-12	-16
A-SF10-1612	-16	-12
A-SF10-1616	-16	-16
A-SF10-1620	-16	-20
A-SF10-2016	-20	-16
A-SF10-2020	-20	-20
A-SF10-2024	-20	-24
A-SF10-2416	-24	-16
A-SF10-2420	-24	-20
A-SF10-2424	-24	-24
A-SF10-3224	-32	-24



Code 62 Male x ORFS Male		
Part Number	CODE 62 M(T1)	ORFS M(T2)
A-2SF10-0808	-08	-08
A-2SF10-1212	-12	-12
A-2SF10-1216	-12	-16
A-2SF10-1612	-16	-12
A-2SF10-1616	-16	-16
A-2SF10-1620	-16	-20
A-2SF10-2016	-20	-16
A-2SF10-2020	-20	-20
A-2SF10-2024	-20	-24
A-2SF10-2420	-24	-20
A-2SF10-2424	-24	-24

ADAPTERS

FLANGES



Code 61 Male x JIC Male

Part Number	CODE 61 M(T1)	JIC M(T2)
A-SJ10-0808	-08	-08
A-SJ10-1208	-12	-08
A-SJ10-1212	-12	-12
A-SJ10-1214	-12	-14
A-SJ10-1216	-12	-16
A-SJ10-1610	-16	-10
A-SJ10-1612	-16	-12
A-SJ10-1616	-16	-16
A-SJ10-1620	-16	-20
A-SJ10-1624	-16	-24
A-SJ10-2012	-20	-12
A-SJ10-2016	-20	-16
A-SJ10-2020	-20	-20
A-SJ10-2024	-20	-24
A-SJ10-2412	-24	-12
A-SJ10-2416	-24	-16
A-SJ10-2420	-24	-20
A-SJ10-2424	-24	-24
A-SJ10-2432	-24	-32
A-SJ10-3214	-32	-14
A-SJ10-3216	-32	-16
A-SJ10-3220	-32	-20
A-SJ10-3224	-32	-24
A-SJ10-3232	-32	-32
A-SJ10-4032	-40	-32

Code 62 Male x JIC Male

Part Number	CODE 62 M(T1)	JIC M(T2)
A-2SJ10-0808	-08	-08
A-2SJ10-1212	-12	-12
A-2SJ10-1216	-12	-16
A-2SJ10-1612	-16	-12
A-2SJ10-1616	-16	-16
A-2SJ10-1620	-16	-20
A-2SJ10-2016	-20	-16
A-2SJ10-2020	-20	-20
A-2SJ10-2024	-20	-24
A-2SJ10-2416	-24	-16
A-2SJ10-2420	-24	-20
A-2SJ10-2424	-24	-24
A-2SJ10-2432	-24	-32
A-2SJ10-3224	-32	-24
A-2SJ10-3232	-32	-32

FLANGES

ADAPTERS

ADAPTERS

FLANGES



Code 61 Male x NPT Female		
Part Number	CODE 61 M(T1)	NPT F(T2)
A-SP22-0808	-08	-08
A-SP22-1212	-12	-12
A-SP22-1616	-16	-16
A-SP22-2020	-20	-20
A-SP22-2424	-24	-24
A-SP22-3232	-32	-32
A-SP22-4040	-40	-40
A-SP22-4848	-48	-48



Code 62 Male x NPT Female		
Part Number	CODE 62 M(T1)	NPT F(T2)
A-2SP22-0808	-08	-08
A-2SP22-1212	-12	-12
A-2SP22-1616	-16	-16
A-2SP22-2020	-20	-20
A-2SP22-2424	-24	-24
A-2SP22-3232	-32	-32



Code 61 Male x ORB Female		
Part Number	CODE 61 M(T1)	ORB F(T2)
A-SR22-0808	-08	-08
A-SR22-1212	-12	-12
A-SR22-1616	-16	-16
A-SR22-2020	-20	-20
A-SR22-2424	-24	-24
A-SR22-3232	-32	-32



Code 62 Male x ORB Female		
Part Number	CODE 62 M(T1)	ORB F(T2)
A-2SR22-1212	-12	-12
A-2SR22-1616	-16	-16
A-2SR22-2020	-20	-20
A-2SR22-2424	-24	-24
A-2SR22-3232	-32	-32

FLANGES

ADAPTERS

ADAPTERS

FLANGES



Code 61 Female x NPT Female		
Part Number	CODE 61 F(T1)	NPT F(T2)
A-SP67-1212	-12	-12
A-SP67-1616	-16	-16
A-SP67-2020	-20	-20
A-SP67-2424	-24	-24
A-SP67-3232	-32	-32



Code 62 Female x NPT Female		
Part Number	CODE 62 F(T1)	NPT F(T2)
A-2SP67-1212	-12	-12
A-2SP67-1616	-16	-16
A-2SP67-2020	-20	-20
A-2SP67-2424	-24	-24
A-2SP67-3232	-32	-32



Code 61 Female x ORB Female		
Part Number	CODE 61 F(T1)	ORB F(T2)
A-SR67-1212	-12	-12
A-SR67-1616	-16	-16
A-SR67-2020	-20	-20
A-SR67-2424	-24	-24
A-SR67-3232	-32	-32



Code 62 Female x ORB Female		
Part Number	CODE 62 F(T1)	ORB F(T2)
A-2SR67-1212	-12	-12
A-2SR67-1616	-16	-16
A-2SR67-2020	-20	-20
A-2SR67-2424	-24	-24
A-2SR67-3232	-32	-32



Code 61 Male x ORFS Male 45°		
Part Number	CODE 61 M(T1)	ORFS M(T2)
A-SF14-1212	-12	-12
A-SF14-1616	-16	-16
A-SF14-2020	-20	-20
A-SF14-2424	-24	-24



Code 62 Male x ORFS Male 45°		
Part Number	CODE 62M(T1)	ORFS M(T2)
A-2SF14-1212	-12	-12
A-2SF14-1616	-16	-16
A-2SF14-2020	-20	-20
A-2SF14-2424	-24	-24



Code 61 Male x JIC Male 45°		
Part Number	CODE 61 M(T1)	JIC M(T2)
A-SJ14-0808	-08	-08
A-SJ14-1208	-12	-08
A-SJ14-1212	-12	-12
A-SJ14-1216	-12	-16
A-SJ14-1612	-16	-12
A-SJ14-1616	-16	-16
A-SJ14-1620	-16	-20
A-SJ14-2012	-20	-12
A-SJ14-2020	-20	-20
A-SJ14-2424	-24	-24
A-SJ14-3232	-32	-32



Code 61 Male x JIC Male 45° Tube		
Part Number	CODE 61 M(T1)	JIC M(T2)
A-SJ14-0808-T	-08	-08
A-SJ14-1208-T	-12	-08
A-SJ14-1212-T	-12	-12
A-SJ14-1216-T	-12	-16
A-SJ14-1220-T	-12	-20
A-SJ14-1610-T	-16	-10
A-SJ14-1612-T	-16	-12
A-SJ14-1616-T	-16	-16
A-SJ14-1620-T	-16	-20
A-SJ14-2012-T	-20	-12
A-SJ14-2016-T	-20	-16
A-SJ14-2020-T	-20	-20
A-SJ14-2024-T	-20	-24
A-SJ14-2416-T	-24	-16
A-SJ14-2420-T	-24	-20
A-SJ14-2424-T	-24	-24
A-SJ14-2432-T	-24	-32
A-SJ14-3224-T	-32	-24
A-SJ14-3232-T	-32	-32
A-SJ14-4024-T	-40	-24
A-SJ14-4040-T	-40	-40



Code 62 Male x JIC Male 45°		
Part Number	CODE 62 M(T1)	JIC M(T2)
A-2SJ14-1212	-12	-12
A-2SJ14-1216	-12	-16
A-2SJ14-1612	-16	-12
A-2SJ14-1616	-16	-16
A-2SJ14-1620	-16	-20
A-2SJ14-2016	-20	-16
A-2SJ14-2020	-20	-20
A-2SJ14-2024	-20	-24
A-2SJ14-2416	-24	-16
A-2SJ14-2420	-24	-20
A-2SJ14-2424	-24	-24
A-2SJ14-3232	-32	-32



Code 62 Male x JIC Male 45° Tube		
Part Number	CODE 62 M(T1)	JIC M(T2)
A-2SJ14-0808-T	-08	-08
A-2SJ14-1212-T	-12	-12
A-2SJ14-1216-T	-12	-16
A-2SJ14-1220-T	-12	-20
A-2SJ14-1612-T	-16	-12
A-2SJ14-1616-T	-16	-16
A-2SJ14-1620-T	-16	-20
A-2SJ14-2012-T	-20	-12
A-2SJ14-2016-T	-20	-16
A-2SJ14-2020-T	-20	-20
A-2SJ14-2024-T	-20	-24
A-2SJ14-2416-T	-24	-16
A-2SJ14-2420-T	-24	-20
A-2SJ14-2424-T	-24	-24
A-2SJ14-3232-T	-32	-32



Code 61 Male x ORFS Male 90°		
Part Number	CODE 61 M(T1)	ORFS M(T2)
A-SF18-1212	-12	-12
A-SF18-1216	-12	-16
A-SF18-1612	-16	-12
A-SF18-1616	-16	-16
A-SF18-1620	-16	-20
A-SF18-2016	-20	-16
A-SF18-2020	-20	-20
A-SF18-2024	-20	-24
A-SF18-2420	-24	-20
A-SF18-2424	-24	-24
A-SF18-3224	-32	-24



Code 62 Male x ORFS Male 90°		
Part Number	CODE 62 M(T1)	ORFS M(T2)
A-2SF18-0812	-08	-12
A-2SF18-1212	-12	-12
A-2SF18-1216	-12	-16
A-2SF18-1612	-16	-12
A-2SF18-1616	-16	-16
A-2SF18-1620	-16	-20
A-2SF18-2016	-20	-16
A-2SF18-2020	-20	-20
A-2SF18-2024	-20	-24
A-2SF18-2420	-24	-20
A-2SF18-2424	-24	-24



Code 61 Male x JIC Male 90°		
Part Number	CODE 61 M(T1)	JIC M(T2)
A-SJ18-0808	-08	-08
A-SJ18-1208	-12	-08
A-SJ18-1212	-12	-12
A-SJ18-1216	-12	-16
A-SJ18-1612	-16	-12
A-SJ18-1616	-16	-16
A-SJ18-1620	-16	-20
A-SJ18-1624	-16	-24
A-SJ18-2012	-20	-12
A-SJ18-2016	-20	-16
A-SJ18-2020	-20	-20
A-SJ18-2024	-20	-24
A-SJ18-2412	-24	-12
A-SJ18-2416	-24	-16
A-SJ18-2420	-24	-20
A-SJ18-2424	-24	-24
A-SJ18-2432	-24	-32
A-SJ18-3224	-32	-24
A-SJ18-3232	-32	-32

Code 61 Male x JIC Male 90° Tube		
Part Number	CODE 61 M(T1)	JIC M(T2)
A-SJ18-0808-T	-08	-08
A-SJ18-1208-T	-12	-08
A-SJ18-1210-T	-12	-10
A-SJ18-1212-T	-12	-12
A-SJ18-1216-T	-12	-16
A-SJ18-1220-T	-12	-20
A-SJ18-1610-T	-16	-10
A-SJ18-1612-T	-16	-12
A-SJ18-1616-T	-16	-16
A-SJ18-1616-T	-16	-16
A-SJ18-1620-T	-16	-20
A-SJ18-1624-T	-16	-24
A-SJ18-2012-T	-20	-12
A-SJ18-2016-T	-20	-16
A-SJ18-2020-T	-20	-20
A-SJ18-2024-T	-20	-24
A-SJ18-2412-T	-24	-12
A-SJ18-2416-T	-24	-16
A-SJ18-2420-T	-24	-20
A-SJ18-2424-T	-24	-24
A-SJ18-2432-T	-24	-32
A-SJ18-3216-T	-32	-16
A-SJ18-3224-T	-32	-24
A-SJ18-3232-T	-32	-32
A-SJ18-4024-T	-40	-24
A-SJ18-4032-T	-40	-32
A-SJ18-4040-T	-40	-40



Code 62 Male x JIC Male 90°		
Part Number	CODE 62 M(T1)	JIC M(T2)
A-2SJ18-0808	-08	-08
A-2SJ18-1208	-12	-08
A-2SJ18-1212	-12	-12
A-2SJ18-1216	-12	-16
A-2SJ18-1612	-16	-12
A-2SJ18-1616	-16	-16
A-2SJ18-1620	-16	-20
A-2SJ18-1624	-16	-24
A-2SJ18-2012	-20	-12
A-2SJ18-2016	-20	-16
A-2SJ18-2020	-20	-20
A-2SJ18-2024	-20	-24
A-2SJ18-2416	-24	-16
A-2SJ18-2420	-24	-20
A-2SJ18-2424	-24	-24
A-2SJ18-2432	-24	-32
A-2SJ18-3224	-32	-24
A-2SJ18-3232	-32	-32

Code 62 Male x JIC Male 90° Tube		
Part Number	CODE 62 M(T1)	JIC M(T2)
A-2SJ18-0808-T	-08	-08
A-2SJ18-0812-T	-08	-12
A-2SJ18-1212-T	-12	-12
A-2SJ18-1216-T	-12	-16
A-2SJ18-1612-T	-16	-12
A-2SJ18-1616-T	-16	-16
A-2SJ18-1620-T	-16	-20
A-2SJ18-1624-T	-16	-24
A-2SJ18-2012-T	-20	-12
A-2SJ18-2016-T	-20	-16
A-2SJ18-2020-T	-20	-20
A-2SJ18-2024-T	-20	-24
A-2SJ18-2416-T	-24	-16
A-2SJ18-2420-T	-24	-20
A-2SJ18-2424-T	-24	-24
A-2SJ18-3224-T	-32	-24
A-2SJ18-3232-T	-32	-32

ORB

ADAPTERS



ORB Hex Plug

Part Number	ORB M
A-R1-02	-02
A-R1-03	-03
A-R1-04	-04
A-R1-05	-05
A-R1-06	-06
A-R1-08	-08
A-R1-10	-10
A-R1-12	-12
A-R1-14	-14
A-R1-16	-16
A-R1-20	-20
A-R1-24	-24
A-R1-32	-32
A-R1-40	-40



ORB Allen Plug

Part Number	ORB M
A-R2-02	-02
A-R2-03	-03
A-R2-04	-04
A-R2-05	-05
A-R2-06	-06
A-R2-08	-08
A-R2-10	-10
A-R2-12	-12
A-R2-14	-14
A-R2-16	-16
A-R2-20	-20
A-R2-24	-24
A-R2-32	-32



ORB Adjustable Male x ORB Male

Part Number	ORB M(T1)	ORB M(T2)
A-R25-0404	-04	-04
A-R25-0606	-06	-06
A-R25-0806	-08	-06
A-R25-0808	-08	-08
A-R25-1008	-10	-08
A-R25-1010	-10	-10
A-R25-1212	-12	-12
A-R25-1612	-16	-12
A-R25-1616	-16	-16
A-R25-2020	-20	-20
A-R25-2424	-24	-24
A-R25-3232	-32	-32

ADAPTERS

ORB



ORB Male x ORFS Male

Part Number	ORB M(T1)	ORFS M(T2)
A-RF10-0304	-03	-04
A-RF10-0306	-03	-06
A-RF10-0404	-04	-04
A-RF10-0406	-04	-06
A-RF10-0408	-04	-08
A-RF10-0504	-05	-04
A-RF10-0506	-05	-06
A-RF10-0604	-06	-04
A-RF10-0606	-06	-06
A-RF10-0608	-06	-08
A-RF10-0610	-06	-10
A-RF10-0612	-06	-12
A-RF10-0804	-08	-04
A-RF10-0806	-08	-06
A-RF10-0808	-08	-08
A-RF10-0810	-08	-10
A-RF10-0812	-08	-12
A-RF10-0816	-08	-16
A-RF10-1006	-10	-06
A-RF10-1008	-10	-08
A-RF10-1010	-10	-10
A-RF10-1012	-10	-12

CONTINUED

ORB Male x ORFS Male

Part Number	ORB M(T1)	ORFS M(T2)
A-RF10-1016	-10	-16
A-RF10-1206	-12	-06
A-RF10-1208	-12	-08
A-RF10-1210	-12	-10
A-RF10-1212	-12	-12
A-RF10-1216	-12	-16
A-RF10-1408	-14	-08
A-RF10-1410	-14	-10
A-RF10-1412	-14	-12
A-RF10-1416	-14	-16
A-RF10-1606	-16	-06
A-RF10-1608	-16	-08
A-RF10-1610	-16	-10
A-RF10-1612	-16	-12
A-RF10-1616	-16	-16
A-RF10-1620	-16	-20
A-RF10-2016	-20	-16
A-RF10-2020	-20	-20
A-RF10-2024	-20	-24
A-RF10-2416	-24	-16
A-RF10-2420	-24	-20
A-RF10-2424	-24	-24
A-RF10-3232	-32	-32

ADAPTERS

ORB



ORB Male x JIC Male		
Part Number	ORB M(T1)	JIC M(T2)
A-RJ10-0202	-02	-02
A-RJ10-0204	-02	-04
A-RJ10-0303	-03	-03
A-RJ10-0304	-03	-04
A-RJ10-0403	-04	-03
A-RJ10-0404	-04	-04
A-RJ10-0405	-04	-05
A-RJ10-0406	-04	-06
A-RJ10-0408	-04	-08
A-RJ10-0410	-04	-10
A-RJ10-0503	-05	-03
A-RJ10-0504	-05	-04
A-RJ10-0505	-05	-05
A-RJ10-0506	-05	-06
A-RJ10-0508	-05	-08
A-RJ10-0604	-06	-04
A-RJ10-0605	-06	-05
A-RJ10-0606	-06	-06
A-RJ10-0608	-06	-08
A-RJ10-0610	-06	-10
A-RJ10-0612	-06	-12
A-RJ10-0804	-08	-04
A-RJ10-0805	-08	-05
A-RJ10-0806	-08	-06
A-RJ10-0808	-08	-08
A-RJ10-0810	-08	-10
A-RJ10-0812	-08	-12
A-RJ10-0816	-08	-16
A-RJ10-1004	-10	-04
A-RJ10-1006	-10	-06
A-RJ10-1008	-10	-08
A-RJ10-1010	-10	-10
A-RJ10-1012	-10	-12
A-RJ10-1014	-10	-14

CONTINUED

ORB Male x JIC Male		
Part Number	ORB M(T1)	JIC M(T2)
A-RJ10-1016	-10	-16
A-RJ10-1204	-12	-04
A-RJ10-1206	-12	-06
A-RJ10-1208	-12	-08
A-RJ10-1210	-12	-10
A-RJ10-1212	-12	-12
A-RJ10-1214	-12	-14
A-RJ10-1216	-12	-16
A-RJ10-1220	-12	-20
A-RJ10-1412	-14	-12
A-RJ10-1414	-14	-14
A-RJ10-1416	-14	-16
A-RJ10-1606	-16	-06
A-RJ10-1608	-16	-08
A-RJ10-1610	-16	-10
A-RJ10-1612	-16	-12
A-RJ10-1614	-16	-14
A-RJ10-1616	-16	-16
A-RJ10-1620	-16	-20
A-RJ10-1624	-16	-24
A-RJ10-2008	-20	-08
A-RJ10-2010	-20	-10
A-RJ10-2012	-20	-12
A-RJ10-2016	-20	-16
A-RJ10-2020	-20	-20
A-RJ10-2024	-20	-24
A-RJ10-2032	-20	-32
A-RJ10-2412	-24	-12
A-RJ10-2416	-24	-16
A-RJ10-2420	-24	-20
A-RJ10-2424	-24	-24
A-RJ10-2432	-24	-32
A-RJ10-3220	-32	-20
A-RJ10-3224	-32	-24
A-RJ10-3232	-32	-32



ORB Male x JIC Male Long		
Part Number	ORB M(T1)	JIC M(T2)
A-RJ11-0404	-04	-04
A-RJ11-0505	-05	-05
A-RJ11-0606	-06	-06
A-RJ11-0806	-08	-06
A-RJ11-0808	-08	-08
A-RJ11-1008	-10	-08
A-RJ11-1010	-10	-10
A-RJ11-1212	-12	-12
A-RJ11-1414	-14	-14
A-RJ11-1612	-16	-12
A-RJ11-1616	-16	-16
A-RJ11-1620	-16	-20
A-RJ11-2020	-20	-20
A-RJ11-2424	-24	-24



ORB Male x NPT Male		
Part Number	ORB M(T1)	NPT M(T2)
A-RP10-0302	-03	-02
A-RP10-0402	-04	-02
A-RP10-0404	-04	-04
A-RP10-0406	-04	-06
A-RP10-0502	-05	-02
A-RP10-0504	-05	-04
A-RP10-0602	-06	-02
A-RP10-0604	-06	-04
A-RP10-0606	-06	-06
A-RP10-0608	-06	-08
A-RP10-0802	-08	-02
A-RP10-0804	-08	-04
A-RP10-0806	-08	-06
A-RP10-0808	-08	-08
A-RP10-0812	-08	-12
A-RP10-1004	-10	-04
A-RP10-1006	-10	-06
A-RP10-1008	-10	-08
A-RP10-1012	-10	-12
A-RP10-1206	-12	-06
A-RP10-1208	-12	-08
A-RP10-1212	-12	-12
A-RP10-1216	-12	-16
A-RP10-1612	-16	-12
A-RP10-1616	-16	-16
A-RP10-1620	-16	-20
A-RP10-2016	-20	-16
A-RP10-2020	-20	-20
A-RP10-2024	-20	-24
A-RP10-2416	-24	-16
A-RP10-2420	-24	-20
A-RP10-2424	-24	-24
A-RP10-2432	-24	-32
A-RP10-3232	-32	-32



ORB Male x ORB Female

Part Number	ORB M(T1)	ORB F(T2)
A-R22-0204	-02	-04
A-R22-0304	-03	-04
A-R22-0402	-04	-02
A-R22-0403	-04	-03
A-R22-0404	-04	-04
A-R22-0405	-04	-05
A-R22-0406	-04	-06
A-R22-0408	-04	-08
A-R22-0504	-05	-04
A-R22-0506	-05	-06
A-R22-0604	-06	-04
A-R22-0606	-06	-06
A-R22-0608	-06	-08
A-R22-0804	-08	-04
A-R22-0805	-08	-05
A-R22-0806	-08	-06
A-R22-0808	-08	-08
A-R22-0810	-08	-10
A-R22-0812	-08	-12
A-R22-1004	-10	-04
A-R22-1005	-10	-05
A-R22-1006	-10	-06
A-R22-1008	-10	-08
A-R22-1010	-10	-10
A-R22-1012	-10	-12
A-R22-1204	-12	-04
A-R22-1205	-12	-05
A-R22-1206	-12	-06
A-R22-1208	-12	-08

CONTINUED

ORB Male x ORB Female

Part Number	ORB M(T1)	ORB F(T2)
A-R22-1210	-12	-10
A-R22-1212	-12	-12
A-R22-1214	-12	-14
A-R22-1216	-12	-16
A-R22-1408	-14	-08
A-R22-1410	-14	-10
A-R22-1412	-14	-12
A-R22-1604	-16	-04
A-R22-1606	-16	-06
A-R22-1608	-16	-08
A-R22-1610	-16	-10
A-R22-1612	-16	-12
A-R22-1614	-16	-14
A-R22-1616	-16	-16
A-R22-1620	-16	-20
A-R22-2004	-20	-04
A-R22-2006	-20	-06
A-R22-2008	-20	-08
A-R22-2010	-20	-10
A-R22-2012	-20	-12
A-R22-2014	-20	-14
A-R22-2016	-20	-16
A-R22-2024	-20	-24
A-R22-2412	-24	-12
A-R22-2416	-24	-16
A-R22-2420	-24	-20
A-R22-3212	-32	-12
A-R22-3216	-32	-16
A-R22-3220	-32	-20
A-R22-3224	-32	-24

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

ORB

ADAPTERS



ORB Male x ORFS Female		
Part Number	ORB M(T1)	ORFS F(T2)
A-RF22-0404	-04	-04
A-RF22-0606	-06	-06
A-RF22-0808	-08	-08
A-RF22-1010	-10	-10
A-RF22-1212	-12	-12
A-RF22-1616	-16	-16
A-RF22-2020	-20	-20



ORB Male x JIC Female		
Part Number	ORB M(T1)	JIC F(T2)
A-RJ22-0404	-04	-04
A-RJ22-0406	-04	-06
A-RJ22-0604	-06	-04
A-RJ22-0606	-06	-06
A-RJ22-0608	-06	-08
A-RJ22-0806	-08	-06
A-RJ22-0808	-08	-08
A-RJ22-0810	-08	-10
A-RJ22-1008	-10	-08
A-RJ22-1010	-10	-10
A-RJ22-1212	-12	-12
A-RJ22-1216	-12	-16
A-RJ22-1616	-16	-16
A-RJ22-2020	-20	-20
A-RJ22-2424	-24	-24
A-RJ22-3232	-32	-32

ADAPTERS

ORB



ORB Male x NPT Female		
Part Number	ORB M(T1)	NPT F(T2)
A-RP22-0204	-02	-04
A-RP22-0302	-03	-02
A-RP22-0304	-03	-04
A-RP22-0402	-04	-02
A-RP22-0404	-04	-04
A-RP22-0406	-04	-06
A-RP22-0502	-05	-02
A-RP22-0504	-05	-04
A-RP22-0506	-05	-06
A-RP22-0602	-06	-02
A-RP22-0604	-06	-04
A-RP22-0606	-06	-06
A-RP22-0608	-06	-08
A-RP22-0612	-06	-12
A-RP22-0802	-08	-02
A-RP22-0804	-08	-04
A-RP22-0806	-08	-06
A-RP22-0808	-08	-08
A-RP22-0812	-08	-12
A-RP22-1002	-10	-02
A-RP22-1004	-10	-04
A-RP22-1006	-10	-06
A-RP22-1008	-10	-08
A-RP22-1012	-10	-12
A-RP22-1204	-12	-04
A-RP22-1206	-12	-06

CONTINUED

ORB Male x NPT Female		
Part Number	ORB M(T1)	NPT F(T2)
A-RP22-1208	-12	-08
A-RP22-1212	-12	-12
A-RP22-1216	-12	-16
A-RP22-1224	-12	-24
A-RP22-1408	-14	-08
A-RP22-1412	-14	-12
A-RP22-1416	-14	-16
A-RP22-1606	-16	-06
A-RP22-1608	-16	-08
A-RP22-1612	-16	-12
A-RP22-1616	-16	-16
A-RP22-1620	-16	-20
A-RP22-1624	-16	-24
A-RP22-2008	-20	-08
A-RP22-2012	-20	-12
A-RP22-2016	-20	-16
A-RP22-2020	-20	-20
A-RP22-2024	-20	-24
A-RP22-2412	-24	-12
A-RP22-2416	-24	-16
A-RP22-2420	-24	-20
A-RP22-2424	-24	-24
A-RP22-3220	-32	-20
A-RP22-3224	-32	-24
A-RP22-3232	-32	-32
A-RP22-4032	-40	-32



ORB Male x NPSM Female		
Part Number	ORB M(T1)	NPSM F(T2)
A-R2P22-0402	-04	-02
A-R2P22-0404	-04	-04
A-R2P22-0406	-04	-06
A-R2P22-0408	-04	-08
A-R2P22-0504	-05	-04
A-R2P22-0506	-05	-06
A-R2P22-0508	-05	-08
A-R2P22-0604	-06	-04
A-R2P22-0606	-06	-06
A-R2P22-0608	-06	-08
A-R2P22-0804	-08	-04
A-R2P22-0806	-08	-06
A-R2P22-0808	-08	-08
A-R2P22-0812	-08	-12
A-R2P22-1004	-10	-04
A-R2P22-1006	-10	-06
A-R2P22-1008	-10	-08
CONTINUED		

ORB Male x NPSM Female		
Part Number	ORB M(T1)	NPSM F(T2)
A-R2P22-1012	-10	-12
A-R2P22-1206	-12	-06
A-R2P22-1208	-12	-08
A-R2P22-1212	-12	-12
A-R2P22-1216	-12	-16
A-R2P22-1408	-14	-08
A-R2P22-1412	-14	-12
A-R2P22-1416	-14	-16
A-R2P22-1608	-16	-08
A-R2P22-1612	-16	-12
A-R2P22-1616	-16	-16
A-R2P22-1620	-16	-20
A-R2P22-2012	-20	-12
A-R2P22-2016	-20	-16
A-R2P22-2020	-20	-20
A-R2P22-2420	-24	-20
A-R2P22-2424	-24	-24
A-R2P22-3232	-32	-32



ORB Female x NPT Male		
Part Number	ORB F(T1)	NPT M(T2)
A-RP55-0402	-04	-02
A-RP55-0404	-04	-04
A-RP55-0406	-04	-06
A-RP55-0502	-05	-02
A-RP55-0504	-05	-04
A-RP55-0604	-06	-04
A-RP55-0606	-06	-06
A-RP55-0608	-06	-08
A-RP55-0806	-08	-06
A-RP55-0808	-08	-08
A-RP55-1006	-10	-06
A-RP55-1008	-10	-08
A-RP55-1012	-10	-12
A-RP55-1208	-12	-08
A-RP55-1212	-12	-12
A-RP55-1412	-14	-12
A-RP55-1612	-16	-12
A-RP55-1616	-16	-16
A-RP55-2020	-20	-20
A-RP55-2424	-24	-24



ORB Female x ORB Female		
Part Number	ORB F(T1)	ORB F(T2)
A-R67-0404	-04	-04
A-R67-0606	-06	-06
A-R67-0808	-08	-08
A-R67-1010	-10	-10
A-R67-1212	-12	-12
A-R67-1616	-16	-16
A-R67-3232	-32	-32



ORB Female x NPT Female		
Part Number	ORB F(T1)	NPT F(T2)
A-RP67-0404	-04	-04
A-RP67-0606	-06	-06
A-RP67-0808	-08	-08
A-RP67-1008	-10	-08
A-RP67-1212	-12	-12
A-RP67-1616	-16	-16



ORB Male x ORFS Male 45°

Part Number	ORB M(T1)	ORFS M(T2)
A-RF29-0304	-03	-04
A-RF29-0404	-04	-04
A-RF29-0406	-04	-06
A-RF29-0604	-06	-04
A-RF29-0606	-06	-06
A-RF29-0608	-06	-08
A-RF29-0804	-08	-04
A-RF29-0806	-08	-06
A-RF29-0808	-08	-08
A-RF29-0810	-08	-10
A-RF29-0812	-08	-12
A-RF29-1006	-10	-06
A-RF29-1008	-10	-08
A-RF29-1010	-10	-10
A-RF29-1012	-10	-12
A-RF29-1208	-12	-08
A-RF29-1210	-12	-10
A-RF29-1212	-12	-12
A-RF29-1216	-12	-16
A-RF29-1608	-16	-08
A-RF29-1612	-16	-12
A-RF29-1616	-16	-16
A-RF29-1620	-16	-20
A-RF29-2016	-20	-16
A-RF29-2020	-20	-20
A-RF29-2424	-24	-24

ORB Male x JIC Male 45°

Part Number	ORB M(T1)	JIC M(T2)
A-RJ29-0202	-02	-02
A-RJ29-0404	-04	-04
A-RJ29-0405	-04	-05
A-RJ29-0406	-04	-06
A-RJ29-0408	-04	-08
A-RJ29-0504	-05	-04
A-RJ29-0505	-05	-05
A-RJ29-0506	-05	-06
A-RJ29-0604	-06	-04
A-RJ29-0605	-06	-05
A-RJ29-0606	-06	-06
A-RJ29-0608	-06	-08
A-RJ29-0804	-08	-04
A-RJ29-0805	-08	-05
A-RJ29-0806	-08	-06
A-RJ29-0808	-08	-08
A-RJ29-0810	-08	-10
A-RJ29-0812	-08	-12
A-RJ29-1006	-10	-06
A-RJ29-1008	-10	-08
A-RJ29-1010	-10	-10
A-RJ29-1012	-10	-12
A-RJ29-1208	-12	-08
A-RJ29-1210	-12	-10
A-RJ29-1212	-12	-12
A-RJ29-1216	-12	-16
A-RJ29-1612	-16	-12
A-RJ29-1616	-16	-16
A-RJ29-1620	-16	-20
A-RJ29-2016	-20	-16
A-RJ29-2020	-20	-20
A-RJ29-2024	-20	-24
A-RJ29-2420	-24	-20
A-RJ29-2424	-24	-24
A-RJ29-3232	-32	-32



ORB Male x NPSM Female 45°

Part Number	ORB M(T1)	NPSM F(T2)
A-R2P38-0402	-04	-02
A-R2P38-0404	-04	-04
A-R2P38-0406	-04	-06
A-R2P38-0604	-06	-04
A-R2P38-0606	-06	-06
A-R2P38-0608	-06	-08
A-R2P38-0804	-08	-04
A-R2P38-0806	-08	-06
A-R2P38-0808	-08	-08
A-R2P38-0812	-08	-12
A-R2P38-1006	-10	-06
A-R2P38-1008	-10	-08
A-R2P38-1012	-10	-12
A-R2P38-1206	-12	-06
A-R2P38-1208	-12	-08
A-R2P38-1212	-12	-12
A-R2P38-1216	-12	-16
A-R2P38-1612	-16	-12
A-R2P38-1616	-16	-16
A-R2P38-2020	-20	-20
A-R2P38-2424	-24	-24

ORB Male x ORFS Male 90°

Part Number	ORB M(T1)	ORFS M(T2)
A-RF33-0304	-03	-04
A-RF33-0404	-04	-04
A-RF33-0406	-04	-06
A-RF33-0408	-04	-08
A-RF33-0504	-05	-04
A-RF33-0506	-05	-06
A-RF33-0604	-06	-04
A-RF33-0606	-06	-06
A-RF33-0608	-06	-08
A-RF33-0804	-08	-04
A-RF33-0806	-08	-06
A-RF33-0808	-08	-08
A-RF33-0810	-08	-10
A-RF33-0812	-08	-12
A-RF33-1006	-10	-06
A-RF33-1008	-10	-08
A-RF33-1010	-10	-10
A-RF33-1012	-10	-12
A-RF33-1206	-12	-06
A-RF33-1208	-12	-08
A-RF33-1210	-12	-10
A-RF33-1212	-12	-12
A-RF33-1216	-12	-16
A-RF33-1220	-12	-20
A-RF33-1412	-14	-12
A-RF33-1416	-14	-16
A-RF33-1606	-16	-06
A-RF33-1608	-16	-08
A-RF33-1612	-16	-12
A-RF33-1616	-16	-16
A-RF33-1620	-16	-20
A-RF33-2016	-20	-16
A-RF33-2020	-20	-20
A-RF33-2024	-20	-24
A-RF33-2420	-24	-20
A-RF33-2424	-24	-24



ORB Male x JIC Male 90°

Part Number	ORB M(T1)	JIC M(T2)
A-RJ33-0202	-02	-02
A-RJ33-0204	-02	-04
A-RJ33-0303	-03	-03
A-RJ33-0304	-03	-04
A-RJ33-0403	-04	-03
A-RJ33-0404	-04	-04
A-RJ33-0405	-04	-05
A-RJ33-0406	-04	-06
A-RJ33-0408	-04	-08
A-RJ33-0504	-05	-04
A-RJ33-0505	-05	-05
A-RJ33-0506	-05	-06
A-RJ33-0508	-05	-08
A-RJ33-0604	-06	-04
A-RJ33-0605	-06	-05
A-RJ33-0606	-06	-06
A-RJ33-0608	-06	-08
A-RJ33-0610	-06	-10
A-RJ33-0612	-06	-12
A-RJ33-0804	-08	-04
A-RJ33-0805	-08	-05
A-RJ33-0806	-08	-06
A-RJ33-0808	-08	-08
A-RJ33-0810	-08	-10
A-RJ33-0812	-08	-12
A-RJ33-0816	-08	-16
A-RJ33-1004	-10	-04
A-RJ33-1005	-10	-05
A-RJ33-1006	-10	-06
A-RJ33-1008	-10	-08

CONTINUED

ORB Male x JIC Male 90°

Part Number	ORB M(T1)	JIC M(T2)
A-RJ33-1010	-10	-10
A-RJ33-1012	-10	-12
A-RJ33-1016	-10	-16
A-RJ33-1206	-12	-06
A-RJ33-1208	-12	-08
A-RJ33-1210	-12	-10
A-RJ33-1212	-12	-12
A-RJ33-1214	-12	-14
A-RJ33-1216	-12	-16
A-RJ33-1220	-12	-20
A-RJ33-1412	-14	-12
A-RJ33-1414	-14	-14
A-RJ33-1416	-14	-16
A-RJ33-1420	-14	-20
A-RJ33-1608	-16	-08
A-RJ33-1610	-16	-10
A-RJ33-1612	-16	-12
A-RJ33-1614	-16	-14
A-RJ33-1616	-16	-16
A-RJ33-1620	-16	-20
A-RJ33-1624	-16	-24
A-RJ33-2010	-20	-10
A-RJ33-2012	-20	-12
A-RJ33-2016	-20	-16
A-RJ33-2020	-20	-20
A-RJ33-2024	-20	-24
A-RJ33-2416	-24	-16
A-RJ33-2420	-24	-20
A-RJ33-2424	-24	-24
A-RJ33-2432	-24	-32
A-RJ33-3232	-32	-32



ORB Male x JIC Male 90° Long

Part Number	ORB M(T1)	JIC M(T2)
A-RJ35-0404	-04	-04
A-RJ35-0604	-06	-04
A-RJ35-0606	-06	-06
A-RJ35-0806	-08	-06
A-RJ35-0808	-08	-08
A-RJ35-0810	-08	-10
A-RJ35-1006	-10	-06
A-RJ35-1008	-10	-08
A-RJ35-1010	-10	-10
A-RJ35-1212	-12	-12
A-RJ35-1616	-16	-16
A-RJ35-2020	-20	-20



ORB Male x JIC Male 90° X-Long

Part Number	ORB M(T1)	JIC M(T2)
A-RJ36-0404	-04	-04
A-RJ36-0604	-06	-04
A-RJ36-0606	-06	-06
A-RJ36-0608	-06	-08
A-RJ36-0806	-08	-06
A-RJ36-0808	-08	-08
A-RJ36-0810	-08	-10
A-RJ36-1008	-10	-08
A-RJ36-1010	-10	-10
A-RJ36-1212	-12	-12
A-RJ36-1216	-12	-16
A-RJ36-1612	-16	-12
A-RJ36-1616	-16	-16
A-RJ36-2020	-20	-20



ORB Male x NPT Male 90°

Part Number	ORB M(T1)	NPT M(T2)
A-RP33-0402	-04	-02
A-RP33-0404	-04	-04
A-RP33-0406	-04	-06
A-RP33-0502	-05	-02
A-RP33-0604	-06	-04
A-RP33-0606	-06	-06
A-RP33-0608	-06	-08
A-RP33-0806	-08	-06
A-RP33-0808	-08	-08
A-RP33-1008	-10	-08
A-RP33-1212	-12	-12
A-RP33-1412	-14	-12
A-RP33-1612	-16	-12
A-RP33-1616	-16	-16
A-RP33-2020	-20	-20
A-RP33-2424	-24	-24
A-RP33-3232	-32	-32



ORB Male x ORB Female 90°

Part Number	ORB M(T1)	ORB F(T2)
A-R39-0404	-04	-04
A-R39-0606	-06	-06
A-R39-0808	-08	-08
A-R39-1010	-10	-10
A-R39-1212	-12	-12
A-R39-1616	-16	-16
A-R39-2020	-20	-20

ORB

ADAPTERS



ORB Male x ORFS Female 90°		
Part Number	ORB M(T1)	ORFS F(T2)
A-RF39-0404	-04	-04
A-RF39-0606	-06	-06
A-RF39-0808	-08	-08
A-RF39-1010	-10	-10
A-RF39-1212	-12	-12
A-RF39-1616	-16	-16
A-RF39-2020	-20	-20



ORB Male x JIC Female 90°		
Part Number	ORB M(T1)	JIC F(T2)
A-RJ39-0404	-04	-04
A-RJ39-0604	-06	-04
A-RJ39-0606	-06	-06
A-RJ39-0608	-06	-08
A-RJ39-0806	-08	-06
A-RJ39-0808	-08	-08
A-RJ39-1010	-10	-10
A-RJ39-1210	-12	-10
A-RJ39-1212	-12	-12
A-RJ39-1616	-16	-16
A-RJ39-2020	-20	-20

ADAPTERS

ORB



ORB Male x NPT Female 90°

Part Number	ORB M(T1)	NPT F(T2)
A-RP39-0402	-04	-02
A-RP39-0404	-04	-04
A-RP39-0406	-04	-06
A-RP39-0502	-05	-02
A-RP39-0602	-06	-02
A-RP39-0604	-06	-04
A-RP39-0606	-06	-06
A-RP39-0806	-08	-06
A-RP39-0808	-08	-08
A-RP39-1006	-10	-06
A-RP39-1008	-10	-08
A-RP39-1010	-10	-10
A-RP39-1208	-12	-08
A-RP39-1212	-12	-12
A-RP39-1412	-14	-12
A-RP39-1612	-16	-12
A-RP39-1616	-16	-16
A-RP39-2020	-20	-20
A-RP39-2424	-24	-24
A-RP39-3232	-32	-32

ORB Male x NPSM Female 90°

Part Number	ORB M(T1)	NPSM F(T2)
A-R2P39-0402	-04	-02
A-R2P39-0404	-04	-04
A-R2P39-0406	-04	-06
A-R2P39-0604	-06	-04
A-R2P39-0606	-06	-06
A-R2P39-0608	-06	-08
A-R2P39-0804	-08	-04
A-R2P39-0806	-08	-06
A-R2P39-0808	-08	-08
A-R2P39-0812	-08	-12
A-R2P39-1004	-10	-04
A-R2P39-1006	-10	-06
A-R2P39-1008	-10	-08
A-R2P39-1012	-10	-12
A-R2P39-1206	-12	-06
A-R2P39-1208	-12	-08
A-R2P39-1212	-12	-12
A-R2P39-1216	-12	-16
A-R2P39-1412	-14	-12
A-R2P39-1612	-16	-12
A-R2P39-1616	-16	-16
A-R2P39-1620	-16	-20
A-R2P39-2012	-20	-12
A-R2P39-2016	-20	-16
A-R2P39-2020	-20	-20
A-R2P39-2420	-24	-20
A-R2P39-2424	-24	-24
A-R2P39-3232	-32	-32

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

ORB

ADAPTERS



ORB Male x ORFS Male Branch Tee

Part Number	ORB M(T1)	ORFS M(T2)
A-RF5-33-0304	-03	-04
A-RF5-33-0404	-04	-04
A-RF5-33-0606	-06	-06
A-RF5-33-0608	-06	-08
A-RF5-33-0806	-08	-06
A-RF5-33-0808	-08	-08
A-RF5-33-1010	-10	-10
A-RF5-33-1012	-10	-12
A-RF5-33-1212	-12	-12
A-RF5-33-1612	-16	-12
A-RF5-33-1616	-16	-16
A-RF5-33-2016	-20	-16
A-RF5-33-2020	-20	-20
A-RF5-33-2424	-24	-24



ORB Male x JIC Male Branch Tee

Part Number	ORB M(T1)	JIC M(T2)
A-RJ5-33-0202	-02	-02
A-RJ5-33-0304	-03	-04
A-RJ5-33-0404	-04	-04
A-RJ5-33-0406	-04	-06
A-RJ5-33-0505	-05	-05
A-RJ5-33-0604	-06	-04
A-RJ5-33-0605	-06	-05
A-RJ5-33-0606	-06	-06
A-RJ5-33-0608	-06	-08
A-RJ5-33-0806	-08	-06
A-RJ5-33-0808	-08	-08
A-RJ5-33-0810	-08	-10
A-RJ5-33-0812	-08	-12
A-RJ5-33-1008	-10	-08
A-RJ5-33-1010	-10	-10
A-RJ5-33-1012	-10	-12
A-RJ5-33-1210	-12	-10
A-RJ5-33-1212	-12	-12
A-RJ5-33-1216	-12	-16
A-RJ5-33-1414	-14	-14
A-RJ5-33-1610	-16	-10
A-RJ5-33-1612	-16	-12
A-RJ5-33-1616	-16	-16
A-RJ5-33-2020	-20	-20
A-RJ5-33-2424	-24	-24
A-RJ5-33-3232	-32	-32

ADAPTERS

ORB



ORB Male x ORFS Male Run Tee

Part Number	ORB M(T1)	ORFS M(T2)
A-RF6-33-0404	-04	-04
A-RF6-33-0406	-04	-06
A-RF6-33-0604	-06	-04
A-RF6-33-0606	-06	-06
A-RF6-33-0608	-06	-08
A-RF6-33-0808	-08	-08
A-RF6-33-1008	-10	-08
A-RF6-33-1010	-10	-10
A-RF6-33-1208	-12	-08
A-RF6-33-1210	-12	-10
A-RF6-33-1212	-12	-12
A-RF6-33-1608	-16	-08
A-RF6-33-1612	-16	-12
A-RF6-33-1616	-16	-16
A-RF6-33-2012	-20	-12
A-RF6-33-2020	-20	-20
A-RF6-33-2424	-24	-24



ORB Male x JIC Male Run Tee

Part Number	ORB M(T1)	JIC M(T2)
A-RJ6-33-0204	-02	-04
A-RJ6-33-0404	-04	-04
A-RJ6-33-0406	-04	-06
A-RJ6-33-0505	-05	-05
A-RJ6-33-0604	-06	-04
A-RJ6-33-0606	-06	-06
A-RJ6-33-0608	-06	-08
A-RJ6-33-0804	-08	-04
A-RJ6-33-0806	-08	-06
A-RJ6-33-0808	-08	-08
A-RJ6-33-0810	-08	-10
A-RJ6-33-1008	-10	-08
A-RJ6-33-1010	-10	-10
A-RJ6-33-1012	-10	-12
A-RJ6-33-1208	-12	-08
A-RJ6-33-1210	-12	-10
A-RJ6-33-1212	-12	-12
A-RJ6-33-1216	-12	-16
A-RJ6-33-1414	-14	-14
A-RJ6-33-1612	-16	-12
A-RJ6-33-1616	-16	-16
A-RJ6-33-2020	-20	-20
A-RJ6-33-2424	-24	-24
A-RJ6-33-3232	-32	-32



ORB Male x ORB Female Run Tee

Part Number	ORB M(T1)	ORB F(T2)
A-R6-39-0404	-04	-04
A-R6-39-0606	-06	-06
A-R6-39-0808	-08	-08
A-R6-39-1010	-10	-10
A-R6-39-1212	-12	-12
A-R6-39-1616	-16	-16

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

ORB

ADAPTERS



ORB Female x ORFS M x F Run Tee

Part Number	ORB F(T1)	ORFS MxF(T2)
A-RF6-69-0404	-04	-04
A-RF6-69-0406	-04	-06
A-RF6-69-0408	-04	-08
A-RF6-69-0410	-04	-10
A-RF6-69-0412	-04	-12
A-RF6-69-0416	-04	-16
A-RF6-69-0420	-04	-20
A-RF6-69-0424	-04	-24
A-RF6-69-0608	-06	-08
A-RF6-69-0610	-06	-10

ORB Female x JIC M x F Run Tee

Part Number	ORB F(T1)	ORFS MxF(T2)
A-RJ6-69-0404	-04	-04
A-RJ6-69-0406	-04	-06
A-RJ6-69-0408	-04	-08
A-RJ6-69-0410	-04	-10
A-RJ6-69-0412	-04	-12
A-RJ6-69-0416	-04	-16
A-RJ6-69-0420	-04	-20
A-RJ6-69-0424	-04	-24
A-RJ6-69-0432	-04	-32

ADAPTERS

ORB

NPT

ADAPTERS

ADAPTERS

NPT



NPT Hex Plug

Part Number	NPT M
A-P1-01	-01
A-P1-02	-02
A-P1-04	-04
A-P1-06	-06
A-P1-08	-08
A-P1-12	-12
A-P1-16	-16
A-P1-20	-20
A-P1-24	-24
A-P1-32	-32



NPT Allen Plug

Part Number	NPT M
A-P2-01	-01
A-P2-02	-02
A-P2-04	-04
A-P2-06	-06
A-P2-08	-08
A-P2-12	-12
A-P2-16	-16
A-P2-20	-20
A-P2-24	-24
A-P2-32	-32



NPT Cap

Part Number	NPT F
A-P3-02	-02
A-P3-04	-04
A-P3-06	-06
A-P3-08	-08
A-P3-12	-12
A-P3-16	-16
A-P3-20	-20
A-P3-24	-24
A-P3-32	-32

NPT

ADAPTERS



NPT Male x NPT Male

Part Number	NPT M(T1)	NPT M(T2)
A-P10-0202	-02	-02
A-P10-0402	-04	-02
A-P10-0404	-04	-04
A-P10-0602	-06	-02
A-P10-0604	-06	-04
A-P10-0606	-06	-06
A-P10-0802	-08	-02
A-P10-0804	-08	-04
A-P10-0806	-08	-06
A-P10-0808	-08	-08
A-P10-1204	-12	-04
A-P10-1206	-12	-06
A-P10-1208	-12	-08
A-P10-1212	-12	-12
A-P10-1606	-16	-06
A-P10-1608	-16	-08
A-P10-1612	-16	-12
A-P10-1616	-16	-16
A-P10-2004	-20	-04
A-P10-2008	-20	-08
A-P10-2012	-20	-12
A-P10-2016	-20	-16
A-P10-2020	-20	-20
A-P10-2412	-24	-12
A-P10-2416	-24	-16
A-P10-2420	-24	-20
A-P10-2424	-24	-24
A-P10-3216	-32	-16
A-P10-3220	-32	-20
A-P10-3224	-32	-24
A-P10-3232	-32	-32
A-P10-4040	-40	-40

NPT Male x ORFS Male

Part Number	NPT M(T1)	ORFS M(T2)
A-PF10-0204	-02	-04
A-PF10-0206	-02	-06
A-PF10-0404	-04	-04
A-PF10-0406	-04	-06
A-PF10-0408	-04	-08
A-PF10-0604	-06	-04
A-PF10-0606	-06	-06
A-PF10-0608	-06	-08
A-PF10-0804	-08	-04
A-PF10-0806	-08	-06
A-PF10-0808	-08	-08
A-PF10-0810	-08	-10
A-PF10-0812	-08	-12
A-PF10-1208	-12	-08
A-PF10-1210	-12	-10
A-PF10-1212	-12	-12
A-PF10-1216	-12	-16
A-PF10-1220	-12	-20
A-PF10-1608	-16	-08
A-PF10-1610	-16	-10
A-PF10-1612	-16	-12
A-PF10-1616	-16	-16
A-PF10-1620	-16	-20
A-PF10-2016	-20	-16
A-PF10-2020	-20	-20
A-PF10-2424	-24	-24

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x JIC Male		
Part Number	NPT M(T1)	JIC M(T2)
A-PJ10-0202	-02	-02
A-PJ10-0203	-02	-03
A-PJ10-0204	-02	-04
A-PJ10-0205	-02	-05
A-PJ10-0206	-02	-06
A-PJ10-0208	-02	-08
A-PJ10-0402	-04	-02
A-PJ10-0403	-04	-03
A-PJ10-0404	-04	-04
A-PJ10-0405	-04	-05
A-PJ10-0406	-04	-06
A-PJ10-0408	-04	-08
A-PJ10-0410	-04	-10
A-PJ10-0602	-06	-02
A-PJ10-0604	-06	-04
A-PJ10-0605	-06	-05
A-PJ10-0606	-06	-06
A-PJ10-0608	-06	-08
A-PJ10-0610	-06	-10
A-PJ10-0612	-06	-12
A-PJ10-0804	-08	-04
A-PJ10-0805	-08	-05
A-PJ10-0806	-08	-06
A-PJ10-0808	-08	-08
A-PJ10-0810	-08	-10
A-PJ10-0812	-08	-12
A-PJ10-0814	-08	-14
A-PJ10-0816	-08	-16
A-PJ10-1204	-12	-04
A-PJ10-1206	-12	-06
A-PJ10-1208	-12	-08
CONTINUED		

NPT Male x JIC Male		
Part Number	NPT M(T1)	JIC M(T2)
A-PJ10-1210	-12	-10
A-PJ10-1212	-12	-12
A-PJ10-1214	-12	-14
A-PJ10-1216	-12	-16
A-PJ10-1220	-12	-20
A-PJ10-1232	-12	-32
A-PJ10-1606	-16	-06
A-PJ10-1608	-16	-08
A-PJ10-1610	-16	-10
A-PJ10-1612	-16	-12
A-PJ10-1614	-16	-14
A-PJ10-1616	-16	-16
A-PJ10-1620	-16	-20
A-PJ10-1624	-16	-24
A-PJ10-1632	-16	-32
A-PJ10-2008	-20	-08
A-PJ10-2012	-20	-12
A-PJ10-2016	-20	-16
A-PJ10-2020	-20	-20
A-PJ10-2024	-20	-24
A-PJ10-2032	-20	-32
A-PJ10-2412	-24	-12
A-PJ10-2416	-24	-16
A-PJ10-2420	-24	-20
A-PJ10-2424	-24	-24
A-PJ10-2432	-24	-32
A-PJ10-3216	-32	-16
A-PJ10-3220	-32	-20
A-PJ10-3224	-32	-24
A-PJ10-3232	-32	-32
A-PJ10-4040	-40	-40
A-PJ10-4848	-48	-48

ADAPTERS

NPT

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

NPT

ADAPTERS



NPT Male x JIC Male Long

Part Number	NPT M(T1)	JIC M(T2)
A-PJ11-0204	-02	-04
A-PJ11-0205	-02	-05
A-PJ11-0206	-02	-06
A-PJ11-0404	-04	-04
A-PJ11-0405	-04	-05
A-PJ11-0406	-04	-06
A-PJ11-0408	-04	-08
A-PJ11-0606	-06	-06
A-PJ11-0608	-06	-08
A-PJ11-0806	-08	-06
A-PJ11-0808	-08	-08
A-PJ11-0810	-08	-10
A-PJ11-0812	-08	-12
A-PJ11-1212	-12	-12
A-PJ11-1216	-12	-16
A-PJ11-1616	-16	-16
A-PJ11-2020	-20	-20
A-PJ11-2424	-24	-24
A-PJ11-3232	-32	-32

NPT Male x JIC Male X-Long

Part Number	NPT M(T1)	JIC M(T2)
A-PJ12-0204	-02	-04
A-PJ12-0205	-02	-05
A-PJ12-0404	-04	-04
A-PJ12-0406	-04	-06
A-PJ12-0606	-06	-06
A-PJ12-0608	-06	-08
A-PJ12-0808	-08	-08
A-PJ12-0810	-08	-10
A-PJ12-1212	-12	-12
A-PJ12-1216	-12	-16
A-PJ12-1616	-16	-16

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x NPT Female		
Part Number	NPT M(T1)	NPT F(T2)
A-P22-0102	-01	-02
A-P22-0202	-02	-02
A-P22-0204	-02	-04
A-P22-0206	-02	-06
A-P22-0208	-02	-08
A-P22-0402	-04	-02
A-P22-0404	-04	-04
A-P22-0406	-04	-06
A-P22-0408	-04	-08
A-P22-0412	-04	-12
A-P22-0420	-04	-20
A-P22-0602	-06	-02
A-P22-0604	-06	-04
A-P22-0606	-06	-06
A-P22-0608	-06	-08
A-P22-0612	-06	-12
A-P22-0802	-08	-02
A-P22-0804	-08	-04
A-P22-0806	-08	-06
A-P22-0808	-08	-08
A-P22-0812	-08	-12
A-P22-0816	-08	-16
A-P22-1202	-12	-02
A-P22-1204	-12	-04
A-P22-1206	-12	-06
A-P22-1208	-12	-08
A-P22-1212	-12	-12
A-P22-1216	-12	-16
A-P22-1220	-12	-20
A-P22-1602	-16	-02
A-P22-1604	-16	-04
A-P22-1606	-16	-06

CONTINUED

NPT Male x NPT Female		
Part Number	NPT M(T1)	NPT F(T2)
A-P22-1608	-16	-08
A-P22-1612	-16	-12
A-P22-1616	-16	-16
A-P22-1620	-16	-20
A-P22-1624	-16	-24
A-P22-2004	-20	-04
A-P22-2006	-20	-06
A-P22-2008	-20	-08
A-P22-2012	-20	-12
A-P22-2016	-20	-16
A-P22-2020	-20	-20
A-P22-2024	-20	-24
A-P22-2404	-24	-04
A-P22-2406	-24	-06
A-P22-2408	-24	-08
A-P22-2412	-24	-12
A-P22-2416	-24	-16
A-P22-2420	-24	-20
A-P22-2424	-24	-24
A-P22-2432	-24	-32
A-P22-3208	-32	-08
A-P22-3212	-32	-12
A-P22-3216	-32	-16
A-P22-3220	-32	-20
A-P22-3224	-32	-24
A-P22-3232	-32	-32
A-P22-4008	-40	-08
A-P22-4016	-40	-16
A-P22-4020	-40	-20
A-P22-4024	-40	-24
A-P22-4032	-40	-32
A-P22-4832	-48	-32

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x NPSM Female

Part Number	NPT M(T1)	NPSM F(T2)
A-P2P22-0202	-02	-02
A-P2P22-0204	-02	-04
A-P2P22-0402	-04	-02
A-P2P22-0404	-04	-04
A-P2P22-0406	-04	-06
A-P2P22-0408	-04	-08
A-P2P22-0604	-06	-04
A-P2P22-0606	-06	-06
A-P2P22-0608	-06	-08
A-P2P22-0804	-08	-04
A-P2P22-0806	-08	-06
A-P2P22-0808	-08	-08
A-P2P22-0812	-08	-12
A-P2P22-1206	-12	-06
A-P2P22-1208	-12	-08
A-P2P22-1212	-12	-12
A-P2P22-1216	-12	-16
A-P2P22-1220	-12	-20
A-P2P22-1606	-16	-06
A-P2P22-1608	-16	-08
A-P2P22-1612	-16	-12
A-P2P22-1616	-16	-16
A-P2P22-1620	-16	-20
A-P2P22-1624	-16	-24
A-P2P22-2012	-20	-12
A-P2P22-2016	-20	-16
A-P2P22-2020	-20	-20
A-P2P22-2024	-20	-24
A-P2P22-2420	-24	-20
A-P2P22-2424	-24	-24
A-P2P22-3232	-32	-32



NPT Male x ORFS Female

Part Number	NPT M(T1)	ORFS F(T2)
A-PF22-0204	-02	-04
A-PF22-0404	-04	-04
A-PF22-0406	-04	-06
A-PF22-0606	-06	-06
A-PF22-0608	-06	-08
A-PF22-0808	-08	-08
A-PF22-0810	-08	-10
A-PF22-1212	-12	-12
A-PF22-1216	-12	-16
A-PF22-1612	-16	-12
A-PF22-1616	-16	-16
A-PF22-1620	-16	-20
A-PF22-2020	-20	-20
A-PF22-2424	-24	-24

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x JIC Female

Part Number	NPT M(T1)	JIC F(T2)
A-PJ22-0204	-02	-04
A-PJ22-0404	-04	-04
A-PJ22-0405	-04	-05
A-PJ22-0406	-04	-06
A-PJ22-0408	-04	-08
A-PJ22-0604	-06	-04
A-PJ22-0606	-06	-06
A-PJ22-0608	-06	-08
A-PJ22-0610	-06	-10
A-PJ22-0806	-08	-06
A-PJ22-0808	-08	-08
A-PJ22-0810	-08	-10
A-PJ22-0812	-08	-12
A-PJ22-1208	-12	-08
A-PJ22-1210	-12	-10
A-PJ22-1212	-12	-12
A-PJ22-1216	-12	-16
A-PJ22-1612	-16	-12
A-PJ22-1616	-16	-16
A-PJ22-2020	-20	-20
A-PJ22-2424	-24	-24
A-PJ22-3232	-32	-32

NPT Female x JIC Male

Part Number	NPT F(T1)	JIC M(T2)
A-PJ55-0202	-02	-02
A-PJ55-0203	-02	-03
A-PJ55-0204	-02	-04
A-PJ55-0205	-02	-05
A-PJ55-0206	-02	-06
A-PJ55-0402	-04	-02
A-PJ55-0403	-04	-03
A-PJ55-0404	-04	-04
A-PJ55-0405	-04	-05
A-PJ55-0406	-04	-06
A-PJ55-0408	-04	-08
A-PJ55-0604	-06	-04
A-PJ55-0605	-06	-05
A-PJ55-0606	-06	-06
A-PJ55-0608	-06	-08
A-PJ55-0610	-06	-10
A-PJ55-0804	-08	-04
A-PJ55-0806	-08	-06
A-PJ55-0808	-08	-08
A-PJ55-0810	-08	-10
A-PJ55-0812	-08	-12
A-PJ55-1206	-12	-06
A-PJ55-1208	-12	-08
A-PJ55-1210	-12	-10
A-PJ55-1212	-12	-12
A-PJ55-1214	-12	-14
A-PJ55-1216	-12	-16
A-PJ55-1610	-16	-10
A-PJ55-1612	-16	-12
A-PJ55-1614	-16	-14
A-PJ55-1616	-16	-16
A-PJ55-1620	-16	-20
A-PJ55-1624	-16	-24
A-PJ55-2016	-20	-16
A-PJ55-2020	-20	-20
A-PJ55-2024	-20	-24
A-PJ55-2420	-24	-20
A-PJ55-2424	-24	-24
A-PJ55-3232	-32	-32
A-PJ55-4040	-40	-40

ADAPTERS

NPT

NPT

ADAPTERS



NPT Female x NPT Female		
Part Number	NPT F(T1)	NPT F(T2)
A-P67-0202	-02	-02
A-P67-0402	-04	-02
A-P67-0404	-04	-04
A-P67-0602	-06	-02
A-P67-0604	-06	-04
A-P67-0606	-06	-06
A-P67-0802	-08	-02
A-P67-0804	-08	-04
A-P67-0806	-08	-06
A-P67-0808	-08	-08
A-P67-1204	-12	-04
A-P67-1206	-12	-06
A-P67-1208	-12	-08
A-P67-1212	-12	-12
A-P67-1608	-16	-08
A-P67-1612	-16	-12
A-P67-1616	-16	-16
A-P67-2012	-20	-12
A-P67-2016	-20	-16
A-P67-2020	-20	-20
A-P67-2420	-24	-20
A-P67-2424	-24	-24
A-P67-3224	-32	-24
A-P67-3232	-32	-32



NPT Female x NPSM Female		
Part Number	NPT F(T1)	NPSM F(T2)
A-P2P67-0202	-02	-02
A-P2P67-0204	-02	-04
A-P2P67-0402	-04	-02
A-P2P67-0404	-04	-04
A-P2P67-0406	-04	-06
A-P2P67-0408	-04	-08
A-P2P67-0604	-06	-04
A-P2P67-0606	-06	-06
A-P2P67-0608	-06	-08
A-P2P67-0804	-08	-04
A-P2P67-0806	-08	-06
A-P2P67-0808	-08	-08
A-P2P67-0812	-08	-12
A-P2P67-1206	-12	-06
A-P2P67-1208	-12	-08
A-P2P67-1212	-12	-12
A-P2P67-1216	-12	-16
A-P2P67-1612	-16	-12
A-P2P67-1616	-16	-16
A-P2P67-2020	-20	-20
A-P2P67-2424	-24	-24
A-P2P67-3232	-32	-32

ADAPTERS

NPT

NPT

ADAPTERS



NPT Female x JIC Female

Part Number	NPT F(T1)	JIC F(T2)
A-PJ67-0202	-02	-02
A-PJ67-0204	-02	-04
A-PJ67-0205	-02	-05
A-PJ67-0404	-04	-04
A-PJ67-0405	-04	-05
A-PJ67-0406	-04	-06
A-PJ67-0408	-04	-08
A-PJ67-0604	-06	-04
A-PJ67-0606	-06	-06
A-PJ67-0608	-06	-08
A-PJ67-0610	-06	-10
A-PJ67-0806	-08	-06
A-PJ67-0808	-08	-08
A-PJ67-0810	-08	-10
A-PJ67-0812	-08	-12
A-PJ67-1210	-12	-10
A-PJ67-1212	-12	-12
A-PJ67-1214	-12	-14
A-PJ67-1616	-16	-16
A-PJ67-2020	-20	-20
A-PJ67-2424	-24	-24
A-PJ67-3232	-32	-32

NPT Male x NPT Male 45°

Part Number	NPT M(T1)	NPT M(T2)
A-P14-0202	-02	-02
A-P14-0404	-04	-04
A-P14-0604	-06	-04
A-P14-0606	-06	-06
A-P14-0808	-08	-08
A-P14-1212	-12	-12
A-P14-1616	-16	-16
A-P14-2020	-20	-20
A-P14-2424	-24	-24
A-P14-3232	-32	-32

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x ORFS Male 45°

Part Number	NPT M(T1)	ORFS M(T2)
A-PF14-0204	-02	-04
A-PF14-0206	-02	-06
A-PF14-0404	-04	-04
A-PF14-0406	-04	-06
A-PF14-0408	-04	-08
A-PF14-0606	-06	-06
A-PF14-0608	-06	-08
A-PF14-0806	-08	-06
A-PF14-0808	-08	-08
A-PF14-0810	-08	-10
A-PF14-0812	-08	-12
A-PF14-1208	-12	-08
A-PF14-1212	-12	-12
A-PF14-1616	-16	-16
A-PF14-2020	-20	-20
A-PF14-2424	-24	-24

NPT Male x JIC Male 45°

Part Number	NPT M(T1)	JIC M(T2)
A-PJ14-0202	-02	-02
A-PJ14-0203	-02	-03
A-PJ14-0204	-02	-04
A-PJ14-0206	-02	-06
A-PJ14-0404	-04	-04
A-PJ14-0405	-04	-05
A-PJ14-0406	-04	-06
A-PJ14-0408	-04	-08
A-PJ14-0604	-06	-04
A-PJ14-0605	-06	-05
A-PJ14-0606	-06	-06
A-PJ14-0608	-06	-08
A-PJ14-0610	-06	-10
A-PJ14-0612	-06	-12
A-PJ14-0804	-08	-04
A-PJ14-0806	-08	-06
A-PJ14-0808	-08	-08
A-PJ14-0810	-08	-10
A-PJ14-0812	-08	-12
A-PJ14-0816	-08	-16
A-PJ14-1206	-12	-06
A-PJ14-1208	-12	-08
A-PJ14-1210	-12	-10
A-PJ14-1212	-12	-12
A-PJ14-1214	-12	-14
A-PJ14-1216	-12	-16
A-PJ14-1612	-16	-12
A-PJ14-1616	-16	-16
A-PJ14-1620	-16	-20
A-PJ14-2016	-20	-16
A-PJ14-2020	-20	-20
A-PJ14-2024	-20	-24
A-PJ14-2420	-24	-20
A-PJ14-2424	-24	-24
A-PJ14-3232	-32	-32

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x NPT Female 45°

Part Number	NPT M(T1)	NPT F(T2)
A-P23-0102	-01	-02
A-P23-0202	-02	-02
A-P23-0404	-04	-04
A-P23-0606	-06	-06
A-P23-0808	-08	-08
A-P23-1212	-12	-12
A-P23-1616	-16	-16
A-P23-2020	-20	-20
A-P23-2424	-24	-24
A-P23-3232	-32	-32



NPT Male x NPSM Female 45°

Part Number	NPT M(T1)	NPSM F(T2)
A-P2P23-0202	-02	-02
A-P2P23-0204	-02	-04
A-P2P23-0402	-04	-02
A-P2P23-0404	-04	-04
A-P2P23-0406	-04	-06
A-P2P23-0604	-06	-04
A-P2P23-0606	-06	-06
A-P2P23-0608	-06	-08
A-P2P23-0804	-08	-04
A-P2P23-0806	-08	-06
A-P2P23-0808	-08	-08
A-P2P23-0812	-08	-12
A-P2P23-1206	-12	-06
A-P2P23-1208	-12	-08
A-P2P23-1212	-12	-12
A-P2P23-1216	-12	-16
A-P2P23-1612	-16	-12
A-P2P23-1616	-16	-16
A-P2P23-1620	-16	-20
A-P2P23-2016	-20	-16
A-P2P23-2020	-20	-20
A-P2P23-2424	-24	-24
A-P2P23-3232	-32	-32

ADAPTERS

NPT

NPT

ADAPTERS



NPT Female x NPT Female		
Part Number	NPT F(T1)	NPT F(T2)
A-P68-0202	-02	-02
A-P68-0404	-04	-04
A-P68-0606	-06	-06
A-P68-0808	-08	-08
A-P68-1212	-12	-12
A-P68-1616	-16	-16
A-P68-2020	-20	-20
A-P68-3232	-32	-32



NPT Female x NPSM Female 45°		
Part Number	NPT F(T1)	NPSM F(T2)
A-P2P68-0202	-02	-02
A-P2P68-0204	-02	-04
A-P2P68-0404	-04	-04
A-P2P68-0406	-04	-06
A-P2P68-0604	-06	-04
A-P2P68-0606	-06	-06
A-P2P68-0608	-06	-08
A-P2P68-0806	-08	-06
A-P2P68-0808	-08	-08
A-P2P68-1208	-12	-08
A-P2P68-1212	-12	-12
A-P2P68-1612	-16	-12
A-P2P68-1616	-16	-16
A-P2P68-2020	-20	-20
A-P2P68-2424	-24	-24



NPT Male x NPT Male 90°		
Part Number	NPT M(T1)	NPT M(T2)
A-P18-0202	-02	-02
A-P18-0204	-02	-04
A-P18-0402	-04	-02
A-P18-0404	-04	-04
A-P18-0604	-06	-04
A-P18-0606	-06	-06
A-P18-0804	-08	-04
A-P18-0806	-08	-06
A-P18-0808	-08	-08
A-P18-1208	-12	-08
A-P18-1212	-12	-12
A-P18-1608	-16	-08
A-P18-1612	-16	-12
A-P18-1616	-16	-16
A-P18-2016	-20	-16
A-P18-2020	-20	-20
A-P18-2424	-24	-24
A-P18-3232	-32	-32

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x ORFS Male 90°		
Part Number	NPT M(T1)	ORFS M(T2)
A-PF18-0204	-02	-04
A-PF18-0206	-02	-06
A-PF18-0208	-02	-08
A-PF18-0404	-04	-04
A-PF18-0406	-04	-06
A-PF18-0408	-04	-08
A-PF18-0604	-06	-04
A-PF18-0606	-06	-06
A-PF18-0608	-06	-08
A-PF18-0804	-08	-04
A-PF18-0806	-08	-06
A-PF18-0808	-08	-08

CONTINUED

NPT Male x ORFS Male 90°		
Part Number	NPT M(T1)	ORFS M(T2)
A-PF18-0810	-08	-10
A-PF18-0812	-08	-12
A-PF18-1208	-12	-08
A-PF18-1210	-12	-10
A-PF18-1212	-12	-12
A-PF18-1216	-12	-16
A-PF18-1610	-16	-10
A-PF18-1612	-16	-12
A-PF18-1616	-16	-16
A-PF18-1620	-16	-20
A-PF18-2020	-20	-20
A-PF18-2424	-24	-24

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x JIC Male 90°

Part Number	NPT M(T1)	JIC M(T2)
A-PJ18-0202	-02	-02
A-PJ18-0203	-02	-03
A-PJ18-0204	-02	-04
A-PJ18-0205	-02	-05
A-PJ18-0206	-02	-06
A-PJ18-0208	-02	-08
A-PJ18-0402	-04	-02
A-PJ18-0403	-04	-03
A-PJ18-0404	-04	-04
A-PJ18-0405	-04	-05
A-PJ18-0406	-04	-06
A-PJ18-0408	-04	-08
A-PJ18-0604	-06	-04
A-PJ18-0605	-06	-05
A-PJ18-0606	-06	-06
A-PJ18-0608	-06	-08
A-PJ18-0610	-06	-10
A-PJ18-0612	-06	-12
A-PJ18-0804	-08	-04
A-PJ18-0805	-08	-05
A-PJ18-0806	-08	-06
A-PJ18-0808	-08	-08
A-PJ18-0810	-08	-10
A-PJ18-0812	-08	-12
A-PJ18-0814	-08	-14
A-PJ18-0816	-08	-16

CONTINUED

NPT Male x JIC Male 90°

Part Number	NPT M(T1)	JIC M(T2)
A-PJ18-1204	-12	-04
A-PJ18-1206	-12	-06
A-PJ18-1208	-12	-08
A-PJ18-1210	-12	-10
A-PJ18-1212	-12	-12
A-PJ18-1214	-12	-14
A-PJ18-1216	-12	-16
A-PJ18-1220	-12	-20
A-PJ18-1608	-16	-08
A-PJ18-1610	-16	-10
A-PJ18-1612	-16	-12
A-PJ18-1614	-16	-14
A-PJ18-1616	-16	-16
A-PJ18-1620	-16	-20
A-PJ18-1624	-16	-24
A-PJ18-2012	-20	-12
A-PJ18-2016	-20	-16
A-PJ18-2020	-20	-20
A-PJ18-2024	-20	-24
A-PJ18-2412	-24	-12
A-PJ18-2416	-24	-16
A-PJ18-2420	-24	-20
A-PJ18-2424	-24	-24
A-PJ18-2432	-24	-32
A-PJ18-3224	-32	-24
A-PJ18-3232	-32	-32
A-PJ18-4040	-40	-40

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x JIC Male 90° Long

Part Number	NPT M(T1)	JIC M(T2)
A-PJ20-0204	-02	-04
A-PJ20-0205	-02	-05
A-PJ20-0206	-02	-06
A-PJ20-0404	-04	-04
A-PJ20-0405	-04	-05
A-PJ20-0406	-04	-06
A-PJ20-0408	-04	-08
A-PJ20-0606	-06	-06
A-PJ20-0608	-06	-08
A-PJ20-0806	-08	-06
A-PJ20-0808	-08	-08
A-PJ20-0810	-08	-10
A-PJ20-0812	-08	-12
A-PJ20-1208	-12	-08
A-PJ20-1210	-12	-10
A-PJ20-1212	-12	-12
A-PJ20-1214	-12	-14
A-PJ20-1216	-12	-16
A-PJ20-1612	-16	-12
A-PJ20-1616	-16	-16
A-PJ20-2020	-20	-20
A-PJ20-2424	-24	-24

NPT Male x JIC Male 90° X-Long

Part Number	NPT M(T1)	JIC M(T2)
A-PJ21-0204	-02	-04
A-PJ21-0205	-02	-05
A-PJ21-0404	-04	-04
A-PJ21-0405	-04	-05
A-PJ21-0406	-04	-06
A-PJ21-0604	-06	-04
A-PJ21-0606	-06	-06
A-PJ21-0608	-06	-08
A-PJ21-0806	-08	-06
A-PJ21-0808	-08	-08
A-PJ21-0810	-08	-10
A-PJ21-0812	-08	-12
A-PJ21-1212	-12	-12
A-PJ21-1214	-12	-14
A-PJ21-1216	-12	-16
A-PJ21-1220	-12	-20
A-PJ21-1616	-16	-16
A-PJ21-2020	-20	-20
A-PJ21-2424	-24	-24

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x NPT Female 90°

Part Number	NPT M(T1)	NPT F(T2)
A-P24-0102	-01	-02
A-P24-0202	-02	-02
A-P24-0204	-02	-04
A-P24-0206	-02	-06
A-P24-0402	-04	-02
A-P24-0404	-04	-04
A-P24-0406	-04	-06
A-P24-0408	-04	-08
A-P24-0602	-06	-02
A-P24-0604	-06	-04
A-P24-0606	-06	-06
A-P24-0608	-06	-08
A-P24-0804	-08	-04
A-P24-0806	-08	-06
A-P24-0808	-08	-08
A-P24-0812	-08	-12
A-P24-1208	-12	-08
A-P24-1212	-12	-12
A-P24-1216	-12	-16
A-P24-1612	-16	-12
A-P24-1616	-16	-16
A-P24-1620	-16	-20
A-P24-2016	-20	-16
A-P24-2020	-20	-20
A-P24-2420	-24	-20
A-P24-2424	-24	-24
A-P24-3232	-32	-32



NPT Male x NPSM Female 90°

Part Number	NPT M(T1)	NPSM F(T2)
A-P2P24-0202	-02	-02
A-P2P24-0204	-02	-04
A-P2P24-0402	-04	-02
A-P2P24-0404	-04	-04
A-P2P24-0406	-04	-06
A-P2P24-0408	-04	-08
A-P2P24-0604	-06	-04
A-P2P24-0606	-06	-06
A-P2P24-0608	-06	-08
A-P2P24-0612	-06	-12
A-P2P24-0804	-08	-04
A-P2P24-0806	-08	-06
A-P2P24-0808	-08	-08
A-P2P24-0812	-08	-12
A-P2P24-1204	-12	-04
A-P2P24-1206	-12	-06
A-P2P24-1208	-12	-08
A-P2P24-1212	-12	-12
A-P2P24-1216	-12	-16
A-P2P24-1220	-12	-20
A-P2P24-1608	-16	-08
A-P2P24-1612	-16	-12
A-P2P24-1616	-16	-16
A-P2P24-1620	-16	-20
A-P2P24-2012	-20	-12
A-P2P24-2016	-20	-16
A-P2P24-2020	-20	-20
A-P2P24-2024	-20	-24
A-P2P24-2420	-24	-20
A-P2P24-2424	-24	-24
A-P2P24-3232	-32	-32

ADAPTERS

NPT

NPT

ADAPTERS



NPT Male x JIC Female 90°

Part Number	NPT M(T1)	JIC M(T2)
A-PJ24-0204	-02	-04
A-PJ24-0205	-02	-05
A-PJ24-0404	-04	-04
A-PJ24-0405	-04	-05
A-PJ24-0406	-04	-06
A-PJ24-0604	-06	-04
A-PJ24-0606	-06	-06
A-PJ24-0608	-06	-08
A-PJ24-0806	-08	-06
A-PJ24-0808	-08	-08
A-PJ24-0810	-08	-10
A-PJ24-0812	-08	-12
A-PJ24-1208	-12	-08
A-PJ24-1212	-12	-12
A-PJ24-1214	-12	-14
A-PJ24-1616	-16	-16
A-PJ24-2020	-20	-20
A-PJ24-2424	-24	-24
A-PJ24-3232	-32	-32

NPT Female x JIC Male 90°

Part Number	NPT F(T1)	JIC M(T2)
A-PJ63-0202	-02	-02
A-PJ63-0203	-02	-03
A-PJ63-0204	-02	-04
A-PJ63-0205	-02	-05
A-PJ63-0206	-02	-06
A-PJ63-0404	-04	-04
A-PJ63-0405	-04	-05
A-PJ63-0406	-04	-06
A-PJ63-0408	-04	-08
A-PJ63-0604	-06	-04
A-PJ63-0605	-06	-05
A-PJ63-0606	-06	-06
A-PJ63-0608	-06	-08
A-PJ63-0610	-06	-10
A-PJ63-0804	-08	-04
A-PJ63-0805	-08	-05
A-PJ63-0806	-08	-06
A-PJ63-0808	-08	-08
A-PJ63-0810	-08	-10
A-PJ63-0812	-08	-12
A-PJ63-1208	-12	-08
A-PJ63-1210	-12	-10
A-PJ63-1212	-12	-12
A-PJ63-1214	-12	-14
A-PJ63-1216	-12	-16
A-PJ63-1608	-16	-08
A-PJ63-1612	-16	-12
A-PJ63-1616	-16	-16
A-PJ63-2016	-20	-16
A-PJ63-2020	-20	-20
A-PJ63-2424	-24	-24
A-PJ63-3232	-32	-32

ADAPTERS

NPT



NPT Female x NPT Female 90°

Part Number	NPT F(T1)	NPT F(T2)
A-P69-0202	-02	-02
A-P69-0402	-04	-02
A-P69-0404	-04	-04
A-P69-0604	-06	-04
A-P69-0606	-06	-06
A-P69-0804	-08	-04
A-P69-0806	-08	-06
A-P69-0808	-08	-08
A-P69-1208	-12	-08
A-P69-1212	-12	-12
A-P69-1612	-16	-12
A-P69-1616	-16	-16
A-P69-2012	-20	-12
A-P69-2020	-20	-20
A-P69-2424	-24	-24
A-P69-3232	-32	-32

NPT Female x NPSM Female 90°

Part Number	NPT F(T1)	NPSM F(T2)
A-P2P69-0202	-02	-02
A-P2P69-0204	-02	-04
A-P2P69-0402	-04	-02
A-P2P69-0404	-04	-04
A-P2P69-0406	-04	-06
A-P2P69-0604	-06	-04
A-P2P69-0606	-06	-06
A-P2P69-0608	-06	-08
A-P2P69-0804	-08	-04
A-P2P69-0806	-08	-06
A-P2P69-0808	-08	-08
A-P2P69-0812	-08	-12
A-P2P69-1208	-12	-08
A-P2P69-1212	-12	-12
A-P2P69-1216	-12	-16
A-P2P69-1612	-16	-12
A-P2P69-1616	-16	-16
A-P2P69-2016	-20	-16
A-P2P69-2020	-20	-20
A-P2P69-2424	-24	-24
A-P2P69-3232	-32	-32

NPT

ADAPTERS



NPT Male x ORFS Bulkhead		
Part Number	Thread 1(T1)	Thread 2(T2)
A-PF13LN-0204	-02	-04
A-PF13LN-0404	-04	-04
A-PF13LN-0406	-04	-06
A-PF13LN-0606	-06	-06
A-PF13LN-0808	-08	-08
A-PF13LN-1212	-12	-12
A-PF13LN-1616	-16	-16



NPT Male x JIC Bulkhead		
Part Number	NPT M(T1)	JIC M(T2)
A-PJ13LN-0204	-02	-04
A-PJ13LN-0404	-04	-04
A-PJ13LN-0406	-04	-06
A-PJ13LN-0604	-06	-04
A-PJ13LN-0606	-06	-06
A-PJ13LN-0608	-06	-08
A-PJ13LN-0806	-08	-06
A-PJ13LN-0808	-08	-08
A-PJ13LN-0810	-08	-10
A-PJ13LN-1212	-12	-12
A-PJ13LN-1616	-16	-16
A-PJ13LN-2020	-20	-20
A-PJ13LN-2424	-24	-24
A-PJ13LN-3232	-32	-32



NPT Female x JIC Bulkhead		
Part Number	NPT F(T1)	JIC M(T2)
A-PJ58LN-0204	-02	-04
A-PJ58LN-0402	-04	-02
A-PJ58LN-0404	-04	-04
A-PJ58LN-0406	-04	-06
A-PJ58LN-0604	-06	-04
A-PJ58LN-0606	-06	-06
A-PJ58LN-0608	-06	-08
A-PJ58LN-0806	-08	-06
A-PJ58LN-0808	-08	-08
A-PJ58LN-0810	-08	-10
A-PJ58LN-0812	-08	-12
A-PJ58LN-1212	-12	-12
A-PJ58LN-1616	-16	-16
A-PJ58LN-2020	-20	-20
A-PJ58LN-2424	-24	-24



NPT Male Branch Tee		
Part Number	NPT M(T1)	NPT M(T2)
A-P5-18-0202	-02	-02
A-P5-18-0404	-04	-04
A-P5-18-0606	-06	-06
A-P5-18-0808	-08	-08
A-P5-18-1212	-12	-12
A-P5-18-1616	-16	-16

ADAPTERS

NPT

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

NPT

ADAPTERS



NPT Male x JIC Male Branch Tee

Part Number	NPT M(T1)	JIC M(T2)
A-PJ5-18-0203	-02	-03
A-PJ5-18-0204	-02	-04
A-PJ5-18-0205	-02	-05
A-PJ5-18-0404	-04	-04
A-PJ5-18-0405	-04	-05
A-PJ5-18-0406	-04	-06
A-PJ5-18-0408	-04	-08
A-PJ5-18-0604	-06	-04
A-PJ5-18-0606	-06	-06
A-PJ5-18-0608	-06	-08
A-PJ5-18-0610	-06	-10
A-PJ5-18-0806	-08	-06
A-PJ5-18-0808	-08	-08
A-PJ5-18-0810	-08	-10
A-PJ5-18-0812	-08	-12
A-PJ5-18-1208	-12	-08
A-PJ5-18-1210	-12	-10
A-PJ5-18-1212	-12	-12
A-PJ5-18-1214	-12	-14
A-PJ5-18-1216	-12	-16
A-PJ5-18-1612	-16	-12
A-PJ5-18-1616	-16	-16
A-PJ5-18-2020	-20	-20
A-PJ5-18-2424	-24	-24
A-PJ5-18-3232	-32	-32



NPT Male x NPT Female Branch Tee

Part Number	NPT M(T1)	NPT F(T2)
A-P5-24-0202	-02	-02
A-P5-24-0404	-04	-04
A-P5-24-0606	-06	-06
A-P5-24-0808	-08	-08
A-P5-24-1212	-12	-12
A-P5-24-1616	-16	-16
A-P5-24-2020	-20	-20
A-P5-24-2424	-24	-24
A-P5-24-3232	-32	-32

ADAPTERS

NPT

NPT

ADAPTERS



NPT Female x NPT Male Branch Tee

Part Number	NPT F(T1)	NPT M(T2)
A-P5-63-0202	-02	-02
A-P5-63-0404	-04	-04
A-P5-63-0606	-06	-06
A-P5-63-0808	-08	-08
A-P5-63-1212	-12	-12
A-P5-63-1616	-16	-16
A-P5-63-2020	-20	-20
A-P5-63-2424	-24	-24



NPT Female x JIC Male Branch Tee

Part Number	NPT F(T1)	JIC M(T2)
A-PJ5-63-0202	-02	-02
A-PJ5-63-0203	-02	-03
A-PJ5-63-0204	-02	-04
A-PJ5-63-0205	-02	-05
A-PJ5-63-0404	-04	-04
A-PJ5-63-0405	-04	-05
A-PJ5-63-0406	-04	-06
A-PJ5-63-0408	-04	-08
A-PJ5-63-0606	-06	-06
A-PJ5-63-0608	-06	-08
A-PJ5-63-0806	-08	-06
A-PJ5-63-0808	-08	-08
A-PJ5-63-0810	-08	-10
A-PJ5-63-0812	-08	-12
A-PJ5-63-1210	-12	-10
A-PJ5-63-1212	-12	-12
A-PJ5-63-1214	-12	-14
A-PJ5-63-1216	-12	-16
A-PJ5-63-1612	-16	-12
A-PJ5-63-1616	-16	-16
A-PJ5-63-2020	-20	-20
A-PJ5-63-2424	-24	-24
A-PJ5-63-3232	-32	-32

ADAPTERS

NPT

NPT

ADAPTERS

ADAPTERS

NPT



NPT Female Branch Tee		
Part Number	NPT F(T1)	NPT F(T2)
A-P5-69-0202	-02	-02
A-P5-69-0404	-04	-04
A-P5-69-0606	-06	-06
A-P5-69-0808	-08	-08
A-P5-69-1212	-12	-12
A-P5-69-1616	-16	-16
A-P5-69-2020	-20	-20
A-P5-69-2424	-24	-24
A-P5-69-3232	-32	-32



NPT x NPSM Female Branch Tee		
Part Number	NPT F(T1)	NPSM F(T2)
A-P2P5-69-0202	-02	-02
A-P2P5-69-0404	-04	-04
A-P2P5-69-0606	-06	-06
A-P2P5-69-0806	-08	-06
A-P2P5-69-0808	-08	-08
A-P2P5-69-1208	-12	-08
A-P2P5-69-1212	-12	-12
A-P2P5-69-1616	-16	-16
A-P2P5-69-2020	-20	-20



NPSM Female Branch Tee		
Part Number	NPSM F(T1)	NPSM F(T2)
A-2P5-69-0202	-02	-02
A-2P5-69-0404	-04	-04
A-2P5-69-0606	-06	-06
A-2P5-69-0808	-08	-08
A-2P5-69-1212	-12	-12
A-2P5-69-1616	-16	-16
A-2P5-69-2020	-20	-20



NPT Male x JIC Male Run Tee		
Part Number	NPT M(T1)	JIC M(T2)
A-PJ6-18-0203	-02	-03
A-PJ6-18-0204	-02	-04
A-PJ6-18-0205	-02	-05
A-PJ6-18-0206	-02	-06
A-PJ6-18-0404	-04	-04
A-PJ6-18-0405	-04	-05
A-PJ6-18-0406	-04	-06
A-PJ6-18-0408	-04	-08
A-PJ6-18-0604	-06	-04
A-PJ6-18-0606	-06	-06
A-PJ6-18-0608	-06	-08
A-PJ6-18-0806	-08	-06
A-PJ6-18-0808	-08	-08
A-PJ6-18-0810	-08	-10
A-PJ6-18-0812	-08	-12
A-PJ6-18-1208	-12	-08
A-PJ6-18-1210	-12	-10
A-PJ6-18-1212	-12	-12
A-PJ6-18-1214	-12	-14
A-PJ6-18-1216	-12	-16
A-PJ6-18-1616	-16	-16
A-PJ6-18-2020	-20	-20
A-PJ6-18-2424	-24	-24
A-PJ6-18-3232	-32	-32

NPT

ADAPTERS

ADAPTERS

NPT



NPT Male x NPT Female Branch Tee

Part Number	NPT M(T1)	NPT F(T2)
A-P6-24-0202	-02	-02
A-P6-24-0404	-04	-04
A-P6-24-0606	-06	-06
A-P6-24-0808	-08	-08
A-P6-24-1212	-12	-12
A-P6-24-1616	-16	-16
A-P6-24-2020	-20	-20
A-P6-24-2424	-24	-24
A-P6-24-3232	-32	-32



NPT Female x NPT Male Run Tee

Part Number	NPT F(T1)	NPT M(T2)
A-P6-63-0202	-02	-02
A-P6-63-0404	-04	-04
A-P6-63-0606	-06	-06
A-P6-63-0808	-08	-08
A-P6-63-1212	-12	-12
A-P6-63-1616	-16	-16
A-P6-63-2020	-20	-20
A-P6-63-2424	-24	-24



NPT Female x JIC Male Run Tee

Part Number	NPT F(T1)	JIC M(T2)
A-PJ6-63-0203	-02	-03
A-PJ6-63-0204	-02	-04
A-PJ6-63-0205	-02	-05
A-PJ6-63-0404	-04	-04
A-PJ6-63-0406	-04	-06
A-PJ6-63-0606	-06	-06
A-PJ6-63-0608	-06	-08
A-PJ6-63-0808	-08	-08
A-PJ6-63-0810	-08	-10
A-PJ6-63-1212	-12	-12
A-PJ6-63-1214	-12	-14
A-PJ6-63-1616	-16	-16
A-PJ6-63-2020	-20	-20
A-PJ6-63-2424	-24	-24
A-PJ6-63-3232	-32	-32



NPT Female x ORFS M x F Run Tee

Part Number	NPT F(T1)	ORFS MxF(T2)
A-PF6-69-0404	-04	-04
A-PF6-69-0406	-04	-06
A-PF6-69-0408	-04	-08
A-PF6-69-0410	-04	-10
A-PF6-69-0412	-04	-12
A-PF6-69-0416	-04	-16
A-PF6-69-0420	-04	-20
A-PF6-69-0424	-04	-24

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

NPT

ADAPTERS



NPT Female x JIC M x F Run Tee		
Part Number	NPT F(T1)	JIC MxF(T2)
A-PJ6-69-0404	-04	-04
A-PJ6-69-0406	-04	-06
A-PJ6-69-0408	-04	-08
A-PJ6-69-0410	-04	-10
A-PJ6-69-0412	-04	-12
A-PJ6-69-0416	-04	-16
A-PJ6-69-0420	-04	-20
A-PJ6-69-0424	-04	-24



NPT Female Cross		
Part Number	NPT F(T1)	NPT F(T2)
A-P7-69-0202	-02	-02
A-P7-69-0404	-04	-04
A-P7-69-0606	-06	-06
A-P7-69-0808	-08	-08
A-P7-69-1212	-12	-12
A-P7-69-1616	-16	-16
A-P7-69-2020	-20	-20
A-P7-69-2424	-24	-24
A-P7-69-3232	-32	-32

ADAPTERS

NPT

ORFS

ADAPTERS



ORFS Hex Plug

Part Number	ORFS M
A-F1-04	-04
A-F1-06	-06
A-F1-08	-08
A-F1-10	-10
A-F1-12	-12
A-F1-16	-16
A-F1-20	-20
A-F1-24	-24



ORFS Cap

Part Number	ORFS F
A-F3-04	-04
A-F3-06	-06
A-F3-08	-08
A-F3-10	-10
A-F3-12	-12
A-F3-16	-16
A-F3-20	-20
A-F3-24	-24



ORFS Male x ORFS Male

Part Number	ORFS M(T1)	ORFS M(T2)
A-F10-0404	-04	-04
A-F10-0604	-06	-04
A-F10-0606	-06	-06
A-F10-0806	-08	-06
A-F10-0808	-08	-08
A-F10-1008	-10	-08
A-F10-1010	-10	-10
A-F10-1208	-12	-08
A-F10-1210	-12	-10
A-F10-1212	-12	-12
A-F10-1612	-16	-12
A-F10-1616	-16	-16
A-F10-2016	-20	-16
A-F10-2020	-20	-20
A-F10-2420	-24	-20
A-F10-2424	-24	-24



ORFS Male x JIC Male

Part Number	ORFS M(T1)	JIC M(T2)
A-FJ10-0404	-04	-04
A-FJ10-0606	-06	-06
A-FJ10-0808	-08	-08
A-FJ10-1010	-10	-10
A-FJ10-1212	-12	-12
A-FJ10-1616	-16	-16
A-FJ10-2020	-20	-20
A-FJ10-2424	-24	-24

ADAPTERS

ORFS



ORFS Male x ORFS Female		
Part Number	ORFS M(T1)	ORFS F(T2)
A-F22-0404	-04	-04
A-F22-0406	-04	-06
A-F22-0408	-04	-08
A-F22-0410	-04	-10
A-F22-0412	-04	-12
A-F22-0604	-06	-04
A-F22-0606	-06	-06
A-F22-0608	-06	-08
A-F22-0610	-06	-10
A-F22-0612	-06	-12
A-F22-0804	-08	-04
A-F22-0806	-08	-06
A-F22-0808	-08	-08
A-F22-0810	-08	-10
A-F22-0812	-08	-12
A-F22-0816	-08	-16
A-F22-1008	-10	-08
CONTINUED		



ORFS Male x ORFS Female		
Part Number	ORFS M(T1)	ORFS F(T2)
A-F22-1010	-10	-10
A-F22-1012	-10	-12
A-F22-1016	-10	-16
A-F22-1208	-12	-08
A-F22-1210	-12	-10
A-F22-1212	-12	-12
A-F22-1216	-12	-16
A-F22-1220	-12	-20
A-F22-1224	-12	-24
A-F22-1612	-16	-12
A-F22-1616	-16	-16
A-F22-1620	-16	-20
A-F22-1624	-16	-24
A-F22-2016	-20	-16
A-F22-2020	-20	-20
A-F22-2024	-20	-24
A-F22-2420	-24	-20
A-F22-2424	-24	-24



ORFS Male x JIC Female		
Part Number	ORFS M(T1)	JIC F(T2)
A-FJ22-0404	-04	-04
A-FJ22-0606	-06	-06
A-FJ22-0808	-08	-08
A-FJ22-1010	-10	-10
A-FJ22-1212	-12	-12
A-FJ22-1616	-16	-16
A-FJ22-2020	-20	-20



ORFS Female x JIC Male		
Part Number	ORFS F(T1)	JIC M(T2)
A-FJ55-0404	-04	-04
A-FJ55-0406	-04	-06
A-FJ55-0412	-04	-12
A-FJ55-0606	-06	-06
A-FJ55-0612	-06	-12
A-FJ55-0806	-08	-06
A-FJ55-0808	-08	-08
A-FJ55-0812	-08	-12
A-FJ55-1010	-10	-10
A-FJ55-1210	-12	-10
A-FJ55-1212	-12	-12
A-FJ55-1612	-16	-12
A-FJ55-1616	-16	-16
A-FJ55-2016	-20	-16
A-FJ55-2020	-20	-20
A-FJ55-2424	-24	-24

ORFS

ADAPTERS

ADAPTERS

ORFS



ORFS Female x ORFS Female		
Part Number	ORFS F(T1)	ORFS F(T2)
A-F67-0404	-04	-04
A-F67-0606	-06	-06
A-F67-0808	-08	-08
A-F67-1010	-10	-10
A-F67-1212	-12	-12
A-F67-1616	-16	-16
A-F67-2020	-20	-20
A-F67-2424	-24	-24



ORFS Male x ORFS Female 45°		
Part Number	ORFS M(T1)	ORFS F(T2)
A-F23-0404	-04	-04
A-F23-0606	-06	-06
A-F23-0808	-08	-08
A-F23-1010	-10	-10
A-F23-1212	-12	-12
A-F23-1616	-16	-16
A-F23-2020	-20	-20
A-F23-2424	-24	-24



ORFS Male x ORFS Male 90°		
Part Number	ORFS M(T1)	ORFS M(T2)
A-F18-0404	-04	-04
A-F18-0604	-06	-04
A-F18-0606	-06	-06
A-F18-0804	-08	-04
A-F18-0808	-08	-08
A-F18-1010	-10	-10
A-F18-1208	-12	-08
A-F18-1212	-12	-12
A-F18-1616	-16	-16
A-F18-2020	-20	-20
A-F18-2424	-24	-24



ORFS Male x ORFS Female		
Part Number	ORFS M(T1)	ORFS F(T2)
A-F24-0404	-04	-04
A-F24-0406	-04	-06
A-F24-0606	-06	-06
A-F24-0806	-08	-06
A-F24-0808	-08	-08
A-F24-0812	-08	-12
A-F24-1010	-10	-10
A-F24-1212	-12	-12
A-F24-1616	-16	-16
A-F24-2020	-20	-20
A-F24-2420	-24	-20
A-F24-2424	-24	-24

ORFS

ADAPTERS



ORFS Bulkhead x ORFS Male

Part Number	ORFS M(T1)	ORFS M(T2)
A-F40LN-0404	-04	-04
A-F40LN-0606	-06	-06
A-F40LN-0806	-08	-06
A-F40LN-0808	-08	-08
A-F40LN-0810	-08	-10
A-F40LN-1008	-10	-08
A-F40LN-1010	-10	-10
A-F40LN-1212	-12	-12
A-F40LN-1216	-12	-16
A-F40LN-1616	-16	-16
A-F40LN-2020	-20	-20
A-F40LN-2424	-24	-24



ORFS Bulkhead x ORFS Male 45°

Part Number	ORFS M(T1)	ORFS M(T2)
A-F44LN-0404	-04	-04
A-F44LN-0604	-06	-04
A-F44LN-0606	-06	-06
A-F44LN-0806	-08	-06
A-F44LN-0808	-08	-08
A-F44LN-0810	-08	-10
A-F44LN-1008	-10	-08
A-F44LN-1010	-10	-10
A-F44LN-1212	-12	-12
A-F44LN-1616	-16	-16
A-F44LN-2020	-20	-20
A-F44LN-2424	-24	-24



ORFS Bulkhead x ORFS Male 90°

Part Number	ORFS M(T1)	ORFS M(T2)
A-F48LN-0404	-04	-04
A-F48LN-0606	-06	-06
A-F48LN-0608	-06	-08
A-F48LN-0806	-08	-06
A-F48LN-0808	-08	-08
A-F48LN-1008	-10	-08
A-F48LN-1010	-10	-10
A-F48LN-1212	-12	-12
A-F48LN-1616	-16	-16
A-F48LN-2020	-20	-20
A-F48LN-2424	-24	-24



ORFS Bulkhead Nut

Part Number	ORFS
A-F4-04	-04
A-F4-06	-06
A-F4-08	-08
A-F4-10	-10
A-F4-12	-12
A-F4-16	-16
A-F4-20	-20
A-F4-24	-24

ADAPTERS

ORFS

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

ORFS

ADAPTERS



ORFS Male Branch Tee

Part Number	ORFS M(T1)	ORFS M(T2)
A-F5-18-0404	-04	-04
A-F5-18-0412	-04	-12
A-F5-18-0606	-06	-06
A-F5-18-0608	-06	-08
A-F5-18-0612	-06	-12
A-F5-18-0806	-08	-06
A-F5-18-0808	-08	-08
A-F5-18-1010	-10	-10
A-F5-18-1210	-12	-10
A-F5-18-1212	-12	-12
A-F5-18-1216	-12	-16
A-F5-18-1612	-16	-12
A-F5-18-1616	-16	-16
A-F5-18-1620	-16	-20
A-F5-18-2020	-20	-20
A-F5-18-2424	-24	-24



ORFS Female x Male Branch Tee

Part Number	ORFS F(T1)	ORFS M(T2)
A-F5-63-0404	-04	-04
A-F5-63-0606	-06	-06
A-F5-63-0808	-08	-08
A-F5-63-1010	-10	-10
A-F5-63-1212	-12	-12
A-F5-63-1616	-16	-16
A-F5-63-2020	-20	-20
A-F5-63-2424	-24	-24

ADAPTERS

ORFS

ORFS

ADAPTERS

ADAPTERS

ORFS



ORFS Female x Male Run Tee

Part Number	ORFS F(T1)	ORFS M(T2)
A-F6-63-0404	-04	-04
A-F6-63-0606	-06	-06
A-F6-63-0808	-08	-08
A-F6-63-1010	-10	-10
A-F6-63-1212	-12	-12
A-F6-63-1616	-16	-16
A-F6-63-2020	-20	-20
A-F6-63-2424	-24	-24



ORFS Bulkhead Branch Tee

Part Number	ORFS M(T1)	ORFS M(T2)
A-F5-48LN-0404	-04	-04
A-F5-48LN-0606	-06	-06
A-F5-48LN-0808	-08	-08
A-F5-48LN-1010	-10	-10
A-F5-48LN-1212	-12	-12
A-F5-48LN-1616	-16	-16
A-F5-48LN-2020	-20	-20
A-F5-48LN-2424	-24	-24



ORFS Bulkhead Run Tee

Part Number	ORFS M(T1)	ORFS M(T2)
A-F6-48LN-0404	-04	-04
A-F6-48LN-0606	-06	-06
A-F6-48LN-0808	-08	-08
A-F6-48LN-1010	-10	-10
A-F6-48LN-1212	-12	-12
A-F6-48LN-1616	-16	-16
A-F6-48LN-2020	-20	-20
A-F6-48LN-2424	-24	-24

JIC

ADAPTERS



JIC HEX PLUG

Part Number	JIC M
A-J1-02	-02
A-J1-03	-03
A-J1-04	-04
A-J1-05	-05
A-J1-06	-06
A-J1-08	-08
A-J1-10	-10
A-J1-12	-12
A-J1-14	-14
A-J1-16	-16
A-J1-20	-20
A-J1-24	-24
A-J1-32	-32



JIC CAP

Part Number	JIC F
A-J3-02	-02
A-J3-03	-03
A-J3-04	-04
A-J3-05	-05
A-J3-06	-06
A-J3-08	-08
A-J3-10	-10
A-J3-12	-12
A-J3-14	-14
A-J3-16	-16
A-J3-20	-20
A-J3-24	-24
A-J3-32	-32



JIC Male x JIC Male

Part Number	JIC M(T1)	JIC M(T2)
A-J10-0202	-02	-02
A-J10-0302	-03	-02
A-J10-0303	-03	-03
A-J10-0402	-04	-02
A-J10-0403	-04	-03
A-J10-0404	-04	-04
A-J10-0504	-05	-04
A-J10-0505	-05	-05
A-J10-0604	-06	-04
A-J10-0605	-06	-05
A-J10-0606	-06	-06
A-J10-0804	-08	-04
A-J10-0805	-08	-05
A-J10-0806	-08	-06
A-J10-0808	-08	-08
A-J10-1004	-10	-04
A-J10-1005	-10	-05
A-J10-1006	-10	-06
A-J10-1008	-10	-08
A-J10-1010	-10	-10

CONTINUED



JIC Male x JIC Male

Part Number	JIC M(T1)	JIC M(T2)
A-J10-1204	-12	-04
A-J10-1206	-12	-06
A-J10-1208	-12	-08
A-J10-1210	-12	-10
A-J10-1212	-12	-12
A-J10-1412	-14	-12
A-J10-1414	-14	-14
A-J10-1608	-16	-08
A-J10-1610	-16	-10
A-J10-1612	-16	-12
A-J10-1616	-16	-16
A-J10-2012	-20	-12
A-J10-2016	-20	-16
A-J10-2020	-20	-20
A-J10-2412	-24	-12
A-J10-2416	-24	-16
A-J10-2420	-24	-20
A-J10-2424	-24	-24
A-J10-3224	-32	-24
A-J10-3232	-32	-32

ADAPTERS

JIC

JIC

ADAPTERS



JIC Male x JIC Female		
Part Number	JIC M(T1)	JIC F(T2)
A-J22-0204	-02	-04
A-J22-0304	-03	-04
A-J22-0402	-04	-02
A-J22-0403	-04	-03
A-J22-0404	-04	-04
A-J22-0405	-04	-05
A-J22-0406	-04	-06
A-J22-0408	-04	-08
A-J22-0410	-04	-10
A-J22-0412	-04	-12
A-J22-0416	-04	-16
A-J22-0504	-05	-04
A-J22-0505	-05	-05
A-J22-0506	-05	-06
A-J22-0508	-05	-08
A-J22-0604	-06	-04
A-J22-0605	-06	-05
A-J22-0606	-06	-06
A-J22-0608	-06	-08
A-J22-0610	-06	-10
A-J22-0612	-06	-12
A-J22-0614	-06	-14
A-J22-0616	-06	-16
A-J22-0804	-08	-04
A-J22-0805	-08	-05
A-J22-0806	-08	-06
A-J22-0808	-08	-08
A-J22-0810	-08	-10
A-J22-0812	-08	-12
A-J22-0814	-08	-14
A-J22-0816	-08	-16
A-J22-0820	-08	-20
A-J22-0824	-08	-24
A-J22-1004	-10	-04
A-J22-1006	-10	-06
CONTINUED		

JIC Male x JIC Female		
Part Number	JIC M(T1)	JIC F(T2)
A-J22-1008	-10	-08
A-J22-1010	-10	-10
A-J22-1012	-10	-12
A-J22-1014	-10	-14
A-J22-1016	-10	-16
A-J22-1020	-10	-20
A-J22-1032	-10	-32
A-J22-1204	-12	-04
A-J22-1206	-12	-06
A-J22-1208	-12	-08
A-J22-1210	-12	-10
A-J22-1212	-12	-12
A-J22-1214	-12	-14
A-J22-1216	-12	-16
A-J22-1220	-12	-20
A-J22-1224	-12	-24
A-J22-1412	-14	-12
A-J22-1416	-14	-16
A-J22-1608	-16	-08
A-J22-1612	-16	-12
A-J22-1614	-16	-14
A-J22-1616	-16	-16
A-J22-1620	-16	-20
A-J22-1624	-16	-24
A-J22-1632	-16	-32
A-J22-2012	-20	-12
A-J22-2016	-20	-16
A-J22-2020	-20	-20
A-J22-2024	-20	-24
A-J22-2032	-20	-32
A-J22-2416	-24	-16
A-J22-2420	-24	-20
A-J22-2424	-24	-24
A-J22-2432	-24	-32
A-J22-3224	-32	-24
A-J22-3232	-32	-32

ADAPTERS

JIC

Ph. 780-413-0904
 Fax 780-413-0905
 Toll Free 1-800-239-0416



18141 - 111 Avenue
 Edmonton, Alberta T5S 2P2
 boschhydraulic.com

JIC

ADAPTERS



JIC Female x JIC Female		
Part Number	JIC F(T1)	JIC F(T2)
A-J67-0404	-04	-04
A-J67-0505	-05	-05
A-J67-0604	-06	-04
A-J67-0605	-06	-05
A-J67-0606	-06	-06
A-J67-0804	-08	-04
A-J67-0806	-08	-06
A-J67-0808	-08	-08
A-J67-1008	-10	-08
A-J67-1010	-10	-10
A-J67-1208	-12	-08
A-J67-1210	-12	-10
A-J67-1212	-12	-12
A-J67-1612	-16	-12
A-J67-1616	-16	-16
A-J67-2020	-20	-20
A-J67-2424	-24	-24
A-J67-3232	-32	-32

JIC Male x JIC Male 45°		
Part Number	JIC M(T1)	JIC M(T2)
A-J14-0303	-3	-03
A-J14-0404	-04	-04
A-J14-0604	-06	-04
A-J14-0606	-06	-06
A-J14-0808	-08	-08
A-J14-1010	-10	-10
A-J14-1212	-12	-12
A-J14-1616	-16	-16

ADAPTERS

JIC



JIC Male x JIC Female 45°

Part Number	JIC M(T1)	JIC F(T2)
A-J23-0202	-02	-02
A-J23-0404	-04	-04
A-J23-0505	-05	-05
A-J23-0606	-06	-06
A-J23-0808	-08	-08
A-J23-1010	-10	-10
A-J23-1212	-12	-12
A-J23-1414	-14	-14
A-J23-1612	-16	-12
A-J23-1616	-16	-16
A-J23-2020	-20	-20
A-J23-2424	-24	-24
A-J23-3232	-32	-32

JIC Male x JIC Male 90°

Part Number	JIC M(T1)	JIC M(T2)
A-J18-0202	-02	-02
A-J18-0303	-03	-03
A-J18-0404	-04	-04
A-J18-0504	-05	-04
A-J18-0505	-05	-05
A-J18-0604	-06	-04
A-J18-0605	-06	-05
A-J18-0606	-06	-06
A-J18-0804	-08	-04
A-J18-0806	-08	-06
A-J18-0808	-08	-08
A-J18-1008	-10	-08
A-J18-1010	-10	-10
A-J18-1208	-12	-08
A-J18-1210	-12	-10
A-J18-1212	-12	-12
A-J18-1414	-14	-14
A-J18-1612	-16	-12
A-J18-1616	-16	-16
A-J18-2016	-20	-16
A-J18-2020	-20	-20
A-J18-2424	-24	-24
A-J18-3232	-32	-32

JIC

ADAPTERS



JIC Male x JIC Female 90°		
Part Number	JIC M(T1)	JIC F(T2)
A-J24-0202	-02	-02
A-J24-0303	-03	-03
A-J24-0404	-04	-04
A-J24-0406	-04	-06
A-J24-0505	-05	-05
A-J24-0604	-06	-04
A-J24-0606	-06	-06
A-J24-0608	-06	-08
A-J24-0806	-08	-06
A-J24-0808	-08	-08
A-J24-0810	-08	-10
A-J24-0812	-08	-12
A-J24-1008	-10	-08
A-J24-1010	-10	-10
A-J24-1012	-10	-12
A-J24-1016	-10	-16
A-J24-1208	-12	-08
A-J24-1210	-12	-10
A-J24-1212	-12	-12
A-J24-1216	-12	-16
A-J24-1414	-14	-14
A-J24-1612	-16	-12
A-J24-1616	-16	-16
A-J24-2020	-20	-20
A-J24-2424	-24	-24
A-J24-3232	-32	-32

JIC Male x JIC Female 90° Long		
Part Number	JIC M(T1)	JIC F(T2)
A-J24L-0404	-04	-04
A-J24L-0606	-06	-06
A-J24L-0808	-08	-08
A-J24L-1010	-10	-10
A-J24L-1212	-12	-12
A-J24L-1616	-16	-16
A-J24L-2020	-20	-20

ADAPTERS

JIC

JIC

ADAPTERS



JIC Female x JIC Female 90°		
Part Number	JIC F(T1)	JIC F(T2)
A-J69-0404	-04	-04
A-J69-0505	-05	-05
A-J69-0606	-06	-06
A-J69-0808	-08	-08
A-J69-1010	-10	-10
A-J69-1212	-12	-12
A-J69-1616	-16	-16



JIC Bulkhead X JIC Male		
Part Number	JIC M(T1)	JIC M(T2)
A-J40LN-0303	-03	-03
A-J40LN-0404	-04	-04
A-J40LN-0406	-04	-06
A-J40LN-0505	-05	-05
A-J40LN-0604	-06	-04
A-J40LN-0606	-06	-06
A-J40LN-0808	-08	-08
A-J40LN-1010	-10	-10
A-J40LN-1212	-12	-12
A-J40LN-1216	-12	-16
A-J40LN-1414	-14	-14
A-J40LN-1616	-16	-16
A-J40LN-2020	-20	-20
A-J40LN-2424	-24	-24
A-J40LN-3232	-32	-32



JIC Bulkhead X JIC Male 45°		
Part Number	JIC M(T1)	JIC M(T2)
A-J44LN-0303	-03	-03
A-J44LN-0404	-04	-04
A-J44LN-0505	-05	-05
A-J44LN-0606	-06	-06
A-J44LN-0608	-06	-08
A-J44LN-0808	-08	-08
A-J44LN-1010	-10	-10
A-J44LN-1212	-12	-12
A-J44LN-1616	-16	-16
A-J44LN-2020	-20	-20
A-J44LN-2424	-24	-24
A-J44LN-3232	-32	-32



JIC Bulkhead X JIC Male 90°		
Part Number	JIC M(T1)	JIC M(T2)
A-J48LN-0303	-03	-03
A-J48LN-0404	-04	-04
A-J48LN-0505	-05	-05
A-J48LN-0606	-06	-06
A-J48LN-0808	-08	-08
A-J48LN-1010	-10	-10
A-J48LN-1212	-12	-12
A-J48LN-1414	-14	-14
A-J48LN-1616	-16	-16
A-J48LN-2020	-20	-20
A-J48LN-2424	-24	-24
A-J48LN-3232	-32	-32

ADAPTERS

JIC

JIC

ADAPTERS



JIC Bulkhead Nut

Part Number	JIC
A-J4-02	-02
A-J4-03	-03
A-J4-04	-04
A-J4-05	-05
A-J4-06	-06
A-J4-08	-08
A-J4-10	-10
A-J4-12	-12
A-J4-14	-14
A-J4-16	-16
A-J4-20	-20
A-J4-24	-24
A-J4-32	-32



JIC Male Branch Tee

Part Number	JIC M(T1)	JIC M(T2)
A-J5-18-0202	-02	-02
A-J5-18-0303	-03	-03
A-J5-18-0404	-04	-04
A-J5-18-0406	-04	-06
A-J5-18-0505	-05	-05
A-J5-18-0604	-06	-04
A-J5-18-0606	-06	-06
A-J5-18-0608	-06	-08
A-J5-18-0806	-08	-06
A-J5-18-0808	-08	-08
A-J5-18-0810	-08	-10
A-J5-18-0812	-08	-12
A-J5-18-1008	-10	-08
A-J5-18-1010	-10	-10
A-J5-18-1208	-12	-08
A-J5-18-1212	-12	-12
A-J5-18-1216	-12	-16
A-J5-18-1414	-14	-14
A-J5-18-1612	-16	-12
A-J5-18-1616	-16	-16
A-J5-18-2016	-20	-16
A-J5-18-2020	-20	-20
A-J5-18-2424	-24	-24
A-J5-18-3232	-32	-32

ADAPTERS

JIC

JIC

ADAPTERS



JIC Female x Male Branch Tee		
Part Number	JIC F(T1)	JIC M(T2)
A-J5-63-0303	-03	-03
A-J5-63-0404	-04	-04
A-J5-63-0505	-05	-05
A-J5-63-0606	-06	-06
A-J5-63-0806	-08	-06
A-J5-63-0808	-08	-08
A-J5-63-1010	-10	-10
A-J5-63-1212	-12	-12
A-J5-63-1414	-14	-14
A-J5-63-1616	-16	-16
A-J5-63-2020	-20	-20
A-J5-63-2424	-24	-24
A-J5-63-3232	-32	-32



JIC Female Branch Tee		
Part Number	JIC F(T1)	JIC F(T2)
A-J5-69-0404	-04	-04
A-J5-69-0505	-05	-05
A-J5-69-0606	-06	-06
A-J5-69-0808	-08	-08
A-J5-69-1010	-10	-10
A-J5-69-1212	-12	-12
A-J5-69-1616	-16	-16
A-J5-69-2020	-20	-20



JIC Female x Male Branch Tee		
Part Number	JIC M(T1)	JIC F(T2)
A-J6-24-0404	-04	-04
A-J6-24-0606	-06	-06
A-J6-24-0808	-08	-08
A-J6-24-1010	-10	-10
A-J6-24-1212	-12	-12
A-J6-24-1616	-16	-16



JIC Female x Male Run Tee		
Part Number	JIC F(T1)	JIC M(T2)
A-J6-63-0303	-03	-03
A-J6-63-0404	-04	-04
A-J6-63-0505	-05	-05
A-J6-63-0606	-06	-06
A-J6-63-0608	-06	-08
A-J6-63-0808	-08	-08
A-J6-63-0810	-08	-10
A-J6-63-1010	-10	-10
A-J6-63-1212	-12	-12
A-J6-63-1414	-14	-14
A-J6-63-1616	-16	-16
A-J6-63-2020	-20	-20
A-J6-63-2424	-24	-24
A-J6-63-3232	-32	-32

ADAPTERS

JIC

JIC

ADAPTERS



JIC Bulkhead Branch Tee		
Part Number	JIC M(T1)	JIC M(T2)
A-J5-48LN-0303	-03	-03
A-J5-48LN-0404	-04	-04
A-J5-48LN-0505	-05	-05
A-J5-48LN-0604	-06	-04
A-J5-48LN-0606	-06	-06
A-J5-48LN-0808	-08	-08
A-J5-48LN-1010	-10	-10
A-J5-48LN-1212	-12	-12
A-J5-48LN-1616	-16	-16
A-J5-48LN-2020	-20	-20
A-J5-48LN-2424	-24	-24



JIC Bulkhead Run Tee		
Part Number	JIC M(T1)	JIC M(T2)
A-J6-48LN-0303	-03	-03
A-J6-48LN-0404	-04	-04
A-J6-48LN-0505	-05	-05
A-J6-48LN-0604	-06	-04
A-J6-48LN-0606	-06	-06
A-J6-48LN-0808	-08	-08
A-J6-48LN-1008	-10	-08
A-J6-48LN-1010	-10	-10
A-J6-48LN-1212	-12	-12
A-J6-48LN-1616	-16	-16
A-J6-48LN-2020	-20	-20
A-J6-48LN-2424	-24	-24



JIC Male Cross		
Part Number	JIC M(T1)	JIC M(T2)
A-J7-18-0202	-02	-02
A-J7-18-0404	-04	-04
A-J7-18-0505	-05	-05
A-J7-18-0606	-06	-06
A-J7-18-0808	-08	-08
A-J7-18-1010	-10	-10
A-J7-18-1212	-12	-12
A-J7-18-1414	-14	-14
A-J7-18-1616	-16	-16
A-J7-18-2020	-20	-20
A-J7-18-2424	-24	-24

ADAPTERS

JIC