



ISO-A NPT Coupler

Part Number	Body Size	Thread Size
Q-IA-04C-04PF	-04	-04
Q-IA-06C-06PF	-06	-06
Q-IA-08C-08PF	-08	-08
Q-IA-08C-12PF	-08	-12
Q-IA-12C-12PF	-12	-12
Q-IA-16C-16PF	-16	-16
Q-IA-20C-20PF	-20	-20
Q-IA-24C-24PF	-24	-24
Q-IA-32C-32PF	-32	-32



ISO-A ORB Coupler

Part Number	Body Size	Thread Size
Q-IA-06C-06RF	-06	-06
Q-IA-06C-08RF	-06	-08
Q-IA-08C-10RF	-08	-10
Q-IA-12C-12RF	-12	-12
Q-IA-16C-16RF	-16	-16
Q-IA-20C-20RF	-20	-20
Q-IA-24C-24RF	-24	-24



ISO-A NPT Nipple

Part Number	Body Size	Thread Size
Q-IA-04N-04PF	-04	-04
Q-IA-06N-06PF	-06	-06
Q-IA-08N-08PF	-08	-08
Q-IA-08N-12PF	-08	-12
Q-IA-12N-12PF	-12	-12
Q-IA-16N-16PF	-16	-16
Q-IA-20N-20PF	-20	-20
Q-IA-24N-24PF	-24	-24
Q-IA-32N-32PF	-32	-32



ISO-A ORB Nipple

Part Number	Body Size	Thread Size
Q-IA-06N-06RF	-06	-06
Q-IA-06N-08RF	-06	-08
Q-IA-08N-10RF	-08	-10
Q-IA-12N-12RF	-12	-12
Q-IA-16N-16RF	-16	-16
Q-IA-20N-20RF	-20	-20
Q-IA-24N-24RF	-24	-24



ISO-A NPT Coupler SS316		
Part Number	Body Size	Thread Size
Q-IA-04C-04PF-SS	-04	-04
Q-IA-06C-06PF-SS	-06	-06
Q-IA-08C-08PF-SS	-08	-08
Q-IA-08C-12PF-SS	-08	-12
Q-IA-12C-12PF-SS	-12	-12
Q-IA-16C-16PF-SS	-16	-16
Q-IA-20C-20PF-SS	-20	-20
Q-IA-24C-24PF-SS	-24	-24
Q-IA-32C-32PF-SS	-32	-32



ISO-A NPT Nipple SS316		
Part Number	Body Size	Thread Size
Q-IA-04N-04PF-SS	-04	-04
Q-IA-06N-06PF-SS	-06	-06
Q-IA-08N-08PF-SS	-08	-08
Q-IA-08N-12PF-SS	-08	-12
Q-IA-12N-12PF-SS	-12	-12
Q-IA-16N-16PF-SS	-16	-16
Q-IA-20N-20PF-SS	-20	-20
Q-IA-24N-24PF-SS	-24	-24
Q-IA-32N-32PF-SS	-32	-32



ISO-A Dust Cap	
Part Number	Body Size
Q-IA-DC-04	-04
Q-IA-DC-06	-06
Q-IA-DC-08	-08
Q-IA-DC-12	-12
Q-IA-DC-16	-16



ISO-A Dust Plug	
Part Number	Body Size
Q-IA-DP-04	-04
Q-IA-DP-06	-06
Q-IA-DP-08	-08
Q-IA-DP-12	-12
Q-IA-DP-16	-16



ISO-B NPT Coupler		
Part Number	Body Size	Thread Size
Q-IB-02C-02PF	-02	-02
Q-IB-04C-04PF	-03	-04
Q-IB-06C-06PF	-04	-06
Q-IB-08C-08PF	-08	-08
Q-IB-12C-12PF	-12	-12
Q-IB-16C-16PF	-16	-16



ISO-B ORB Coupler		
Part Number	Body Size	Thread Size
Q-IB-02C-04RF	-02	-04
Q-IB-04C-06RF	-04	-06
Q-IB-06C-06RF	-06	-06
Q-IB-06C-08RF	-06	-08
Q-IB-08C-08RF	-08	-08
Q-IB-08C-10RF	-08	-10
Q-IB-12C-12RF	-12	-12
Q-IB-16C-16RF	-16	-16



ISO-B NPT Nipple		
Part Number	Body Size	Thread Size
Q-IB-02N-02PF	-02	-02
Q-IB-04N-04PF	-04	-04
Q-IB-06N-06PF	-06	-06
Q-IB-08N-08PF	-08	-08
Q-IB-12N-12PF	-12	-12
Q-IB-16N-16PF	-16	-16



ISO-B ORB Nipple		
Part Number	Body Size	Thread Size
Q-IB-02N-04RF	-02	-04
Q-IB-04N-06RF	-04	-06
Q-IB-06N-06RF	-06	-06
Q-IB-06N-08RF	-06	-08
Q-IB-08N-08RF	-08	-08
Q-IB-08N-10RF	-08	-10
Q-IB-12N-12RF	-12	-12
Q-IB-16N-16RF	-16	-16



ISO-B NPT Coupler Brass		
Part Number	Body Size	Thread Size
Q-IB-02C-02PF-B	-02	-02
Q-IB-04C-04PF-B	-03	-04
Q-IB-06C-06PF-B	-04	-06
Q-IB-08C-08PF-B	-08	-08
Q-IB-12C-12PF-B	-12	-12
Q-IB-16C-16PF-B	-16	-16



ISO-B NPT Nipple Brass		
Part Number	Body Size	Thread Size
Q-IB-02N-02PF-B	-02	-02
Q-IB-04N-04PF-B	-04	-04
Q-IB-06N-06PF-B	-06	-06
Q-IB-08N-08PF-B	-08	-08
Q-IB-12N-12PF-B	-12	-12
Q-IB-16N-16PF-B	-16	-16



ISO-B NPT Coupler SS316		
Part Number	Body Size	Thread Size
Q-IB-02C-02PF-SS	-02	-02
Q-IB-04C-04PF-SS	-03	-04
Q-IB-06C-06PF-SS	-04	-06
Q-IB-08C-08PF-SS	-08	-08
Q-IB-12C-12PF-SS	-12	-12
Q-IB-16C-16PF-SS	-16	-16



ISO-B NPT Nipple SS316		
Part Number	Body Size	Thread Size
Q-IB-02N-02PF-SS	-02	-02
Q-IB-04N-04PF-SS	-04	-04
Q-IB-06N-06PF-SS	-06	-06
Q-IB-08N-08PF-SS	-08	-08
Q-IB-12N-12PF-SS	-12	-12
Q-IB-16N-16PF-SS	-16	-16



ISO-B Dust Cap	
Part Number	Body Size
Q-IB-DC-04	-04
Q-IB-DC-06	-06
Q-IB-DC-08	-08
Q-IB-DC-12	-12
Q-IB-DC-16	-16



ISO-B Dust Plug	
Part Number	Body Size
Q-IB-DP-04	-04
Q-IB-DP-06	-06
Q-IB-DP-08	-08
Q-IB-DP-12	-12
Q-IB-DP-16	-16



Agriculture NPT Coupler		
Part Number	Body Size	Thread Size
Q-AG-04C-04PF	-04	-04
Q-AG-06C-06PF	-06	-06
Q-AG-08C-08PF	-08	-08
Q-AG-12C-12PF	-12	-12
Q-AG-16C-16PF	-16	-16



Agriculture ORB Coupler		
Part Number	Body Size	Thread Size
Q-AG-04C-06RF	-04	-06
Q-AG-06C-06RF	-06	-06
Q-AG-08C-08RF	-08	-08
Q-AG-08C-10RF	-08	-10



Agriculture NPT Nipple		
Part Number	Body Size	Thread Size
Q-AG-04N-04PF	-04	-04
Q-AG-06N-06PF	-06	-06
Q-AG-08N-08PF	-08	-08
Q-AG-12N-12PF	-12	-12
Q-AG-16N-16PF	-16	-16



Agriculture ORB Nipple		
Part Number	Body Size	Thread Size
Q-AG-04N-06RF	-04	-06
Q-AG-06N-06RF	-06	-06
Q-AG-08N-08RF	-08	-08
Q-AG-08N-10RF	-08	-10



Agriculture Push/Pull NPT Coupler

Part Number	Body Size	Thread Size
Q-AGP-08C-08PF	-08	-08



Agriculture Push/Pull ORB Coupler

Part Number	Body Size	Thread Size
Q-AGP-08C-08RF	-08	-08
Q-AGP-08C-10RF	-08	-10



Agriculture Push/Pull Metric Coupler

Part Number	Body Size	Thread Size
Q-AGP-08C-18MF	-08	M18X1.5
Q-AGP-08C-22MF	-08	M22X1.5



Agriculture Metric Nipple

Part Number	Body Size	Thread Size
Q-AG-08N-22MF	-08	M22X1.5



Agriculture Dust Cap

Part Number	Body Size
Q-AG-DC-04	-04
Q-AG-DC-06	-06
Q-AG-DC-08	-08
Q-AG-DC-12	-12
Q-AG-DC-16	-16



Agriculture Dust Plug

Part Number	Body Size
Q-AG-DP-04	-04
Q-AG-DP-06	-06
Q-AG-DP-08	-08
Q-AG-DP-12	-12
Q-AG-DP-16	-16



Flat Face NPT Coupler		
Part Number	Body Size	Thread Size
Q-FF-04C-04PF	-04	-04
Q-FF-06C-06PF	-06	-06
Q-FF-06C-08PF	-06	-08
Q-FF-08C-08PF	-08	-08
Q-FF-08C-12PF	-08	-12
Q-FF-10C-12PF	-10	-12
Q-FF-12C-12PF	-12	-12
Q-FF-12C-16PF	-12	-16
Q-FF-16C-16PF	-16	-16
Q-FF-16C-20PF	-16	-20
Q-FF-20C-24PF	-20	-24



Flat Face ORB Coupler		
Part Number	Body Size	Thread Size
Q-FF-04C-06RF	-04	-06
Q-FF-06C-06RF	-06	-06
Q-FF-06C-08RF	-06	-08
Q-FF-08C-08RF	-08	-08
Q-FF-08C-10RF	-08	-10
Q-FF-08C-12RF	-08	-12
Q-FF-10C-12RF	-10	-12
Q-FF-12C-12RF	-12	-12
Q-FF-12C-16RF	-12	-16
Q-FF-16C-16RF	-16	-16
Q-FF-16C-20RF	-16	-20



Flat Face ORFS Bulkhead Coupler		
Part Number	Body Size	Thread Size
Q-FF-08C-10FM-BH	-08	-10
Q-FF-08C-12FM-BH	-08	-12
Q-FF-08C-16FM-BH	-08	-16
Q-FF-10C-10FM-BH	-10	-10



Flat Face BSPP Coupler		
Part Number	Body Size	Thread Size
Q-FF-04C-04BF	-04	-04
Q-FF-06C-06BF	-06	-06
Q-FF-06C-08BF	-06	-08
Q-FF-08C-08BF	-08	-08
Q-FF-08C-12BF	-08	-12
Q-FF-10C-12BF	-10	-12
Q-FF-12C-12BF	-12	-12
Q-FF-12C-16BF	-12	-16
Q-FF-16C-16BF	-16	-16
Q-FF-16C-20BF	-16	-20



Flat Face NPT Nipple		
Part Number	Body Size	Thread Size
Q-FF-04N-04PF	-02	-04
Q-FF-06N-06PF	-06	-06
Q-FF-06N-08PF	-06	-08
Q-FF-08N-08PF	-08	-08
Q-FF-08N-12PF	-08	-12
Q-FF-10N-12PF	-10	-12
Q-FF-12N-12PF	-10	-12
Q-FF-12N-16PF	-12	-16
Q-FF-16N-16PF	-16	-16
Q-FF-16N-20PF	-16	-20
Q-FF-20N-24PF	-20	-24



Flat Face ORB Nipple		
Part Number	Body Size	Thread Size
Q-FF-04N-06RF	-04	-06
Q-FF-06N-06RF	-06	-06
Q-FF-06N-08RF	-06	-08
Q-FF-08N-08RF	-08	-08
Q-FF-08N-10RF	-08	-10
Q-FF-08N-12RF	-08	-12
Q-FF-10N-12RF	-10	-12
Q-FF-12N-12RF	-12	-12
Q-FF-12N-16RF	-12	-16
Q-FF-16N-16RF	-16	-16
Q-FF-16N-20RF	-16	-20



Flat Face ORFS Bulkhead Nipple		
Part Number	Body Size	Thread Size
Q-FF-08N-10FM-BH	-08	-10
Q-FF-08N-12FM-BH	-08	-12
Q-FF-08N-16FM-BH	-08	-16
Q-FF-10N-10FM-BH	-10	-10



Flat Face BSPP Coupler		
Part Number	Body Size	Thread Size
Q-FF-04N-04BF	-04	-04
Q-FF-06N-06BF	-06	-06
Q-FF-06N-08BF	-06	-08
Q-FF-08N-08BF	-08	-08
Q-FF-08N-12BF	-08	-12
Q-FF-10N-12BF	-10	-12
Q-FF-12N-12BF	-12	-12
Q-FF-12N-16BF	-12	-16
Q-FF-16N-16BF	-16	-16
Q-FF-16N-20BF	-16	-20



Flat Face NPT Coupler SS316		
Part Number	Body Size	Thread Size
Q-FF-04C-04PF-SS	-04	-04
Q-FF-06C-06PF-SS	-06	-06
Q-FF-06C-08PF-SS	-06	-08
Q-FF-08C-08PF-SS	-08	-08
Q-FF-08C-12PF-SS	-08	-12
Q-FF-10C-12PF-SS	-10	-12
Q-FF-12C-12PF-SS	-12	-12
Q-FF-12C-16PF-SS	-12	-16
Q-FF-16C-16PF-SS	-16	-16
Q-FF-16C-20PF-SS	-16	-20
Q-FF-20C-24PF-SS	-20	-24

Flat Face NPT Nipple SS316		
Part Number	Body Size	Thread Size
Q-FF-04N-04PF-SS	-02	-04
Q-FF-06N-06PF-SS	-06	-06
Q-FF-06N-08PF-SS	-06	-08
Q-FF-08N-08PF-SS	-08	-08
Q-FF-08N-12PF-SS	-08	-12
Q-FF-10N-12PF-SS	-10	-12
Q-FF-12N-12PF-SS	-10	-12
Q-FF-12N-16PF-SS	-12	-16
Q-FF-16N-16PF-SS	-16	-16
Q-FF-16N-20PF-SS	-16	-20
Q-FF-20N-24PF-SS	-20	-24



Flat Face Dust Cap	
Part Number	Body Size
Q-FF-DC-04N	-04
Q-FF-DC-06N	-06
Q-FF-DC-08N	-08
Q-FF-DC-10N	-10
Q-FF-DC-12N	-12
Q-FF-DC-16N	-16

Flat Face Dust Plug	
Part Number	Body Size
Q-FF-DC-04C	-04
Q-FF-DC-06C	-06
Q-FF-DC-08C	-08
Q-FF-DC-10C	-10
Q-FF-DC-12C	-12
Q-FF-DC-16C	-16

Ph. 780-413-0904
Fax 780-413-0905
Toll Free 1-800-239-0416



18141 - 111 Avenue
Edmonton, Alberta T5S 2P2
boschhydraulic.com

QUICK COUPLERS



71 Series NPT Coupler		
Part Number	Body Size	Thread Size
Q-71-08C-08PF	-08	-08
Q-71-12C-12PF	-12	-12
Q-71-16C-16PF	-16	-16
Q-71-16C-20PF	-16	-20



71 Series NPT Nipple		
Part Number	Body Size	Thread Size
Q-71-08N-08PF	-08	-08
Q-71-12N-12PF	-12	-12
Q-71-16N-16PF	-16	-16
Q-71-16N-20PF	-16	-20



71 Series Dust Cap	
Part Number	Body Size
Q-71-DC-08	-08
Q-71-DC-12	-12
Q-71-DC-16	-16



71 Series Dust Plug	
Part Number	Body Size
Q-71-DP-08	-08
Q-71-DP-12	-12
Q-71-DP-16	-16

QUICK COUPLERS



Wing Style NPT Coupler		
Part Number	Body Size	Thread Size
Q-WS-12C-08PF	-12	-08
Q-WS-12C-12PF	-12	-12
Q-WS-16C-16PF	-16	-16
Q-WS-20C-20PF	-20	-20
Q-WS-24C-24PF	-24	-24



Wing Style NPT Nipple		
Part Number	Body Size	Thread Size
Q-WS-12N-08PF	-12	-08
Q-WS-12N-12PF	-12	-12
Q-WS-16N-16PF	-16	-16
Q-WS-20N-20PF	-20	-20
Q-WS-24N-24PF	-24	-24



Wing Style Dust Cap	
Part Number	Body Size
Q-WS-DC-12	-12
Q-WS-DC-16	-16
Q-WS-DC-20	-20
Q-WS-DC-24	-24



Wing Style Dust Plug	
Part Number	Body Size
Q-WS-DP-12	-12
Q-WS-DP-16	-16
Q-WS-DP-20	-20
Q-WS-DP-24	-24



PTC NPT Coupler		
Part Number	Body Size	Thread Size
Q-PTC-08C-08PF	-08	-08
Q-PTC-12C-12PF	-12	-12
Q-PTC-16C-16PF	-16	-16
Q-PTC-20C-20PF	-20	-20



PTC NPT Nipple		
Part Number	Body Size	Thread Size
Q-PTC-08N-08PF	-08	-08
Q-PTC-12N-12PF	-12	-12
Q-PTC-16N-16PF	-16	-16
Q-PTC-20N-20PF	-20	-20



PTC Dust Cap	
Part Number	Body Size
Q-PTC-DC-08	-04
Q-PTC-DC-12	-12
Q-PTC-DC-16	-16
Q-PTC-DC-20	-20



PTC Dust Plug	
Part Number	Body Size
Q-PTC-DP-08	-08
Q-PTC-DP-12	-12
Q-PTC-DP-16	-16
Q-PTC-DP-20	-20



Jack Female NPT Coupler		
Part Number	Body Size	Thread Size
Q-PSB-04C-04PF	-04	-04
Q-PSB-06C-06PF	-06	-06



Jack Male NPT Coupler		
Part Number	Body Size	Thread Size
Q-PSB-04C-04PM	-04	-04
Q-PSB-06C-06PM	-06	-06



Jack Female NPT Nipple		
Part Number	Body Size	Thread Size
Q-PSB-04N-04PF	-04	-04
Q-PSB-06N-06PF	-06	-06



Jack Dust Cap	
Part Number	Body Size
Q-PS-DC-04	-04
Q-PS-DC-06	-06



Jack Dust Plug	
Part Number	Body Size
Q-PS-DP-04	-04
Q-PS-DP-06	-06



VEP NPT Coupler

Part Number	Body Size	Thread Size
Q-HFT-04C-04PF	-04	-04
Q-HFT-06C-06PF	-06	-06
Q-HFT-06C-08PF	-06	-08
Q-HFT-08C-08PF	-08	-08
Q-HFT-08C-12PF	-08	-12
Q-HFT-12C-12PF	-12	-12
Q-HFT-16C-12PF	-16	-12
Q-HFT-16C-16PF	-16	-16
Q-HFT-20C-20PF	-20	-20
Q-HFT-24C-24PF	-24	-24
Q-HFT-32C-32PF	-32	-32

VEP ORB Coupler

Part Number	Body Size	Thread Size
Q-HFT-04C-04RF	-04	-04
Q-HFT-06C-06RF	-06	-06
Q-HFT-06C-08RF	-06	-08
Q-HFT-08C-08RF	-08	-08
Q-HFT-08C-12RF	-08	-12
Q-HFT-12C-12RF	-12	-12
Q-HFT-16C-16RF	-16	-16
Q-HFT-20C-20RF	-20	-20
Q-HFT-24C-24RF	-24	-24



VEP NPT Nipple

Part Number	Body Size	Thread Size
Q-HFT-04N-04PF	-04	-04
Q-HFT-06N-06PF	-06	-06
Q-HFT-06N-08PF	-06	-08
Q-HFT-08N-08PF	-08	-08
Q-HFT-08N-12PF	-08	-12
Q-HFT-12N-12PF	-12	-12
Q-HFT-16N-12PF	-16	-12
Q-HFT-16N-16PF	-16	-16
Q-HFT-20N-20PF	-20	-20
Q-HFT-24N-24PF	-24	-24
Q-HFT-32N-32PF	-32	-32

VEP ORB Nipple

Part Number	Body Size	Thread Size
Q-HFT-04N-04RF	-04	-04
Q-HFT-06N-06RF	-06	-06
Q-HFT-06N-08RF	-06	-08
Q-HFT-08N-08RF	-08	-08
Q-HFT-08N-12RF	-08	-12
Q-HFT-12N-12RF	-12	-12
Q-HFT-16N-16RF	-16	-16
Q-HFT-20N-20RF	-20	-20
Q-HFT-24N-24RF	-24	-24



VEP Dust Cap	
Part Number	Body Size
Q-HFT-DC-06	-06
Q-HFT-DC-08	-08
Q-HFT-DC-12	-12
Q-HFT-DC-16	-16
Q-HFT-DC-20	-20
Q-HFT-DC-24	-24
Q-HFT-DC-32	-32



VEP Dust Plug	
Part Number	Body Size
Q-HFT-DP-06	-06
Q-HFT-DP-08	-08
Q-HFT-DP-12	-12
Q-HFT-DP-16	-16
Q-HFT-DP-20	-20
Q-HFT-DP-24	-24
Q-HFT-DP-32	-32



Heavy Duty Wing NPT Coupler		
Part Number	Body Size	Thread Size
Q-LC-12C-08PF	-12	-08
Q-LC-12C-12PF	-12	-12
Q-LC-16C-16PF	-16	-16
Q-LC-20C-20PF	-20	-20
Q-LC-24C-24PF	-24	-24
Q-LC-32C-32PF	-32	-32



Heavy Duty Wing NPT Nipple		
Part Number	Body Size	Thread Size
Q-LC-12N-08PF	-12	-08
Q-LC-12N-12PF	-12	-12
Q-LC-16N-16PF	-16	-16
Q-LC-20N-20PF	-20	-20
Q-LC-24N-24PF	-24	-24
Q-LC-32N-32PF	-32	-32



Heavy Duty Wing Dust Cap	
Part Number	Body Size
Q-LC-DC-12-ALM	-12
Q-LC-DC-16-ALM	-16
Q-LC-DC-20-ALM	-20
Q-LC-DC-24-ALM	-24
Q-LC-DC-32-ALM	-32



Heavy Duty Wing Dust Plug	
Part Number	Body Size
Q-LC-DP-12-ALM	-12
Q-LC-DP-16-ALM	-16
Q-LC-DP-20-ALM	-20
Q-LC-DP-24-ALM	-24
Q-LC-DP-32-ALM	-32



HS NPT Coupler		
Part Number	Body Size	Thread Size
Q-HS-02C-06PF	Group 02	-06
Q-HS-03C-08PF	Group 03	-08
Q-HS-04C-12PF	Group 04	-12
Q-HS-06C-16PF	Group 06	-16



HS BSPP Coupler		
Part Number	Body Size	Thread Size
Q-HS-02C-06BF	Group 02	-06
Q-HS-03C-06BF	Group 03	-06
Q-HS-03C-08BF	Group 03	-08
Q-HS-04C-12BF	Group 04	-12
Q-HS-06C-16BF	Group 06	-16



HS DIN Coupler		
Part Number	Body Size	Thread Size
Q-HS-02C-10LM	Group 02	10L
Q-HS-02C-12SM	Group 02	12S
Q-HS-03C-12SM	Group 03	12S
Q-HS-04C-20SM	Group 04	20S
Q-HS-04C-22LM	Group 04	22L
Q-HS-06C-22LM	Group 06	22L
Q-HS-06C-30SM	Group 06	30S
Q-HS-08C-30SM	Group 08	30S
Q-HS-08C-38SM	Group 08	38S



HS DIN Bulkhead Coupler		
Part Number	Body Size	Thread Size
Q-HS-02C-10LM-BH	Group 02	10L
Q-HS-04C-15LM-BH	Group 04	15L
Q-HS-04C-20SM-BH	Group 04	20S
Q-HS-06C-30SM-BH	Group 06	30S
Q-HS-08C-30SM-BH	Group 08	30S
Q-HS-08C-38SM-BH	Group 08	38S



HS NPT Nipple

Part Number	Body Size	Thread Size
Q-HS-02N-06PF	Group 02	-06
Q-HS-03N-08PF	Group 03	-08
Q-HS-04N-12PF	Group 04	-12
Q-HS-06N-16PF	Group 06	-16



HS BSPP Nipple

Part Number	Body Size	Thread Size
Q-HS-02N-06BF	Group 02	-06
Q-HS-03N-06BF	Group 03	-06
Q-HS-03N-08BF	Group 03	-08
Q-HS-04N-12BF	Group 04	-12
Q-HS-06N-16BF	Group 06	-16



HS DIN Nipple

Part Number	Body Size	Thread Size
Q-HS-02N-10LM	Group 02	10L
Q-HS-02N-12SM	Group 02	12S
Q-HS-03N-12SM	Group 03	12S
Q-HS-04N-20SM	Group 04	20S
Q-HS-04N-22LM	Group 04	22L
Q-HS-06N-22LM	Group 06	22L
Q-HS-06N-25SM	Group 06	25S
Q-HS-06N-30SM	Group 06	30S
Q-HS-08N-30SM	Group 08	30S
Q-HS-08N-38SM	Group 08	38S



HS DIN Bulkhead Nipple

Part Number	Body Size	Thread Size
Q-HS-02N-10LM-BH	Group 02	10L
Q-HS-02N-12SM-BH	Group 02	12S
Q-HS-04N-20SM-BH	Group 04	20S
Q-HS-06N-30SM-BH	Group 06	30S
Q-HS-08N-30SM-BH	Group 08	30S
Q-HS-08N-38SM-BH	Group 08	38S



HS Dust Cap

Part Number	Body Size
Q-HS-DC-02	Group 02
Q-HS-DC-03	Group 03
Q-HS-DC-04	Group 04
Q-HS-DC-06	Group 06
Q-HS-DC-08	Group 08



HS Dust Plug

Part Number	Body Size
Q-HS-DP-02	Group 02
Q-HS-DP-03	Group 03
Q-HS-DP-04	Group 04
Q-HS-DP-06	Group 06
Q-HS-DP-08	Group 08



RK DIN Loose Half		
Part Number	Body Size	Thread Size
Q-RK-08L-L-2	Group 02	08L
Q-RK-10L-L-2	Group 02	10L
Q-RK-10S-L-2	Group 02	10S
Q-RK-12L-L-2	Group 02	12L
Q-RK-12S-L-2	Group 02	12S
Q-RK-14S-L-2	Group 02	14S
Q-RK-15L-L-2	Group 02	15L
Q-RK-16S-L-2	Group 02	16S
Q-RK-15L-L-3	Group 03	15L
Q-RK-16S-L-3	Group 03	16S
Q-RK-20S-L-3	Group 03	20S
Q-RK-16S-L-4	Group 04	16S
Q-RK-18L-L-4	Group 04	18L
Q-RK-20S-L-4	Group 04	20S
Q-RK-18L-L-6	Group 06	18L
Q-RK-20S-L-6	Group 06	20S
Q-RK-22L-L-6	Group 06	22L
Q-RK-25S-L-6	Group 06	25S
Q-RK-28L-L-6	Group 06	28L
Q-RK-30S-L-6	Group 06	30S
Q-RK-35L-L-8	Group 08	35L
Q-RK-38S-L-8	Group 08	38S
Q-RK-42L-L-8	Group 08	42L

RK DIN Fixed Half		
Part Number	Body Size	Thread Size
Q-RK-08L-F-2	Group 02	08L
Q-RK-10L-F-2	Group 02	10L
Q-RK-10S-F-2	Group 02	10S
Q-RK-12L-F-2	Group 02	12L
Q-RK-12S-F-2	Group 02	12S
Q-RK-14S-F-2	Group 02	14S
Q-RK-15L-F-2	Group 02	15L
Q-RK-16S-F-2	Group 02	16S
Q-RK-15L-F-3	Group 03	15L
Q-RK-16S-F-3	Group 03	16S
Q-RK-20S-F-3	Group 03	20S
Q-RK-16S-F-4	Group 04	16S
Q-RK-18L-F-4	Group 04	18L
Q-RK-20S-F-4	Group 04	20S
Q-RK-18L-F-6	Group 06	18L
Q-RK-20S-F-6	Group 06	20S
Q-RK-22L-F-6	Group 06	22L
Q-RK-25S-F-6	Group 06	25S
Q-RK-28L-F-6	Group 06	28L
Q-RK-30S-F-6	Group 06	30S
Q-RK-35L-F-8	Group 08	35L
Q-RK-38S-F-8	Group 08	38S
Q-RK-42L-F-8	Group 08	42L



RK Dust Cap	
Part Number	Body Size
Q-RK-DC-02	Group 02
Q-RK-DC-03	Group 03
Q-RK-DC-04	Group 04
Q-RK-DC-06	Group 06
Q-RK-DC-08	Group 08

RK Dust Plug	
Part Number	Body Size
Q-RK-DP-02	Group 02
Q-RK-DP-03	Group 03
Q-RK-DP-04	Group 04
Q-RK-DP-06	Group 06
Q-RK-DP-08	Group 08